















## Which tools fit which attachments?

Attachments / Tools	Workstation (220)	Flex Shaft (225)	Router Table (231)	Plunge Router (335)	Right Angle Attachment (575)	Multipurpose Cutting Kit (565)	Wall Tile Cutting Kit (566)	Grout Removal Kit (568)	Mini Saw (670)	Line Circle Cutter (678)	Shaping Platform Attachment (576)	Detailer's Grip Attachment (577)	Chainsaw Sharpener (1453)	Flex Shaft Tool Holder (222)
														
DREMEL® Fortiflex	x	x	x	x	x	x	x	x	x	x	x	x	x	•
DREMEL® 8000 10.8V	•	•	x	x	•	•	•	•	x	•	•	•	•	•
DREMEL® 4000	•	•	•	•	•	•	•	•	•	•	•	•	•	•
DREMEL® 398 / 400 Series	•	•	Adapt	•	•	•	•	•	•	•	•	•	•	•
DREMEL® Stylus	x	x	x	x	x	x	x	x	x	x	x	x	x	x
DREMEL® 7700	NA	NA	x	x	NA	NA	NA	NA	x	NA	•	•	•	x
DREMEL® 300 Series	•	•	Adapt	•	•	•	•	•	•	•	•	•	•	•
DREMEL® 395 Multipro	•	•	•	•	•	•	•	•	•	•	•	•	•	•
DREMEL® 200 Series	•	•	•	•	•	•	•	•	•	•	•	•	•	•
DREMEL® 8200 10.8V	•	•	Adapt	•	•	•	•	•	•	•	•	•	•	•

• : Possible Combination

x : Combination not possible

Adapt : If you are facing problems to fit your tool to the attachment 231 you need an adaptor. Request it through your local hotline free of charge

NA : The combination of tool and attachment is possible but not advised

[» Close window](#)