

# MSP430 Hardware Tools

## User's Guide



Literature Number: SLAU278M  
May 2009–Revised March 2013

|  |           |
|--|-----------|
| <b>Preface</b> .....   | <b>7</b>  |
| <b>1 Get Started Now!</b> .....  | <b>12</b> |
| 1.1 Flash Emulation Tool (FET) Overview .....  | 13        |
| 1.2 Kit Contents, MSP-FET430PIF .....  | 14        |
| 1.3 Kit Contents, eZ430-F2013 .....  | 14        |
| 1.4 Kit Contents, eZ430-T2012 .....  | 14        |
| 1.5 Kit Contents, eZ430-RF2500 .....   | 14        |
| 1.6 Kit Contents, eZ430-RF2500T .....  | 14        |
| 1.7 Kit Contents, eZ430-RF2500-SEH .....   | 14        |
| 1.8 Kit Contents, eZ430-Chronos-xxx .....  | 15        |
| 1.9 Kit Contents, MSP-FET430UIF .....  | 15        |
| 1.10 Kit Contents, MSP-FET430xx .....  | 15        |
| 1.11 Kit Contents, FET430F6137RF900 .....  | 16        |
| 1.12 Kit Contents, MSP-TS430xx .....   | 17        |
| 1.13 Kit Contents, EM430Fx1x7RF900 .....   | 19        |
| 1.14 Hardware Installation, MSP-FET430PIF .....  | 19        |
| 1.15 Hardware Installation, MSP-FET430UIF .....  | 19        |
| 1.16 Hardware Installation, eZ430-XXXX, MSP-EXP430G2, MSP-EXP430FR5739, MSP-EXP430F5529 .....    | 20        |
| 1.17 Hardware Installation, MSP-FET430Uxx, MSP-TS430xxx, FET430F6137RF900, EM430Fx137RF900 ..... | 20        |
| 1.18 Important MSP430 Documents on the Web .....   | 20        |
| <b>2 Design Considerations for In-Circuit Programming</b> .....                                  | <b>21</b> |
| 2.1 Signal Connections for In-System Programming and Debugging .....                             | 22        |
| 2.2 External Power .....   | 26        |
| 2.3 Bootstrap Loader (BSL) .....   | 26        |
| <b>A Frequently Asked Questions and Known Issues</b> .....                                       | <b>27</b> |
| A.1 Hardware FAQs .....  | 28        |
| A.2 Known Issues .....   | 30        |
| <b>B Hardware</b> .....  | <b>31</b> |
| B.1 MSP-TS430D8 .....  | 33        |
| B.2 MSP-TS430PW14 .....  | 36        |
| B.3 MSP-TS430L092 .....  | 39        |
| B.4 MSP-TS430L092 Active Cable .....   | 42        |
| B.5 MSP-TS430PW24 .....  | 45        |
| B.6 MSP-TS430DW28 .....  | 48        |
| B.7 MSP-TS430PW28 .....  | 51        |
| B.8 MSP-TS430PW28A .....   | 54        |
| B.9 MSP-TS430DA38 .....  | 57        |
| B.10 MSP-TS430QFN23x0 .....  | 60        |
| B.11 MSP-TS430RSB40 .....  | 63        |
| B.12 MSP-TS430RHA40A .....   | 66        |
| B.13 MSP-TS430DL48 .....   | 69        |
| B.14 MSP-TS430RGZ48B .....   | 72        |
| B.15 MSP-TS430RGZ48C .....   | 75        |
| B.16 MSP-TS430PM64 .....   | 78        |

|          |  |            |
|----------|--|------------|
| B.17     | MSP-TS430PM64A .....                     | 81         |
| B.18     | MSP-TS430RGC64B .....                    | 84         |
| B.19     | MSP-TS430RGC64C .....                    | 87         |
| B.20     | MSP-TS430RGC64USB .....                  | 91         |
| B.21     | MSP-TS430PN80 .....                      | 95         |
| B.22     | MSP-TS430PN80A .....                     | 98         |
| B.23     | MSP-TS430PN80USB .....                   | 101        |
| B.24     | MSP-TS430PZ100 .....                     | 105        |
| B.25     | MSP-TS430PZ100A .....                    | 108        |
| B.26     | MSP-TS430PZ100B .....                    | 111        |
| B.27     | MSP-TS430PZ100C .....                    | 114        |
| B.28     | MSP-TS430PZ5x100 .....                   | 118        |
| B.29     | MSP-TS430PZ100USB .....                  | 121        |
| B.30     | MSP-TS430PEU128 .....                    | 125        |
| B.31     | EM430F5137RF900 .....                    | 128        |
| B.32     | EM430F6137RF900 .....                    | 132        |
| B.33     | EM430F6147RF900 .....                    | 136        |
| B.34     | MSP-FET430PIF .....                      | 140        |
| B.35     | MSP-FET430UIF .....                      | 142        |
| B.35.1   | MSP-FET430UIF Revision History .....     | 147        |
| <b>C</b> | <b>Hardware Installation Guide .....</b> | <b>148</b> |
| C.1      | Hardware Installation .....              | 149        |
|          | <b>Document Revision History .....</b>   | <b>154</b> |

## List of Figures

|       |   |    |
|-------|---|----|
| 2-1.  | Signal Connections for 4-Wire JTAG Communication.....   | 23 |
| 2-2.  | Signal Connections for 2-Wire JTAG Communication (Spy-Bi-Wire) Used by MSP430F2xx, MSP430G2xx and MSP430F4xx Devices..... | 24 |
| 2-3.  | Signal Connections for 2-Wire JTAG Communication (Spy-Bi-Wire) Used by MSP430F5xx and MSP430F6xx Devices .....            | 25 |
| B-1.  | MSP-TS430D8 Target Socket Module, Schematic .....   | 33 |
| B-2.  | MSP-TS430D8 Target Socket Module, PCB .....   | 34 |
| B-3.  | MSP-TS430PW14 Target Socket Module, Schematic .....   | 36 |
| B-4.  | MSP-TS430PW14 Target Socket Module, PCB .....   | 37 |
| B-5.  | MSP-TS430L092 Target Socket Module, Schematic.....  | 39 |
| B-6.  | MSP-TS430L092 Target Socket Module, PCB.....  | 40 |
| B-7.  | MSP-TS430L092 Active Cable Target Socket Module, Schematic.....   | 42 |
| B-8.  | MSP-TS430L092 Active Cable Target Socket Module, PCB.....   | 43 |
| B-9.  | MSP-TS430PW24 Target Socket Module, Schematic .....   | 45 |
| B-10. | MSP-TS430PW24 Target Socket Module, PCB .....   | 46 |
| B-11. | MSP-TS430DW28 Target Socket Module, Schematic .....   | 48 |
| B-12. | MSP-TS430DW28 Target Socket Module, PCB .....   | 49 |
| B-13. | MSP-TS430PW28 Target Socket Module, Schematic .....   | 51 |
| B-14. | MSP-TS430PW28 Target Socket Module, PCB .....   | 52 |
| B-15. | MSP-TS430PW28A Target Socket Module, Schematic.....   | 54 |
| B-16. | MSP-TS430PW28A Target Socket Module, PCB (Red) .....  | 55 |
| B-17. | MSP-TS430DA38 Target Socket Module, Schematic .....   | 57 |
| B-18. | MSP-TS430DA38 Target Socket Module, PCB .....   | 58 |
| B-19. | MSP-TS430QFN23x0 Target Socket Module, Schematic .....  | 60 |
| B-20. | MSP-TS430QFN23x0 Target Socket Module, PCB .....  | 61 |
| B-21. | MSP-TS430RSB40 Target Socket Module, Schematic .....  | 63 |
| B-22. | MSP-TS430RSB40 Target Socket Module, PCB .....  | 64 |
| B-23. | MSP-TS430RHA40A Target Socket Module, Schematic .....   | 66 |
| B-24. | MSP-TS430RHA40A Target Socket Module, PCB .....   | 67 |
| B-25. | MSP-TS430DL48 Target Socket Module, Schematic .....   | 69 |
| B-26. | MSP-TS430DL48 Target Socket Module, PCB .....   | 70 |
| B-27. | MSP-TS430RGZ48B Target Socket Module, Schematic .....   | 72 |
| B-28. | MSP-TS430RGZ48B Target Socket Module, PCB .....   | 73 |
| B-29. | MSP-TS430RGZ48C Target Socket Module, Schematic .....   | 75 |
| B-30. | MSP-TS430RGZ48C Target Socket Module, PCB .....   | 76 |
| B-31. | MSP-TS430PM64 Target Socket Module, Schematic.....  | 78 |
| B-32. | MSP-TS430PM64 Target Socket Module, PCB.....  | 79 |
| B-33. | MSP-TS430PM64A Target Socket Module, Schematic.....   | 81 |
| B-34. | MSP-TS430PM64A Target Socket Module, PCB .....  | 82 |
| B-35. | MSP-TS430RGC64B Target Socket Module, Schematic .....   | 84 |
| B-36. | MSP-TS430RGC64B Target Socket Module, PCB .....   | 85 |
| B-37. | MSP-TS430RGC64C Target Socket Module, Schematic.....  | 88 |
| B-38. | MSP-TS430RGC64C Target Socket Module, PCB .....   | 89 |
| B-39. | MSP-TS430RGC64USB Target Socket Module, Schematic .....   | 91 |
| B-40. | MSP-TS430RGC64USB Target Socket Module, PCB .....   | 92 |
| B-41. | MSP-TS430PN80 Target Socket Module, Schematic .....   | 95 |
| B-42. | MSP-TS430PN80 Target Socket Module, PCB .....   | 96 |
| B-43. | MSP-TS430PN80A Target Socket Module, Schematic .....  | 98 |

|       |   |     |
|-------|---|-----|
| B-44. | MSP-TS430PN80A Target Socket Module, PCB .....                            | 99  |
| B-45. | MSP-TS430PN80USB Target Socket Module, Schematic .....                    | 101 |
| B-46. | MSP-TS430PN80USB Target Socket Module, PCB .....                          | 102 |
| B-47. | MSP-TS430PZ100 Target Socket Module, Schematic .....                      | 105 |
| B-48. | MSP-TS430PZ100 Target Socket Module, PCB .....                            | 106 |
| B-49. | MSP-TS430PZ100A Target Socket Module, Schematic.....                      | 108 |
| B-50. | MSP-TS430PZ100A Target Socket Module, PCB.....                            | 109 |
| B-51. | MSP-TS430PZ100B Target Socket Module, Schematic.....                      | 111 |
| B-52. | MSP-TS430PZ100B Target Socket Module, PCB.....                            | 112 |
| B-53. | MSP-TS430PZ100C Target Socket Module, Schematic .....                     | 114 |
| B-54. | MSP-TS430PZ100C Target Socket Module, PCB .....                           | 115 |
| B-55. | MSP-TS430PZ5x100 Target Socket Module, Schematic .....                    | 118 |
| B-56. | MSP-TS430PZ5x100 Target Socket Module, PCB.....                           | 119 |
| B-57. | MSP-TS430PZ100USB Target Socket Module, Schematic.....                    | 121 |
| B-58. | MSP-TS430PZ100USB Target Socket Module, PCB .....                         | 122 |
| B-59. | MSP-TS430PEU128 Target Socket Module, Schematic .....                     | 125 |
| B-60. | MSP-TS430PEU128 Target Socket Module, PCB .....                           | 126 |
| B-61. | EM430F5137RF900 Target board, Schematic.....                              | 128 |
| B-62. | EM430F5137RF900 Target board, PCB.....                                    | 129 |
| B-63. | EM430F6137RF900 Target board, Schematic.....                              | 132 |
| B-64. | EM430F6137RF900 Target board, PCB.....                                    | 133 |
| B-65. | EM430F6147RF900 Target Board, Schematic .....                             | 136 |
| B-66. | EM430F6147RF900 Target Board, PCB .....                                   | 137 |
| B-67. | MSP-FET430PIF FET Interface Module, Schematic.....                        | 140 |
| B-68. | MSP-FET430PIF FET Interface Module, PCB.....                              | 141 |
| B-69. | MSP-FET430UIF USB Interface, Schematic (1 of 4) .....                     | 142 |
| B-70. | MSP-FET430UIF USB Interface, Schematic (2 of 4) .....                     | 143 |
| B-71. | MSP-FET430UIF USB Interface, Schematic (3 of 4) .....                     | 144 |
| B-72. | MSP-FET430UIF USB Interface, Schematic (4 of 4) .....                     | 145 |
| B-73. | MSP-FET430UIF USB Interface, PCB .....                                    | 146 |
| C-1.  | Windows XP Hardware Wizard .....  | 149 |
| C-2.  | Windows XP Driver Location Selection Folder.....                          | 150 |
| C-3.  | Device Manager Using USB Debug Interface using VID/PID 0x2047/0x0010..... | 151 |
| C-4.  | Device Manager Using USB Debug Interface with VID/PID 0x0451/0xF430 ..... | 152 |
| C-5.  | Device Manager Using USB Debug Interface with VID/PID 0x0451/0xF432 ..... | 153 |

## List of Tables

|       |  |     |
|-------|--|-----|
| 1-1.  | Flash Emulation Tool (FET) Features and Device Compatibility ..... | 13  |
| 1-2.  | Individual Kit Contents, MSP-TS430xx .....                         | 17  |
| B-1.  | MSP-TS430D8 Bill of Materials .....                                | 35  |
| B-2.  | MSP-TS430PW14 Bill of Materials .....                              | 38  |
| B-3.  | MSP-TS430L092 Bill of Materials .....                              | 41  |
| B-4.  | MSP-TS430L092 JP1 Settings .....                                   | 43  |
| B-5.  | MSP-TS430L092 Active Cable Bill of Materials .....                 | 44  |
| B-6.  | MSP-TS430PW24 Bill of Materials .....                              | 47  |
| B-7.  | MSP-TS430DW28 Bill of Materials .....                              | 50  |
| B-8.  | MSP-TS430PW28 Bill of Materials .....                              | 53  |
| B-9.  | MSP-TS430PW28A Bill of Materials .....                             | 56  |
| B-10. | MSP-TS430DA38 Bill of Materials .....                              | 59  |
| B-11. | MSP-TS430QFN23x0 Bill of Materials .....                           | 62  |
| B-12. | MSP-TS430RSB40 Bill of Materials .....                             | 65  |
| B-13. | MSP-TS430RHA40A Bill of Materials .....                            | 68  |
| B-14. | MSP-TS430DL48 Bill of Materials .....                              | 71  |
| B-15. | MSP-TS430RGZ48B Bill of Materials .....                            | 74  |
| B-16. | MSP-TS430RGZ48C Revision History .....                             | 76  |
| B-17. | MSP-TS430RGZ48C Bill of Materials .....                            | 77  |
| B-18. | MSP-TS430PM64 Bill of Materials .....                              | 80  |
| B-19. | MSP-TS430PM64A Bill of Materials .....                             | 83  |
| B-20. | MSP-TS430RGC64B Bill of Materials .....                            | 86  |
| B-21. | MSP-TS430RGC64C Bill of Materials .....                            | 90  |
| B-22. | MSP-TS430RGC64USB Bill of Materials .....                          | 93  |
| B-23. | MSP-TS430PN80 Bill of Materials .....                              | 97  |
| B-24. | MSP-TS430PN80A Bill of Materials .....                             | 100 |
| B-25. | MSP-TS430PN80USB Bill of Materials .....                           | 103 |
| B-26. | MSP-TS430PZ100 Bill of Materials .....                             | 107 |
| B-27. | MSP-TS430PZ100A Bill of Materials .....                            | 110 |
| B-28. | MSP-TS430PZ100B Bill of Materials .....                            | 113 |
| B-29. | MSP-TS430PZ100C Bill of Materials .....                            | 116 |
| B-30. | MSP-TS430PZ5x100 Bill of Materials .....                           | 120 |
| B-31. | MSP-TS430PZ100USB Bill of Materials .....                          | 123 |
| B-32. | MSP-TS430PEU128 Bill of Materials .....                            | 127 |
| B-33. | EM430F5137RF900 Bill of Materials .....                            | 130 |
| B-34. | EM430F6137RF900 Bill of Materials .....                            | 134 |
| B-35. | EM430F6147RF900 Bill of Materials .....                            | 138 |
| C-1.  | USB VIDs and PIDs Used in MSP430 Tools .....                       | 149 |

## Read This First

---

---

---

### About This Manual

This manual describes the hardware of the Texas Instruments MSP-FET430 Flash Emulation Tool (FET). The FET is the program development tool for the MSP430 ultralow-power microcontroller. Both available interface types, the parallel port interface and the USB interface, are described.

### How to Use This Manual

Read and follow the instructions in [Chapter 1](#). This chapter lists the contents of the FET, provides instructions on installing the hardware and according software drivers. After you see how quick and easy it is to use the development tools, TI recommends that you read all of this manual.

This manual describes the setup and operation of the FET but does not fully describe the MSP430™ microcontrollers or the development software systems. For details of these items, see the appropriate TI documents listed in [Section 1.18](#).

This manual applies to the following tools (and devices):

- MSP-FET430PIF (debug interface with parallel port connection, for all MSP430 flash-based devices)
- MSP-FET430UIF (debug interface with USB connection, for all MSP430 flash-based devices)
- eZ430-F2013 (USB stick form factor interface with attached MSP430F2013 target, for all MSP430F20xx, MSP430G2x01, MSP430G2x11, MSP430G2x21, and MSP430G2x31 devices)
- eZ430-T2012 (three MSP430F2012 based target boards)
- eZ430-RF2500 (USB stick form factor interface with attached MSP430F2274 and CC2500 target, for all MSP430F20xx, MSP430F21x2, MSP430F22xx, MSP430G2x01, MSP430G2x11, MSP430G2x21, and MSP430G2x31 devices)
- eZ430-RF2500T (one MSP430F2274 and CC2500 target board including battery pack)
- eZ430-RF2500-SEH (USB stick form factor interface with attached MSP430F2274 and CC2500 target and solar energy harvesting module)
- eZ430-Chronos-xxx (USB stick form factor interface with CC430F6137 based development system contained in a watch. Includes <1 GHz RF USB access point)

The following tools contain the USB debug interface (MSP-FET430UIF) and the respective target socket module:

- MSP-FET430U8 (for MSP430G2210 and MSP430G2230 devices in 8-pin D packages) (green PCB)
- MSP-FET430U14 (for MSP430F20xx, MSP430F20xx, MSP430G2x01, MSP430G2x11, MSP430G2x21, and MSP430G2x31 devices in 14-pin PW packages) (green PCB)
- MSP-FET430U092 (for MSP430FL092 devices in 14-pin PW packages) (green PCB)
- MSP-FET430U24 (for MSP430AFE2xx devices in 24-pin PW packages) (green PCB)
- MSP-FET430U28 (for MSP430F11xx(A) devices in 20- and 28-pin DW or PW packages)
- MSP-FET430U28A (for MSP430F20xx and MSP430G2xxx devices in 14-, 20-, and 28-pin PW)
- MSP-FET430U38 (for MSP430F22x2 and MSP430F22x4 devices in 38-pin DA packages)
- MSP-FET430U23x0 (for MSP430F23x0 devices in 40-pin RHA packages)
- MSP-FET430U40 (for MSP430F51x1, MSP430F51x2 devices in 40-pin RSB packages)
- MSP-FET430U40A (for MSP430FR572x, MSP430FR573x devices in 40-pin RHA packages)
- MSP-FET430U48 (for MSP430F22x2 and MSP430F22x4 devices in 48-pin DL packages)
- MSP-FET430U48B (for MSP430F534x devices in 48-pin RGZ packages)

- MSP-FET430U48C (for MSP430FR58xx and MSP430FR59xx devices in 48-pin RGZ packages)
- MSP-FET430U64 (for MSP430F13x, MSP430F14x, MSP430F14x1, MSP430F15x, MSP430F16x(1), MSP430F23x, MSP430F24x, MSP430F24xx, MSP430F261x, MSP430F41x, MSP430F42x(A), MSP430FE42x(A), MSP430FE42x2, and MSP430FW42x devices in 64-pin PM packages)
- MSP-FET430U64A (for MSP430F41x2 devices in 64-pin PM packages) (red PCB)
- MSP-FET430U64B (for MSP430F530x devices in 64-pin RGC packages) (blue PCB)
- MSP-FET430U64C (for MSP430F522x and MSP430F521x devices in 64-pin RGC packages) (black PCB)
- MSP-FET430U64USB (for MSP430F550x, MSP430F551x, MSP430552x, devices in 64-pin RGC packages)
- MSP-FET430U80 (for MSP430F241x, MSP430F261x, MSP430F43x, MSP430F43x1, MSP430FG43x, MSP430F47x, and MSP430FG47x devices in 80-pin PN packages)
- MSP-FET430U80A (for MSP430F532x devices in 80-pin PN packages)
- MSP-FET430U80USB (for MSP430F552x devices with USB peripheral in 80-pin PN packages)
- MSP-FET430U100 (for MSP430F43x, MSP430F43x1, MSP430F44x, MSP430FG461x, and MSP430F47xx devices in 100-pin PZ packages)
- MSP-FET430U100A (for MSP430F471xx devices in 100-pin PZ packages) (red PCB)
- MSP-FET430U100B (for MSP430F67xx devices in 100-pin PZ packages) (blue PCB)
- MSP-FET430U100C (for MSP430F643x and MSP430F533x devices in 100-pin PZ packages) (black PCB)
- MSP-FET430U5x100 (for MSP430F54xx(A) devices and MSP430BT5190 in 100-pin PZ packages) (green PCB)
- MSP-FET430U100USB (for MSP430F663x and MSP430F563x devices in 100-pin PZ packages) (green PCB)
- MSP-FET430U128 (for MSP430F67xx and MSP430F67xx1 devices in 128-pin PEU packages) (green PCB)
- FET430F5137RF900 (for CC430F513x devices in 48-pin RGZ packages) (green PCB)
- FET430F6137RF900 (for CC430F612x and CC430F613x devices in 64-pin RGC packages) (green PCB)

Stand-alone target-socket modules (without debug interface):

- MSP-TS430D8 (for MSP430G2210 and MSP430G2230 devices in 8-pin D packages) (green PCB)
- MSP-TS430PW14 (for MSP430F20xx, MSP430G2x01, MSP430G2x11, MSP430G2x21 and MSP430G2x31 devices in 14-pin PW packages) (green PCB)
- MSP-TS430L092 (for MSP430FL092 devices in 14-pin PW packages) (green PCB)
- MSP-TS430PW24 (for MSP430AFE2xx devices in 24-pin PW packages) (green PCB)
- MSP-TS430DW28 (for MSP430F11xx(A) devices in 28-pin DW packages) (green PCB)
- MSP-TS430PW28 (for MSP430F11xx(A) devices in 28-pin PW packages) (green PCB)
- MSP-TS430PW28A (for MSP430F20xx and MSP430G2xxx devices in 14, 20, and 28-pin PW) (red PCB)
- MSP-TS430DA38 (for MSP430F22x2 and MSP430F22x4 devices in 38-pin DA packages) (green PCB)
- MSP-TS430QFN23x0 / MSP-TS430QFN40 (for MSP430F23x0 devices in 40-pin RHA packages) (green PCB)
- MSP-TS430RSB40 (for MSP430F51x1, MSP430F51x2 devices in 40-pin RSB packages) (green PCB)
- MSP-TS430RHA40A (for MSP430FR572x, MSP430FR573x devices in 40-pin RHA packages) (red PCB)
- MSP-TS430DL48 (for MSP430F22x2 and MSP430F22x4 devices in 48-pin DL packages) (green PCB)
- MSP-TS430RGZ48B (for MSP430F534x devices in 48-pin RGZ packages) (blue PCB)
- MSP-TS430RGZ48C (for MSP430FR58xx and MSP430FR59xx devices in 48-pin RGZ packages) (black PCB)



- MSP-TS430PM64 (for MSP430F13x, MSP430F14x, MSP430F14x1, MSP430F15x, MSP430F16x(1), MSP430F23x, MSP430F24x, MSP430F24xx, MSP430F261x, MSP430F41x, MSP430F42x(A), MSP430FE42x(A), MSP430FE42x2, and MSP430FW42x devices in 64-pin PM packages) (green PCB)
- MSP-TS430PM64A (for MSP430F41x2 devices in 64-pin PM packages) (red PCB)
- MSP-TS430RGC64B (for MSP430F530x devices in 64-pin RGC packages) (blue PCB)
- MSP-TS430RGC64C (for MSP430F522x and MSP430F521x devices in 64-pin RGC packages) (black PCB)
- MSP-TS430RGC64USB (for MSP430F550x, MSP430F551x, MSP430F552x, devices in 64-pin RGC packages) (green PCB)
- MSP-TS430PN80 (for MSP430F241x, MSP430F261x, MSP430F43x, MSP430F43x1, MSP430FG43x, MSP430F47x, and MSP430FG47x devices in 80-pin PN packages) (green PCB)
- MSP-TS430PN80A (for MSP430F532x devices in 80-pin PN packages) (red PCB)
- MSP-TS430PN80USB (for MSP430F551x and MSP430F552x devices with USB peripheral in 80-pin PN packages) (green PCB)
- MSP-TS430PZ100 (for MSP430F43x, MSP430F43x1, MSP430F44x, MSP430FG461x, and MSP430F47xx devices in 100-pin PZ packages) (green PCB)
- MSP-TS430PZ100A (for MSP430F471xx devices in 100-pin PZ packages) (red PCB)
- MSP-FET430PZ100B (for MSP430F67xx devices in 100-pin PZ packages) (blue PCB)
- MSP-TS430PZ100C (for MSP430F643x and MSP430F533x devices in 100-pin PZ packages) (black PCB)
- MSP-TS430PZ5x100 (for MSP430F54xx(A) and the MSP430BT5190 devices in 100-pin PZ packages) (green PCB)
- MSP-TS430PZ100USB (for MSP430F663x and MSP430F563x devices in 100-pin PZ packages) (green PCB)
- MSP-TS430PEU128 (for MSP430F67xx and MSP430F67xx1 devices in 128-pin PEU packages) (green PCB)
- EM430F5137RF900 (with integrated CC430F5137 IC in a 48-pin RGZ package) (green PCB)
- EM430F6137RF900 (with integrated CC430F6137 IC in a 64-pin RGC package) (green PCB)
- EM430F6147RF900 (with integrated CC430F6147 IC in a 64-pin RGC package) (red PCB)

These tools contain the most up-to-date materials available at the time of packaging. For the latest materials (data sheets, user's guides, software, application information, etc.), visit the TI MSP430 web site at [www.ti.com/msp430](http://www.ti.com/msp430) or contact your local TI sales office.

## Information About Cautions and Warnings

This document may contain cautions and warnings.

### CAUTION

This is an example of a caution statement.

A caution statement describes a situation that could potentially damage your software or equipment.

### WARNING

This is an example of a warning statement.

A warning statement describes a situation that could potentially cause harm to you.

The information in a caution or a warning is provided for your protection. Read each caution and warning carefully.

## Related Documentation From Texas Instruments

### MSP430 development tools documentation:

*CCS for MSP430 User's Guide* (literature number [SLAU157](#))

*Code Composer Studio v5.x Core Edition* ([CCS Mediawiki](#))

*IAR for MSP430 User's Guide* (literature number [SLAU138](#))

*IAR Embedded Workbench KickStart* (literature number [SLAC050](#))

*eZ430-F2013 Development Tool User's Guide* (literature number [SLAU176](#))

*eZ430-RF2480 User's Guide* (literature number [SWRA176](#))

*eZ430-RF2500 Development Tool User's Guide* (literature number [SLAU227](#))

*eZ430-RF2500-SEH Development Tool User's Guide* (literature number [SLAU273](#))

*eZ430-Chronos Development Tool User's Guide* (literature number [SLAU292](#))

*MSP-SA430SUB1GHZ, Sub-1 GHz RF Spectrum Analyzer Tool* (literature number [SLAU371](#))

*MSP430F5529 USB Experimenter's Board, MSP-EXP430F5529* (literature number [SLAU330](#))

*MSP430F5438 Experimenter Board, MSP-EXP430F5438* (literature number [SLAU263](#))

*MSP430 LaunchPad Value Line Development kit, MSP-EXP430G2* (literature number [SLAU318](#))

### MSP430 device user's guides:

*MSP430x1xx Family User's Guide* (literature number [SLAU049](#))

*MSP430x2xx Family User's Guide* (literature number [SLAU144](#))

*MSP430x3xx Family User's Guide* (literature number [SLAU012](#))

*MSP430x4xx Family User's Guide* (literature number [SLAU056](#))

*MSP430x5xx and MSP430x6xx Family User's Guide* (literature number [SLAU208](#))

*CC430 Family User's Guide* (literature number [SLAU259](#))

*MSP430FR57xx Family User's Guide* (literature number [SLAU272](#))

*MSP430FR58xx and MSP430FR59xx Family User's Guide* (literature number [SLAU367](#))

## **If You Need Assistance**

Support for the MSP430 devices and the FET development tools is provided by the Texas Instruments Product Information Center (PIC). Contact information for the PIC can be found on the TI web site at [www.ti.com/support](http://www.ti.com/support). The Texas Instruments [E2E Community support forums](#) for the [MSP430](#) provide open interaction with peer engineers, TI engineers, and other experts. Additional device-specific information can be found on the [MSP430 web site](#).

## Get Started Now!

This chapter lists the contents of the FET and provides instruction on installing the hardware.

| Topic  | Page |
|--|------|
| 1.1 Flash Emulation Tool (FET) Overview .....  | 13   |
| 1.2 Kit Contents, MSP-FET430PIF .....  | 14   |
| 1.3 Kit Contents, eZ430-F2013 .....  | 14   |
| 1.4 Kit Contents, eZ430-T2012 .....  | 14   |
| 1.5 Kit Contents, eZ430-RF2500 .....   | 14   |
| 1.6 Kit Contents, eZ430-RF2500T .....  | 14   |
| 1.7 Kit Contents, eZ430-RF2500-SEH .....   | 14   |
| 1.8 Kit Contents, eZ430-Chronos-xxx .....  | 15   |
| 1.9 Kit Contents, MSP-FET430UIF .....  | 15   |
| 1.10 Kit Contents, MSP-FET430xx .....  | 15   |
| 1.11 Kit Contents, FET430F6137RF900 .....  | 16   |
| 1.12 Kit Contents, MSP-TS430xx .....   | 17   |
| 1.13 Kit Contents, EM430Fx1x7RF900 .....   | 19   |
| 1.14 Hardware Installation, MSP-FET430PIF .....  | 19   |
| 1.15 Hardware Installation, MSP-FET430UIF .....  | 19   |
| 1.16 Hardware Installation, eZ430-XXXX, MSP-EXP430G2, MSP-EXP430FR5739, MSP-EXP430F5529 .....    | 20   |
| 1.17 Hardware Installation, MSP-FET430Uxx, MSP-TS430xxx, FET430F6137RF900, EM430Fx137RF900 ..... | 20   |
| 1.18 Important MSP430 Documents on the Web .....   | 20   |

## 1.1 Flash Emulation Tool (FET) Overview

TI offers several flash emulation tools according to different requirements.

**Table 1-1. Flash Emulation Tool (FET) Features and Device Compatibility<sup>(1)</sup>**

|  | eZ430-F2013 | eZ430-RF2500 | eZ430-RF2480 | eZ430-RF2560 | MSP-WDSxx Metawatch | eZ430-Chronos | MSP-FET430PIF | MSP-FET430UIF | LaunchPad (MSP-EXP430G2) | MSP-EXP430FR5739 | MSP-EXP430F5529 |
|--|-------------|--------------|--------------|--------------|---------------------|---------------|---------------|---------------|--------------------------|------------------|-----------------|
| Supports all MSP430 and CC430 flash-based devices (F1xx, F2xx, F4xx, F5xx, F6xx, G2xx, L092, FR57xx) |             |              |              |              |                     |               | x             | x             |                          |                  |                 |
| Supports only F20xx, G2x01, G2x11, G2x21, G2x31  | x           |              |              |              |                     |               |               |               |                          |                  |                 |
| Supports MSP430F20xx, F21x2, F22xx, G2x01, G2x11, G2x21, G2x31, G2x53                                |             |              |              |              |                     |               |               |               | x                        |                  |                 |
| Supports MSP430F20xx, F21x2, F22xx, G2x01, G2x11, G2x21, G2x31                                       |             | x            | x            |              |                     |               |               |               |                          |                  |                 |
| Supports F5438, F5438A   |             |              |              | x            |                     |               |               |               |                          |                  |                 |
| Supports BT5190, F5438A  |             |              |              |              | x                   |               |               |               |                          |                  |                 |
| Supports only F552x  |             |              |              |              |                     |               |               |               |                          |                  | x               |
| Supports FR57xx, F5638, F6638  |             |              |              |              |                     |               |               |               |                          | x                |                 |
| Supports only CC430F613x   |             |              |              |              |                     | x             |               |               |                          |                  |                 |
| Allows fuse blow   |             |              |              |              |                     |               |               | x             |                          |                  |                 |
| Adjustable target supply voltage   |             |              |              |              |                     |               |               | x             |                          |                  |                 |
| Fixed 2.8-V target supply voltage  |             |              |              |              |                     |               | x             |               |                          |                  |                 |
| Fixed 3.6-V target supply voltage  | x           | x            | x            | x            | x                   | x             |               |               | x                        | x                | x               |
| 4-wire JTAG  |             |              |              |              |                     |               | x             | x             |                          |                  |                 |
| 2-wire JTAG <sup>(2)</sup>   | x           | x            | x            | x            | x                   | x             |               | x             | x                        | x                | x               |
| Application UART   |             | x            | x            | x            | x                   | x             |               |               | x                        | x                | x               |
| Supported by CCS for Windows   | x           | x            | x            | x            | x                   | x             | x             | x             | x                        | x                | x               |
| Supported by CCS for Linux   |             |              |              |              |                     |               |               | x             |                          |                  |                 |
| Supported by IAR   | x           | x            | x            | x            | x                   | x             | x             | x             | x                        | x                | x               |

<sup>(1)</sup> The MSP-FET430PIF is for legacy device support only. This emulation tool will not support any new devices released after 2011.

<sup>(2)</sup> The 2-wire JTAG debug interface is also referred to as Spy-Bi-Wire (SBW) interface.

**1.2 Kit Contents, MSP-FET430PIF**

- One READ ME FIRST document
- One MSP-FET430PIF interface module
- One 25-conductor cable
- One 14-conductor cable

NOTE: This part is obsolete and is not recommended to use in new design.

**1.3 Kit Contents, eZ430-F2013**

- One QUICK START GUIDE document
- One eZ430-F2013 development tool including one MSP430F2013 target board

**1.4 Kit Contents, eZ430-T2012**

- Three MSP430F2012-based target boards

**1.5 Kit Contents, eZ430-RF2500**

- One QUICK START GUIDE document
- One eZ430-RF2500 CD-ROM
- One eZ430-RF2500 development tool including one MSP430F2274 and CC2500 target board
- One eZ430-RF2500T target board
- One AAA battery pack with expansion board (batteries included)

**1.6 Kit Contents, eZ430-RF2500T**

- One eZ430-RF2500T target board
- One AAA battery pack with expansion board (batteries included)

**1.7 Kit Contents, eZ430-RF2500-SEH**

- One MSP430 development tool CD containing documentation and development software
- One eZ430-RF USB debugging interface
- Two eZ430-RF2500T wireless target boards
- One SEH-01 solar energy harvester board
- One AAA battery pack with expansion board (batteries included)

## 1.8 Kit Contents, eZ430-Chronos-xxx

### '433, '868, '915

- One QUICK START GUIDE document
- One ez430-Chronos emulator
- One screwdriver
- Two spare screws

#### **eZ430-Chronos-433:**

- One 433-MHz eZ430-Chronos watch (battery included)
- One 433-MHz eZ430-Chronos access point

#### **eZ430-Chronos-868:**

- One 868-MHz eZ430-Chronos watch (battery included)
- One 868-MHz eZ430-Chronos access point

#### **eZ430-Chronos-915:**

- One 915-MHz eZ430-Chronos watch (battery included)
- One 915-MHz eZ430-Chronos access point

## 1.9 Kit Contents, MSP-FET430UIF

- One READ ME FIRST document
- One MSP-FET430UIF interface module
- One USB cable
- One 14-conductor cable

## 1.10 Kit Contents, MSP-FET430xx

### 'U8, 'U14, 'U092, 'U24, 'U28, 'U28A, 'U38, 'U23x0, 'U40, 'U40A, 'U48, 'U48B, 'U64, 'U64A, 'U64B, 'U64C, 'U64USB, 'U80, 'U80USB, 'U100, 'U100A, 'U100B, 'U100C, 'U5x100, 'U100USB, 'U128

- One READ ME FIRST document
- One MSP-FET430UIF USB interface module. This is the unit that has a USB B-connector on one end of the case, and a 2x7-pin male connector on the other end of the case.
- One USB cable
- One 32.768-kHz crystal from Micro Crystal (except MSP-FET430U24)
- A 2x7-pin male JTAG connector is also present on the PCB (see different setup for L092)
- One 14-Pin JTAG conductor cable
- One small box containing two MSP430 device samples (See table for Sample Type)
- One target socket module. To check the devices used for each board and a summary of the board, see [Table 1-2](#). MSP-TS430xx below is the target socket module for each MSP-FET430Uxx kit.

**MSP-FET430U8:** One **MSP-TS430D8** target socket module.

**MSP-FET430U14:** One **MSP-TS430PW14** target socket module.

**MSP-FET430U092:** One **MSP-TS430L092** target socket module with Active Cable.

**MSP-FET430U24:** One **MSP-TS430PW24** target socket module.

**MSP-FET430U28:** One **MSP-TS430PW28** target socket module.

**MSP-FET430U28A:** One **MSP-TS430PW28A** target socket module.

**MSP-FET430U38:** One **MSP-TS430DA38** target socket module..

**MSP-FET430U23x0:** One **MSP-TS430QFN23x0** (former name MSP-TS430QFN40) target socket module.

**MSP-FET430U40:** One **MSP-TS430RSB40** target socket module.

**MSP-FET430U48:** One **MSP-TS430DL48** target socket module.

**MSP-FET430U48B:** One **MSP-TS430RGZ48B** target socket module.  
**MSP-FET430U48C:** One **MSP-TS430RGZ48C** target socket module.  
**MSP-FET430U64:** One **MSP-TS430PM64** target socket module.  
**MSP-FET430U64A:** One **MSP-TS430PM64A** target socket module.  
**MSP-FET430U64B:** One **MSP-TS430RGC64B** target socket module.  
**MSP-FET430U64C:** One **MSP-TS430RGC64C** target socket module.  
**MSP-FET430U64USB:** One **MSP-TS430RGC64USB** target socket module.  
**MSP-FET430U80:** One **MSP-TS430PN80** target socket module.  
**MSP-FET430U80A:** One **MSP-TS430PN80A** target socket module.  
**MSP-FET430U80USB:** One **MSP-TS430PN80USB** target socket module.  
**MSP-FET430U100:** One **MSP-TS430PZ100** target socket module.  
**MSP-FET430U100A:** One **MSP-TS430PZ100A** target socket module.  
**MSP-FET430U100B:** One **MSP-TS430PZ100B** target socket module.  
**MSP-FET430U100C:** One **MSP-TS430PZ100C** target socket module.  
**MSP-FET430U5x100:** One **MSP-TS430PZ5x100** target socket module.  
**MSP-FET430U100USB:** One **MSP-TS430PZ100USB** target socket module.  
**MSP-FET430U128:** One **MSP-TS430PEU128** target socket module.

Consult the device data sheets for device specifications. Device errata can be found in the respective device product folder on the web provided as a PDF document. Depending on the device, errata may also be found in the device bug database at [www.ti.com/sc/cgi-bin/buglist.cgi](http://www.ti.com/sc/cgi-bin/buglist.cgi).

### 1.11 Kit Contents, FET430F6137RF900

- One READ ME FIRST document
- One legal notice
- One MSP-FET430UIF interface module
- Two EM430F6137RF900 target socket modules. This is the PCB on which is soldered a CC430F6137 device in a 64-pin RGC package. A 2x7-pin male connector is also present on the PCB
- Two CC430EM battery packs
- Four AAA batteries
- Two 868-MHz or 915-MHz antennas
- Two 32.768-kHz crystals
- 18 PCB 2x4-pin headers
- One USB cable
- One 14-pin JTAG conductor cable



## 1.12 Kit Contents, MSP-TS430xx

- One READ ME FIRST document
- One 32.768-kHz crystal from Micro Crystal (except MSP-TS430PW24)
- One target socket module
- A 2x7-pin male JTAG connector is also present on the PCB (see different setup for L092)
- One small box containing two MSP430 device samples (see [Table 1-2](#) for sample type)

**Table 1-2. Individual Kit Contents, MSP-TS430xx**

| Part Number      | Socket Type              | Supported Devices  | Included Devices   | Headers and Comment  |
|------------------|--------------------------|--|--|--|
| MSP-TS430D8      | 8-pin D<br>(TSSOP ZIF)   | MSP430G2210,<br>MSP430G2230  | 1 x MSP430G2210 and<br>1 x MSP430G2230                         | Two PCB 1x4-pin headers (two male and two female)  |
| MSP-TS430PW14    | 14-pin PW<br>(TSSOP ZIF) | MSP430F20xx,<br>MSP430G2x01,<br>MSP430G2x11,<br>MSP430G2x21,<br>MSP430G2x31  | 2 x MSP430F2013IPW   | Four PCB 1x7-pin headers (two male and two female)   |
| MSP-TS430L092    | 14-pin PW<br>(TSSOP ZIF) | MSP-TS430L092  | 2 x MSP430L092IPW  | Four PCB 1x7-pin headers (two male and two female). A "Micro-MaTch" 10-pin female connector is also present on the PCB which connects the kit with an 'Active Cable' PCB; this 'Active Cable' PCB is connected by 14-pin JTAG cable with the FET430UIF |
| MSP-TS430PW24    | 24-pin PW<br>(TSSOP ZIF) | MSP430AFE2xx   | 2 x MSP430AFE253IPW  | Four PCB 1x12-pin headers (two male and two female)  |
| MSP-TS430DW28    | 28-pin DW<br>(SSOP ZIF)  | MSP430F11x1,<br>MSP430F11x2,<br>MSP430F12x,<br>MSP430F12x2,<br>MSP430F21xx<br>Supports devices in 20- and 28-pin DA packages | 2 x MSP430F123IDW  | Four PCB 1x12-pin headers (two male and two female)  |
| MSP-TS430PW28    | 28-pin PW<br>(TSSOP ZIF) | MSP430F11x1,<br>MSP430F11x2,<br>MSP430F12x,<br>MSP430F12x2,<br>MSP430F21xx   | 2 x MSP430F2132IPW   | Four PCB 1x12-pin headers (two male and two female)  |
| MSP-TS430PW28A   | 28-pin PW<br>(TSSOP ZIF) | MSP430F20xx,<br>MSP430G2xxx in 14-, 20-, and 28-pin PW packages  | 2 x MSP430G2452IPW20   | Four PCB 1x12-pin headers (two male and two female)  |
| MSP-TS430DA38    | 38-pin DA<br>(TSSOP ZIF) | MSP430F22xx,<br>MSP430G2x44,<br>MSP430G2x55  | 2 x MSP430F2274IDA<br>2 x MSP430G2744IDA<br>2 x MSP430G2955IDA | Four PCB 1x19-pin headers (two male and two female)  |
| MSP-TS430QFN23x0 | 40-pin RHA<br>(QFN ZIF)  | MSP430F23x0  | 2 x MSP430F2370IRHA  | Eight PCB 1x10-pin headers (four male and four female)   |
| MSP-TS430RSB40   | 40-pin RSB<br>(QFN ZIF)  | MSP430F51x1,<br>MSP430F51x2  | 2 x MSP430F5172IRSB  | Eight PCB 1x10-pin headers (four male and four female)   |
| MSP-TS430RHA40A  | 40-pin RHA<br>(QFN ZIF)  | MSP430FR572x,<br>MSP430FR573x  | 2 x MSP430FR5739IRHA   | Eight PCB 1x10-pin headers (four male and four female)   |
| MSP-TS430DL48    | 48-pin DL<br>(TSSOP ZIF) | MSP430F42x0  | 2 x MSP430F4270IDL   | Four PCB 2x12-pin headers (two male and two female)  |
| MSP-TS430RGZ48B  | 48-pin RGZ<br>(QFN ZIF)  | MSP430F534x  | 2 x MSP430F5342IRGZ  | Eight PCB 1x12-pin headers (four male and four female)   |
| MSP-TS430RGZ48C  | 48-pin RGZ<br>(QFN ZIF)  | MSP430FR58xx and<br>MSP430FR59xx   | 2 x MSP430FR5969IRGZ   | Eight PCB 1x12-pin headers (four male and four female)   |

**Table 1-2. Individual Kit Contents, MSP-TS430xx (continued)**

| Part Number       | Socket Type           | Supported Devices   | Included Devices   | Headers and Comment   |
|-------------------|-----------------------|---|--|---|
| MSP-TS430PM64     | 64-pin PM (QFP ZIF)   | MSP430F13x,<br>MSP430F14x,<br>MSP430F14x1,<br>MSP430F15x,<br>MSP430F16x(1),<br>MSP430F23x,<br>MSP430F24x,<br>MSP430F24xx,<br>MSP430F261x,<br>MSP430F41x,<br>MSP430F42x(A),<br>MSP430FE42x(A),<br>MSP430FE42x2,<br>MSP430FW42x | TS Kit:<br>2 x MSP430F2618IPM;<br>FET Kit:<br>2 x MSP430F4171IPM and<br>2 x MSP430F1691IPM | Eight PCB 1x16-pin headers (four male and four female)  |
| MSP-TS430PM64A    | 64-pin PM (QFP ZIF)   | MSP430F41x2   | 2 x MSP430F4152IPM   | Eight PCB 1x16-pin headers (four male and four female)  |
| MSP-TS430RGC64B   | 64-pin RGC (QFN ZIF)  | MSP430F530x   | 2 x MSP430F5310IRGC  | Eight PCB 1x16-pin headers (four male and four female)  |
| MSP-TS430RGC64C   | 64-pin RGC (QFN ZIF)  | MSP430F522x,<br>MSP430F521x   | 2 x MSP430F5229IRGC  | Eight PCB 1x16-pin headers (four male and four female)  |
| MSP-TS430RGC64USB | 64-pin RGC (QFN ZIF)  | MSP430F550x,<br>MSP430F551x,<br>MSP430F552x   | 2 x MSP430F5510IRGC or<br>2 x MSP430F5528IRGC  | Eight PCB 1x16-pin headers (four male and four female)  |
| MSP-TS430PN80     | 80-pin PN (QFP ZIF)   | MSP430F241x,<br>MSP430F261x,<br>MSP430F43x,<br>MSP430F43x1,<br>MSP430FG43x,<br>MSP430F47x,<br>MSP430FG47x   | 2 x MSP430FG439IPN   | Eight PCB 1x20-pin headers (four male and four female)  |
| MSP-TS430PN80A    | 80-pin PN (QFP ZIF)   | MSP430F532x   | 2 x MSP430F5329IPN   | Eight PCB 1x20-pin headers (four male and four female)  |
| MSP-TS430PN80USB  | 80-pin PN (QFP ZIF)   | MSP430F552x,<br>MSP430F551x   | 2 x MSP430F5529IPN   | Eight PCB 1x20-pin headers (four male and four female)  |
| MSP-TS430PZ100    | 100-pin PZ (QFP ZIF)  | MSP430F43x,<br>MSP430F43x1,<br>MSP430F44x, MSP430<br>MSP430FG461x, MSP430<br>F47xx  | 2 x MSP430FG4619IPZ  | Eight PCB 1x25-pin headers (four male and four female)  |
| MSP-TS430PZ100A   | 100-pin PZ (QFP ZIF)  | MSP430F471xx  | 2 x MSP430F47197IPZ  | Eight PCB 1x25-pin headers (four male and four female)  |
| MSP-TS430PZ100B   | 100-pin PZ (QFP ZIF)  | MSP430F67xx   | 2 x MSP430F6733IPZ   | Eight PCB 1x25-pin headers (four male and four female)  |
| MSP-TS430PZ100C   | 100-pin PZ (QFP ZIF)  | MSP430F645x,<br>MSP430F643x,<br>MSP430F535x,<br>MSP430F533x   | 2 x MSP430F6438IPZ   | Eight PCB 1x25-pin headers (four male and four female)  |
| MSP-TS430PZ5x100  | 100-pin PZ (QFP ZIF)  | MSP430F543x,<br>MSP430BT5190,<br>MSP430SL5438A  | 2 x MSP430F5438IPZ   | Eight PCB 1x25-pin headers (four male and four female)  |
| MSP-TS430PZ100USB | 100-pin PZ (QFP ZIF)  | MSP430F665x,<br>MSP430F663x,<br>MSP430F563x   | 2 x MSP430F6638IPZ   | Eight PCB 1x25-pin headers (four male and four female)  |
| MSP-TS430PEU128   | 128-pin PEU (QFP ZIF) | MSP430F677x,<br>MSP430F676x,<br>MSP430F674x,<br>MSP430F677x1,<br>MSP430F676x1,<br>MSP430F674x1  | 2 x MSP430F67791IPEU   | Four PCB 1x26-pin headers (two male and two female) and four PCB 1x38-pin headers (two male and two female) |

See the device data sheets for device specifications. Device errata can be found in the respective device product folder on the web provided as a PDF document. Depending on the device, errata may also be found in the device bug database at [www.ti.com/sc/cgi-bin/buglist.cgi](http://www.ti.com/sc/cgi-bin/buglist.cgi).

### 1.13 Kit Contents, EM430Fx1x7RF900

- One READ ME FIRST document
- One legal notice
- Two target socket module

**MSP-EM430F5137RF900:** Two EM430F5137RF900 target socket modules. This is the PCB on which is soldered a CC430F5137 device in a 48-pin RGZ package. A 2x7-pin male connector is also present on the PCB

**MSP-EM430F6137RF900:** Two EM430F6137RF900 target socket modules. This is the PCB on which is soldered a CC430F6137 device in a 64-pin RGC package. A 2x7-pin male connector is also present on the PCB

**MSP-EM430F6147RF900:** Two EM430F6147RF900 target socket modules. This is the PCB on which is soldered a CC430F6147 device in a 64-pin RGC package. A 2x7-pin male connector is also present on the PCB

- Two CC430EM battery packs
- Four AAA batteries
- Two 868- or 915-MHz antennas
- Two 32.768-kHz crystals
- 18 PCB 2x4-pin headers

### 1.14 Hardware Installation, MSP-FET430PIF

Follow these steps to install the hardware for the MSP-FET430PIF tools:

1. Use the 25-conductor cable to connect the FET interface module to the parallel port of the PC. The necessary driver for accessing the PC parallel port is installed automatically during CCS or IAR Embedded Workbench installation. Note that a restart is required after the CCS or IAR Embedded Workbench installation for the driver to become active.
2. Use the 14-conductor cable to connect the parallel-port debug interface module to a target board, such as an MSP-TS430xxx target socket module. Module schematics and PCBs are shown in [Appendix B](#).

### 1.15 Hardware Installation, MSP-FET430UIF

Follow these steps to install the hardware for the MSP-FET430UIF tool:

1. Install the IDE (CCS or IAR) you plan to use before connecting USB-FET interface to PC. The IDE installation installs drivers automatically.
2. Use the USB cable to connect the USB-FET interface module to a USB port on the PC. The USB FET should be recognized, as the USB device driver is installed automatically. If the driver has not been installed yet, the install wizard starts. Follow the prompts and point the wizard to the driver files.

The default location for CCS is c:\ti\ccsv5\ccs\_base\emulation\drivers\msp430\USB\_CDC or c:\ti\ccsv5\ccs\_base\emulation\drivers\msp430\USB\_FET\_XP\_XX, depending of firmware version of the tool.

The default location for IAR Embedded Workbench is <Installation Root>\Embedded Workbench x.x\430\drivers\TIUSBFET\ez430-UART or <Installation Root>\Embedded Workbench x.x\430\drivers\<Win\_OS>, depending of firmware version of the tool.

The USB driver is installed automatically. Detailed driver installation instructions can be found in [Appendix C](#).

3. After connecting to a PC, the USB FET performs a self-test during which the red LED may flash for approximately two seconds. If the self-test passes successfully, the green LED stays on.
4. Use the 14-conductor cable to connect the USB-FET interface module to a target board, such as an MSP-TS430xxx target socket module.
5. Ensure that the MSP430 device is securely seated in the socket, and that its pin 1 (indicated with a circular indentation on the top surface) aligns with the "1" mark on the PCB.
6. Compared to the parallel-port debug interface, the USB FET has additional features including JTAG security fuse blow and adjustable target  $V_{CC}$  (1.8 V to 3.6 V). Supply the module with up to 60 mA.

### 1.16 Hardware Installation, eZ430-XXXX, MSP-EXP430G2, MSP-EXP430FR5739, MSP-EXP430F5529

To install eZ430-XXXX, MSP-EXP430G2, MSP-EXP430FR5739, MSP-EXP430F5529 tools follow instructions 1 and 2 of [Section 1.15](#)

### 1.17 Hardware Installation, MSP-FET430Uxx, MSP-TS430xxx, FET430F6137RF900, EM430Fx137RF900

Follow these steps to install the hardware for the MSP-FET430Uxx and MSP-TS430xxx tools:

1. Follow instructions 1 and 2 of [Section 1.15](#)
2. Connect the MSP-FET430PIF or MSP-FET430UIF debug interface to the appropriate port of the PC. Use the 14-conductor cable to connect the FET interface module to the supplied target socket module.
3. Ensure that the MSP430 device is securely seated in the socket and that its pin 1 (indicated with a circular indentation on the top surface) aligns with the "1" mark on the PCB.
4. Ensure that the two jumpers (LED and VCC) near the 2x7-pin male connector are in place. Illustrations of the target socket modules and their parts are found in [Appendix B](#).

### 1.18 Important MSP430 Documents on the Web

The primary sources of MSP430 information are the device-specific data sheet and user's guide. The MSP430 web site ([www.ti.com/msp430](http://www.ti.com/msp430)) contains the most recent version of these documents.

PDF documents describing the CCS tools (CCS IDE, the assembler, the C compiler, the linker, and the librarian) are in the msp430\documentation folder. A Code Composer Studio specific [Wiki page \(FAQ\)](#) is available, and the Texas Instruments [E2E Community support forums](#) for the MSP430 and Code Composer Studio v5 provide additional help besides the product help and Welcome page.

PDF documents describing the IAR tools (Workbench C-SPY, the assembler, the C compiler, the linker, and the librarian) are in the common\doc and 430\doc folders. Supplements to the documents (that is, the latest information) are available in HTML format in the same directories. A IAR specific [Wiki Page](#) is also available.

## ***Design Considerations for In-Circuit Programming***

---

---

This chapter presents signal requirements for in-circuit programming of the MSP430.

| <b>Topic</b>  | <b>Page</b> |
|---|-------------|
| <b>2.1 Signal Connections for In-System Programming and Debugging .....</b> | <b>22</b>   |
| <b>2.2 External Power .....</b>   | <b>26</b>   |
| <b>2.3 Bootstrap Loader (BSL) .....</b>                                     | <b>26</b>   |

## 2.1 Signal Connections for In-System Programming and Debugging

### MSP-FET430PIF, MSP-FET430UIF, MSP-GANG, MSP-GANG430, MSP-PRGS430


With the proper connections, the debugger and an FET hardware JTAG interface (such as the MSP-FET430PIF and MSP-FET430UIF) can be used to program and debug code on the target board. In addition, the connections also support the MSP-GANG430 or MSP-PRGS430 production programmers, thus providing an easy way to program prototype boards, if desired.

[Figure 2-1](#) shows the connections between the 14-pin FET interface module connector and the target device required to support in-system programming and debugging for 4-wire JTAG communication.

[Figure 2-2](#) shows the connections for 2-wire JTAG mode (Spy-Bi-Wire). The 4-wire JTAG mode is supported on most MSP430 devices except of small pin count devices e.g. MSP430G2230. The 2-wire JTAG mode is available on selected devices only. See the *CCS User's Guide for MSP430* ([SLAU157](#)) or *IAR for MSP430 User's Guide* ([SLAU138](#)) for information on which interface method can be used on which device.


The connections for the FET interface module and the MSP-GANG, MSP-GANG430 or MSP-PRGS430 are identical. Both the FET interface module and MSP-GANG430 can supply  $V_{CC}$  to the target board (via pin 2). In addition, the FET interface module, MSP-GANG and MSP-GANG430 have a  $V_{CC}$ -sense feature that, if used, requires an alternate connection (pin 4 instead of pin 2). The  $V_{CC}$ -sense feature senses the local  $V_{CC}$  present on the target board (that is, a battery or other local power supply) and adjusts the output signals accordingly. If the target board is to be powered by a local  $V_{CC}$ , then the connection to pin 4 on the JTAG should be made, and not the connection to pin 2. This utilizes the  $V_{CC}$ -sense feature and prevents any contention that might occur if the local on-board  $V_{CC}$  were connected to the  $V_{CC}$  supplied from the FET interface module, MSP-GANG or the MSP-GANG430. If the  $V_{CC}$ -sense feature is not necessary (that is, if the target board is to be powered from the FET interface module, MSP-GANG or MSP-GANG430), the  $V_{CC}$  connection is made to pin 2 on the JTAG header and no connection is made to pin 4. [Figure 2-1](#) and [Figure 2-2](#) show a jumper block that supports both scenarios of supplying  $V_{CC}$  to the target board. If this flexibility is not required, the desired  $V_{CC}$  connections may be hard-wired eliminating the jumper block. Pins 2 and 4 must not be connected simultaneously.

Note that in 4-wire JTAG communication mode (see [Figure 2-1](#)), the connection of the target RST signal to the JTAG connector is optional when using devices that support only 4-wire JTAG communication mode. However, when using devices that support 2-wire JTAG communication mode in 4-wire JTAG mode, the RST connection must be made. The MSP430 development tools and device programmers perform a target reset by issuing a JTAG command to gain control over the device. However, if this is unsuccessful, the RST signal of the JTAG connector may be used by the development tool or device programmer as an additional way to assert a device reset.



- A If a local target power supply is used, make connection J1. If power from the debug or programming adapter is used, make connection J2.
- B The configuration of R1 and C1 for the  $\overline{\text{RST}}/\text{NMI}$  pin depends on the device family. See the respective MSP430 family user's guide for the recommended configuration.
- C The TEST pin is available only on MSP430 family members with multiplexed JTAG pins. See the device-specific data sheet to determine if this pin is available.
- D The connection to the JTAG connector  $\overline{\text{RST}}$  pin is optional when using 4-wire JTAG communication mode capable-only devices and not required for device programming or debugging. However, this connection is required when using 2-wire JTAG communication mode capable devices in 4-wire JTAG mode.
- E When using 2-wire JTAG communication capable devices in 4-wire JTAG mode, the upper limit for C1 should not exceed 2.2 nF. This applies to both TI FET interface modules (LPT and USB FET).


**Figure 2-1. Signal Connections for 4-Wire JTAG Communication**



- A If a local target power supply is used, make connection J1. If power from the debug or programming adapter is used, make connection J2.
- B The device  $\overline{\text{RST/NMI/SBWTIO}}$  pin is used in 2-wire mode for bidirectional communication with the device during JTAG access, and any capacitance that is attached to this signal may affect the ability to establish a connection with the device. The upper limit for C1 is 2.2 nF when using current TI tools.
- C R2 protects the JTAG debug interface TCK signal from the JTAG security fuse blow voltage that is supplied by the TEST/VPP pin during the fuse blow process. If fuse blow functionality is not needed, R2 is not required (populate 0  $\Omega$ ) and do not connect TEST/VPP to TEST/SBWTCK.

**Figure 2-2. Signal Connections for 2-Wire JTAG Communication (Spy-Bi-Wire) Used by MSP430F2xx, MSP430G2xx and MSP430F4xx Devices**





- A Make connection J1 if a local target power supply is used, or make connection J2 if the target is powered from the debug or programming adapter.
- B The device  $\overline{RST}/NMI/SBWDIO$  pin is used in 2-wire mode for bidirectional communication with the device during JTAG access, and any capacitance that is attached to this signal may affect the ability to establish a connection with the device. The upper limit for C1 is 2.2 nF when using current TI tools.

**Figure 2-3. Signal Connections for 2-Wire JTAG Communication (Spy-Bi-Wire) Used by MSP430F5xx and MSP430F6xx Devices**

## 2.2 External Power

The MSP-FET430UIF can supply targets with up to 60 mA through pin 2 of the 14-pin connector. Please note that the target should not consume more than 60 mA, even as a peak current, as it may violate the USB specification. E.g., if the target board has a capacitor on VCC more than 10  $\mu$ F, it may cause inrush current during capacitor charging that may exceed 60 mA. In this case the current should be limited by the design of the target board, or an external power supply should be used.

The  $V_{CC}$  for the target can be selected between 1.8 V and 3.6 V in steps of 0.1 V. Alternatively, the target can be supplied externally. In this case, the external voltage should be connected to pin 4 of the 14-pin connector. The MSP-FET430UIF then adjusts the level of the JTAG signals to external  $V_{CC}$  automatically. Only pin 2 (MSP-FET430UIF supplies target) or pin 4 (target is externally supplied) must be connected; not both at the same time.

When a target socket module is powered from an external supply, the external supply powers the device on the target socket module and any user circuitry connected to the target socket module, and the FET interface module continues to be powered from the PC via the parallel port. If the externally supplied voltage differs from that of the FET interface module, the target socket module must be modified so that the externally supplied voltage is routed to the FET interface module (so that it may adjust its output voltage levels accordingly). See the target socket module schematics in [Appendix B](#).

The PC parallel port can source a limited amount of current. Because of the ultralow-power requirement of the MSP430, a standalone FET does not exceed the available current. However, if additional circuitry is added to the tool, this current limit could be exceeded. In this case, external power can be supplied to the tool via connections provided on the target socket modules. See the schematics and pictorials of the target socket modules in [Appendix B](#) to locate the external power connectors. Note that the MSP-FET430PIF is not recommended for new design.

## 2.3 Bootstrap Loader (BSL)

The JTAG pins provide access to the flash memory of the MSP430Fxxx devices. On some devices, these pins are shared with the device port pins, and this sharing of pins can complicate a design (or sharing may not be possible). As an alternative to using the JTAG pins, most MSP430Fxxx devices contain a program (a "bootstrap loader") that permits the flash memory to be erased and programmed using a reduced set of signals. The *MSP430 Programming Via the Bootstrap Loader User's Guide* ([SLAU319](#)) describes this interface. See the [MSP430 web site](#) for the application reports and a list of MSP430 BSL tool developers.

TI suggests that MSP430Fxxx customers design their circuits with the BSL in mind (that is, TI suggests providing access to these signals by, for example, a header).

See FAQ [Hardware #10](#) for a second alternative to sharing the JTAG and port pins.

## ***Frequently Asked Questions and Known Issues***

---

---

This appendix presents solutions to frequently asked questions regarding the MSP-FET430 hardware.

| <b>Topic</b>                   | <b>Page</b> |
|--------------------------------|-------------|
| <b>A.1 Hardware FAQs .....</b> | <b>28</b>   |
| <b>A.2 Known Issues .....</b>  | <b>30</b>   |

## A.1 Hardware FAQs

### 1. MSP430F22xx Target Socket Module (MSP-TS430DA38) – Important Information

Due to the large capacitive coupling introduced by the device socket between the adjacent signals XIN/P2.6 (socket pin 6) and  $\overline{\text{RST}}$ /SBWTDIO (socket pin 7), in-system debugging can disturb the LFXT1 low-frequency crystal oscillator operation (ACLK). This behavior applies only to the Spy-Bi-Wire (2-wire) JTAG configuration and only to the period while a debug session is active.

Workarounds:

- Use the 4-wire JTAG mode debug configuration instead of the Spy-Bi-Wire (2-wire) JTAG configuration. This can be achieved by placing jumpers JP4 through JP9 accordingly.
- Use the debugger option "Run Free" that can be selected from the Advanced Run drop-down menu (at top of Debug View). This prevents the debugger from accessing the MSP430 while the application is running. Note that, in this mode, a manual halt is required to see if a breakpoint was hit. See the IDE documentation for more information on this feature.
- Use an external clock source to drive XIN directly.

### 2. With current interface hardware and software, there is a weakness when adapting target boards that are powered externally. This leads to an accidental fuse check in the MSP430. This is valid for PIF and UIF but is mainly seen on UIF. A solution is being developed.

Workarounds:

- Connect  $\overline{\text{RST}}$ /NMI pin to JTAG header (pin 11), LPT and USB tools are able to pull the RST line, which also resets the device internal fuse logic.
- Use the debugger option "Release JTAG On Go" that can be selected from the IDE drop-down menu. This prevents the debugger from accessing the MSP430 while the application is running. Note that in this mode, a manual halt is required to see if a breakpoint was hit. See the IDE documentation for more information on this feature.
- Use an external clock source to drive XIN directly.

### 3. The 14-conductor **cable** connecting the FET interface module and the target socket module **must not exceed 8 inches (20 centimeters) in length.**

### 4. The signal assignment on the **14-conductor cable** is **identical** for the **parallel port interface** and the **USB FET.**

### 5. **To utilize the on-chip ADC voltage references, the capacitor must be installed** on the target socket module. See schematic of the target socket module to populate the capacitor according to the data sheet of the device.

### 6. **To utilize the charge pump on the devices with LCD+ Module, the capacitor must be installed** on the target socket module. See schematic of the target socket module to populate the capacitor according to the data sheet of the device.

### 7. **Crystals or resonators Q1 and Q2 (if applicable) are not provided on the target socket module.** For MSP430 devices that contain user-selectable loading capacitors, see device and crystal data sheets for the value of capacitance.

### 8. **Crystals or resonators have no effect upon the operation of the tool and the CCS debugger or C-SPY** (as any required clocking and timing is derived from the internal DCO and FLL).

### 9. **On devices with multiplexed port or JTAG pins**, to use these pin in their port capability: For CCS: "Run Free" (in Run pulldown menu at top of Debug View) must be selected. For C-SPY: "Release JTAG On Go" must be selected.

### 10. **As an alternative to sharing the JTAG and port pins** (on low pin count devices), **consider using an MSP430 device that is a "superset" of the smaller device.** A very powerful feature of the MSP430 is that the family members are code and architecturally compatible, so code developed on one device (for example, one without shared JTAG and port pins) ports effortlessly to another (assuming an equivalent set of peripherals).

11. **Information memory may not be blank** (erased to 0xFF) when the device is delivered from TI. Customers should erase the information memory before its first use. Main memory of packaged devices is blank when the device is delivered from TI.
12. **The device current is higher than expected.** The device current measurement may not be accurate with the debugger connected to the device. For accurate measurement, disconnect the debugger.
13. The following **ZIF sockets** are used in the FET tools and target socket modules:
  - 8-pin device (D package): Yamaichi IC369-0082
  - 14-pin device (PW package): Enplas OTS-14-065-01
  - 14-pin package for 'L092 (PW package): Yamaichi IC189-0142-146
  - 24-pin package (PW package): Enplas OTS-24(28)-0.65-02
  - 28-pin device (DW package): Wells-CTI 652 D028
  - 28-pin device (PW package): Enplas OTS-28-0.65-01
  - 38-pin device (DA package): Yamaichi IC189-0382-037
  - 40-pin device (RHA package): Enplas QFN-40B-0.5-01
  - 40-pin device (RSB package): Enplas QFN-40B-0.4
  - 48-pin device (RGZ package): Yamaichi QFN11T048-008 A101121-001
  - 48-pin device (DL package): Yamaichi IC51-0482-1163
  - 64-pin device (PM package): Yamaichi IC51-0644-807
  - 64-pin device (RGC package): Yamaichi QFN11T064-006
  - 80-pin device (PN package): Yamaichi IC201-0804-014
  - 100-pin device (PZ package): Yamaichi IC201-1004-008
  - 128-pin device (PEU package): Yamaichi IC500-1284-009P

Enplas: [www.enplas.com](http://www.enplas.com)

Wells-CTI: [www.wellscti.com](http://www.wellscti.com)

Yamaichi: [www.yamaichi.us](http://www.yamaichi.us)

## A.2 Known Issues

### MSP-FET430UIF *Current detection algorithm of the UIF firmware*

---

**Problem Description** If high current is detected, the  $I_{CC}$  monitor algorithm stays in a loop of frequently switching on and off the target power supply. This power switching puts some MSP430 devices such as the MSP430F5438 in a state that requires a power cycle to return the device to JTAG control.

A side issue is that if the UIF firmware has entered this switch on and switch off loop, it is not possible to turn off the power supply to the target by calling MSP430\_VCC(0). A power cycle is required to remove the device from this state.

**Solution** IAR KickStart and Code Composer Essentials that have the MSP430.dll version 2.04.00.003 and higher do not show this problem. Update the software development tool to this version or higher to update the MSP-FET430UIF firmware.

### MSP-FET430PIF *Some PCs do not supply 5 V through the parallel port*

---

**Problem Description** Device identification problems with modern PCs, because the parallel port often does not deliver 5 V as was common with earlier hardware.

1. When connected to a laptop, the test signal is clamped to 2.5 V.
2. When the external  $V_{CC}$  becomes less than 3 V, up to 10 mA is flowing in the adapter via pin 4 (sense).

**Solution** Measure the voltage level of the parallel port. If it is too low, provide external 5 V to the  $V_{CC}$  pads of the interface. The jumper on a the target socket must be switched to external power.

## ***Hardware***

---

---

---

This appendix contains information relating to the FET hardware, including schematics, PCB pictorials, and bills of materials. All other tools, such as the eZ430 series, are described in separate product-specific user's guides.

| Topic                                | Page |
|--------------------------------------|------|
| B.1 MSP-TS430D8 .....                | 33   |
| B.2 MSP-TS430PW14 .....              | 36   |
| B.3 MSP-TS430L092 .....              | 39   |
| B.4 MSP-TS430L092 Active Cable ..... | 42   |
| B.5 MSP-TS430PW24 .....              | 45   |
| B.6 MSP-TS430DW28 .....              | 48   |
| B.7 MSP-TS430PW28 .....              | 51   |
| B.8 MSP-TS430PW28A .....             | 54   |
| B.9 MSP-TS430DA38 .....              | 57   |
| B.10 MSP-TS430QFN23x0 .....          | 60   |
| B.11 MSP-TS430RSB40 .....            | 63   |
| B.12 MSP-TS430RHA40A .....           | 66   |
| B.13 MSP-TS430DL48 .....             | 69   |
| B.14 MSP-TS430RGZ48B .....           | 72   |
| B.15 MSP-TS430RGZ48C .....           | 75   |
| B.16 MSP-TS430PM64 .....             | 78   |
| B.17 MSP-TS430PM64A .....            | 81   |
| B.18 MSP-TS430RGC64B .....           | 84   |
| B.19 MSP-TS430RGC64C .....           | 87   |
| B.20 MSP-TS430RGC64USB .....         | 91   |
| B.21 MSP-TS430PN80 .....             | 95   |
| B.22 MSP-TS430PN80A .....            | 98   |
| B.23 MSP-TS430PN80USB .....          | 101  |
| B.24 MSP-TS430PZ100 .....            | 105  |
| B.25 MSP-TS430PZ100A .....           | 108  |
| B.26 MSP-TS430PZ100B .....           | 111  |
| B.27 MSP-TS430PZ100C .....           | 114  |
| B.28 MSP-TS430PZ5x100 .....          | 118  |
| B.29 MSP-TS430PZ100USB .....         | 121  |
| B.30 MSP-TS430PEU128 .....           | 125  |
| B.31 EM430F5137RF900 .....           | 128  |
| B.32 EM430F6137RF900 .....           | 132  |
| B.33 EM430F6147RF900 .....           | 136  |
| B.34 MSP-FET430PIF .....             | 140  |
| B.35 MSP-FET430UIF .....             | 142  |



B.1 MSP-TS430D8





Figure B-1. MSP-TS430D8 Target Socket Module, Schematic

14 pin connector for debugging only  
in Spy-Bi-Wire mode (4 Wire JTAG  
not available)



**Figure B-2. MSP-TS430D8 Target Socket Module, PCB**

**Table B-1. MSP-TS430D8 Bill of Materials**

| Position | Ref Des | No. per Board | Description                 | DigiKey Part No.     | Comment   |
|----------|---------|---------------|-----------------------------|----------------------|---|
| 1        | J4, J6  | 2             | 2-pin header, male, TH      | SAM1035-02-ND        | place jumper on header                                    |
| 2        | J5      | 1             | 3-pin header, male, TH      | SAM1035-03-ND        | place jumper on pins 1-2                                  |
| 3        | SBW     | 1             | 10-pin connector, male, TH  | HRP10H-ND            |   |
| 4        | J3      | 1             | 3-pin header, male, TH      | SAM1035-03-ND        |   |
| 5        | C8      | 1             | 2.2nF, CSMD0805             | Buerklin 53 D 292    |   |
| 6        | C7      | 1             | 10uF, 10V, 1210ELKO         | 478-3875-1-ND        |   |
| 7        | R5      | 1             | 47K, 0805                   | 541-47000ATR-ND      |   |
| 8        | C5      | 1             | 100nF, CSMD0805             | 311-1245-2-ND        |   |
| 9        | R2, R3  | 2             | 330R, 0805                  | 541-330ATR-ND        |   |
| 10       | J1, J2  | 2             | 4-pin header, TH            | SAM1029-04-ND        | DNP: headers enclosed with kit. Keep vias free of solder. |
| 10,1     | J1, J2  | 1             | 4-pin socket, TH            | SAM1029-04-ND        | DNP: receptacles enclosed with kit.                       |
| 11       | U1      | 1             | SO8 Socket: Type IC369-0082 |                      | Manuf.: Yamaichi  |
| 12       | D1      | 1             | red, LED 0603               |                      |   |
| 13       | MSP430  | 2             | MSP430x                     |                      | "DNP: enclosed with kit. Is supplied by TI"               |
| 14       | PCB     | 1             | 50,0mmx44,5mm               | MSP-TS430D8 Rev. 1.0 |   |

B.2 MSP-TS430PW14




Figure B-3. MSP-TS430PW14 Target Socket Module, Schematic



**Table B-2. MSP-TS430PW14 Bill of Materials**

| Position | Ref Des                           | No. per Board | Description                         | DigiKey Part No.   | Comment  |
|----------|-----------------------------------|---------------|-------------------------------------|--|--|
| 1        | C1, C2                            | 0             | 12pF, SMD0805                       |  | DNP  |
| 2        | C7                                | 1             | 10uF, 10V, Tantal Size B            | 511-1463-2-ND  |  |
| 3        | C3, C5                            | 1             | 100nF, SMD0805                      | 478-3351-2-ND  | DNP: C3  |
| 4        | C8                                | 0             | 2.2nF, SMD0805                      |  | DNP  |
| 5        | D1                                | 1             | green LED, SMD0603                  | 475-1056-2-ND  |  |
| 6        | J1, J2                            | 0             | 7-pin header, TH                    | SAM1029-07-ND<br>SAM1213-07-ND                           | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder<br>: Header<br>: Receptacle |
| 7        | J3, J5, J7, J8, J9, J10, J11, J12 | 8             | 3-pin header, male, TH              | SAM1035-03-ND  | Place jumpers on headers J5, J7, J8, J9, J10, J11, J12; Pos 1-2                                      |
| 8        | J4, J6                            | 2             | 2-pin header, male, TH              | SAM1035-02-ND  | Place jumper on header   |
| 9        |                                   | 9             | Jumper                              | 15-38-1024-ND  | Place on: J5, J7-J12; Pos 1-2  |
| 10       | JTAG                              | 1             | 14-pin connector, male, TH          | HRP14H-ND  |  |
| 12       | Q1                                | 0             | Crystal                             | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: keep vias free of solder  |
| 13       | R2, R3                            | 2             | 330 Ω, SMD0805                      | 541-330ATR-ND  |  |
| 15       | R5                                | 1             | 47k Ω, SMD0805                      | 541-47000ATR-ND  |  |
| 16       | U1                                | 1             | Socket: OTS-14-0.65-01              |  | Manuf.: Enplas   |
| 17       | PCB                               | 1             | 56 x 53 mm                          |  | 2 layers   |
| 18       | Adhesive plastic feet             | 4             | Approximately 6mm width, 2mm height | For example, 3M Bumpons Part No. SJ-5302                 | Apply to corners at bottom side  |
| 19       | MSP430                            | 2             | MSP430F2013IPW                      |  | DNP: enclosed with kit, supplied by TI   |







**Table B-3. MSP-TS430L092 Bill of Materials**

| Pos. | Ref Des No.             | No. Per Board | Description                    | DigiKey Part No.               | Comment   |
|------|-------------------------|---------------|--------------------------------|--------------------------------|---|
| 1    | C1, C2                  | 2             | 330nF, SMD0603                 |                                |   |
| 2    | C5                      | 1             | 100n, SMD0603                  |                                |   |
| 3    | C6                      | 1             | 10u, SMD0805                   |                                |   |
| 4    | C10                     | 1             | 100n, SMD0603                  |                                |   |
| 5    | EEPROM1                 | 1             | M95512 SO08 (SO8)              | ST Micro M95160R               | Digikey: 497-8688-1-ND  |
| 7    | J1, J2                  | 2             | 7-pin header, TH               | SAM1213-07-ND<br>SAM1035-07-ND | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J3                      | 1             | 3-pin header, male, TH         | SAM1035-03-ND                  |   |
| 9    | J4, J5                  | 2             | FE4L, FE4H                     | 4 pol. Stifftreihe             | DNP; Keep vias free of solder.  |
| 11   | J13                     | 1             | MICRO_STECKV_10                |                                | Reichelt: MicroMaTch-Connector: MM FL 10G   |
| 12   | JP1, JP2, JP3           | 3             | 2-pin header, male, TH         | SAM1035-02-ND                  | place jumper on header  |
| 15   | L1                      | 1             | 33uH, SMD0806                  | LQH2MCN330K02L                 | Farnell: 151-5557   |
| 16   | LED1, LED4              | 2             | LEDCHIPLED_0603                |                                | Farnell: 1686065  |
| 17   | Q2                      | 1             | BC817-16LT1SMD                 | BC817-16LT1SMD                 | SOT23-BEC   |
| 18   | R0, R6, R7              | 3             | 2K7, SMD0603                   |                                |   |
| 19   | R1                      | 1             | 1k, SMD0603                    |                                |   |
| 20   | R2                      | 1             | 47k, SMD0603                   |                                |   |
| 21   | R4, R5, R8, R10, RC, RD | 6             | 10k, SMD0603                   |                                |   |
| 22   | RA                      | 1             | 3.9k, SMD0603                  |                                |   |
| 23   | RB                      | 1             | 6.8k, SMD0603                  |                                |   |
| 24   | U1                      | 1             | 14 Pin Socket - IC189-0142-146 | Manuf. Yamaichi                |   |
| 22   | MSP430                  | 2             | MSP430L092PWR                  |                                | DNP: Enclosed with kit. Is supplied by TI.  |

B.4 MSP-TS430L092 Active Cable




Figure B-7. MSP-TS430L092 Active Cable Target Socket Module, Schematic


Figure B-8 shows the PCB layout for the Active Cable. The following pinning is possible:

- JP1 has two jumpers (Jumper 1 and Jumper 2) that can be set as shown in Table B-4.

**Table B-4. MSP-TS430L092 JP1 Settings**

| Jumper 1 | Jumper 2 | Description   |
|----------|----------|---|
| Off      | Off      | The active cable has no power and does not function.  |
| Off      | On       | The active cable receives power from target socket. For this option, the target socket must have its own power supply.  |
| On       | Off      | The active cable receives power from the JTAG connector.  |
| On       | On       | The JTAG connector powers the active cable and the target socket. For this option, the target socket must not have its own power source, as this would cause a not defined state. |

- JP2 is for reset. For the standard MSP-TS430L092, this jumper must be set. It sets the reset pin to high and can also control it. Without this jumper on the MSP-TS430L092, reset is set to zero.



**Figure B-8. MSP-TS430L092 Active Cable Target Socket Module, PCB**

**Table B-5. MSP-TS430L092 Active Cable Bill of Materials**

| Pos. | Ref Des        | No. Per Board | Description                | DigiKey Part No.                          | Comment   |
|------|----------------|---------------|----------------------------|---|---|
| 1    | C1, C3, C5, C6 | 4             | 100nF, SMD0603             |   |   |
| 2    | C2, C4         | 2             | 1uF, SMD0805               |   |   |
| 3    | R1, R10        | 2             | 10K, SMD0603               |   |   |
| 4    | R2             | 1             | 4K7, SMD0603               |   |   |
| 5    | R5, R6, R7, R9 | 4             | 100, SMD0603               |   |   |
| 6    | R8             | 1             | 680k, SMD0603              |   |   |
| 7    | R11, R15       | 2             | 1K, SMD0603                |   |   |
| 8    | R12            | 0             | SMD0603                    |   | DNP   |
| 9    | R13            | 0             | SMD0603                    |   | DNP   |
| 10   | R14            | 1             | 0, SMD0603                 |   |   |
| 11   | IC1            | 1             | SN74AUC1G04DBVR            |   | Manu: TI  |
| 12   | IC2, IC3, IC4  | 3             | SN74AUC2G125DCTR           |   | Manu: TI  |
| 13   | J2             | 1             | MICRO_STECKV_10            | Reichelt: MicroMaTch-Connector: MM FL 10G |   |
| 14   | JP1            | 1             | 2x2 Header                 | JP2Q                                      | Put jumper on Position 1 and 2. Do not mix direction. |
| 15   | JP2            | 1             | 2-pin header, male, TH     | SAM1035-02-ND                             | place jumper on header                                |
| 16   | JTAG           | 1             | 14-pin connector, male, TH | HRP14H-ND                                 |   |
| 17   | Q1             | 1             | BC817-25LT1SMD, SOT23-BEC  | Digi-Key: BC817-25LT1GOSCT-ND             |   |
| 18   | U1, U2         | 2             | TLVH431IDBVR               | SOT23-5                                   | Manu: TI  |

B.5 MSP-TS430PW24





Figure B-9. MSP-TS430PW24 Target Socket Module, Schematic



**Figure B-10. MSP-TS430PW24 Target Socket Module, PCB**

**Table B-6. MSP-TS430PW24 Bill of Materials**

| Position | Ref Des  | No. per Board | Description                            | DigiKey Part No.                                | Comment   |
|----------|--|---------------|--|---|---|
| 1        | C1, C2   | 0             | 12pF, SMD0805                          |   | DNP   |
| 2        | C5   | 1             | 2.2nF, SMD0805                         |   |   |
| 3        | C3, C7   | 2             | 10uF, 10V, SMD0805                     |   |   |
| 4        | C4, C6, C8                                     | 3             | 100nF, SMD0805                         | 478-3351-2-ND                                   |   |
| 5        | D1   | 1             | green LED, SMD0805                     | P516TR-ND                                       |   |
| 6        | J1, J2   | 0             | 12-pin header, TH                      | "SAM1029-07-<br>NDSAM1213-07-ND"                | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder. (Header & Receptacle) |
| 7        | J5, JP1,<br>JP4, JP5,<br>JP6, JP7,<br>JP8, JP9 | 8             | 3-pin header, male, TH                 | SAM1035-03-ND                                   | Place jumper on 1-2 of JP4-JP9<br>Place on 1-2 on JP1   |
| 8        | JP2, JP3                                       | 2             | 2-pin header, male, TH                 | SAM1035-02-ND                                   | Place jumper on header  |
| 9        |  | 9             | Jumper                                 | 15-38-1024-ND                                   | see Pos 7 an 8  |
| 10       | JTAG   | 1             | 14-pin connector, male,<br>TH          | HRP14H-ND                                       |   |
| 11       | Q1   | 0             | Crystal                                |   | DNP: keep vias free of solder   |
| 12       | R1, R7   | 2             | 330 Ω, SMD0805                         | 541-330ATR-ND                                   |   |
| 13       | R5, R6,<br>R8, R9,                             | 2             | 0 Ohm, SMD0805                         | 541-000ATR-ND                                   | DNP R5, R6  |
| 14       | R4   | 1             | 47k Ohm, SMD0805                       | 541-47000ATR-ND                                 |   |
| 15       | U1   | 1             | Socket: OTS 24(28)-<br>065-02-00       |   | Manuf.: Enplas  |
| 16       | PCB  | 1             | 68.5 x 61 mm                           |   | 2 layers  |
| 17       | Adhesive<br>plastic feet                       | 4             | Approximately 6mm<br>width, 2mm height | for example, 3M<br>Bumpons Part No. SJ-<br>5302 | Apply to corners at bottom side   |
| 18       | MSP430   | 2             | MSP430AFE2xx                           |   | DNP: enclosed with kit, supplied by TI  |

B.6 MSP-TS430DW28





Figure B-11. MSP-TS430DW28 Target Socket Module, Schematic





**Figure B-12. MSP-TS430DW28 Target Socket Module, PCB**

**Table B-7. MSP-TS430DW28 Bill of Materials**

| Position | Ref Des                                   | No. per Board | Description              | DigiKey Part No.   | Comment   |
|----------|---|---------------|--------------------------|--|---|
| 1        | C1, C2                                    | 0             | 12pF, SMD0805            |  | DNP: C1, C2, Cover holes while soldering  |
| 2        | C5  | 1             | 100nF, SMD0805           |  |   |
| 3        | C7  | 1             | 10uF, 10V Tantal Elko B  |  |   |
| 4        | C8  | 1             | 10nF                     | SMD0805  |   |
| 5        | D1  | 1             | LED3 T1 3mm yellow       | RS: 228-4991   |   |
| 6        | Q1  | 0             | QUARZ, Crystal           | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Cover holes while soldering  |
| 7        | J1, J2                                    | 2             | 14-pin header, TH male   |  | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7.1      |   | 2             | 14-pin header, TH female |  | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8        | J3  | 1             | 3-Pin Connector, male    |  |   |
| 9        | J4, J5                                    | 2             | 2-Pin Connector, male    |  | With jumper   |
| 10       | BOOTST                                    | 0             | ML10, 10-Pin Conn., m    | RS: 482-115  | DNP, Cover holes while soldering  |
| 11       | JTAG                                      | 1             | ML14, 14-Pin Conn., m    | RS: 482-121  |   |
| 12       | R1, R2,<br>R6, R7,<br>R8, R9,<br>R10, R11 | 4             | 0R, SMD0805              |  | DNP: R1, R2, R9, R10  |
| 13       | R3  | 1             | 560R, SMD0805            |  |   |
| 14       | R5  | 1             | 47K, SMD0805             |  |   |
| 15       | U1  | 1             | SOP28DW socket           | Yamaichi: IC189-0282-042                                 |   |
| 16       | U2  | 0             | TSSOP                    |  | DNP   |

B.7 MSP-TS430PW28




Figure B-13. MSP-TS430PW28 Target Socket Module, Schematic




Figure B-14. MSP-TS430PW28 Target Socket Module, PCB

**Table B-8. MSP-TS430PW28 Bill of Materials<sup>(1)</sup>**

| Pos. | Ref Des                                    | No. per Board | Description              | DigiKey Part No.   | Comment  |
|------|--|---------------|--------------------------|--|--|
| 1    | C1, C2                                     | 0             | 12pF, SMD0805            |  | DNP: C1, C2 , Cover holes while soldering  |
| 2    | C3   | 1             | 10uF, 10V Tantal Elko B  |  |  |
| 3    | C4   | 1             | 100nF, SMD0805           |  |  |
| 4    | C5   | 0             | 2.2nF, SMD0805           |  | DNP  |
| 5    | D1   | 1             | LED green SMD0603        |  |  |
| 6    | Q1   | 0             | QUARZ, Crystal           | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Cover holes and neighboring holes while soldering   |
| 7    | J1, J2                                     | 2             | 14-pin header, TH male   |  | DNP: Headers and receptacles enclosed with kit.Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7.1  |  | 2             | 14-pin header, TH female |  | DNP: headers and receptacles enclosed with kit.Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5, IP1                                    | 1             | 3-Pin Connector , male   |  |  |
| 8a   | JP1, JP4,<br>JP5, JP6,<br>JP7, JP8,<br>JP9 | 7             | 3-Pin Connector , male   |  | Jumper on Pos 1-2  |
| 9    | JP2, JP3                                   | 2             | 2-Pin Connector , male   |  | with Jumper  |
| 10   | BOOTST                                     | 0             | ML10, 10-Pin Conn. , m   | RS: 482-115  | DNP: Cover holes while soldering   |
| 11   | JTAG                                       | 1             | ML14, 14-Pin Conn. , m   | RS: 482-121  |  |
| 12   | R1, R7                                     | 2             | 330R, SMD0805            |  |  |
| 12   | R2, R3, R5,<br>R6                          | 0             | 0R, SMD0805              |  | DNP  |
| 14   | R4   | 1             | 47K, SMD0805             |  |  |
| 15   | U1   | 1             | SOP28PW socket           | Enplas: OTS-28-0.65-01                                   |  |

<sup>(1)</sup> PCB 66 x 79 mm, two layers; Rubber stand off, four pieces

B.8 MSP-TS430PW28A




Figure B-15. MSP-TS430PW28A Target Socket Module, Schematic




Figure B-16. MSP-TS430PW28A Target Socket Module, PCB (Red)

**Table B-9. MSP-TS430PW28A Bill of Materials**

| Position | Ref Des                               | No. per Board | Description                         | DigiKey Part No.                                     | Comment   |
|----------|---------------------------------------|---------------|-------------------------------------|--|---|
| 1        | C1, C2                                | 0             | 12pF, SMD0805                       |  | DNP   |
| 2        | C5                                    | 1             | 2.2nF, SMD0805                      |  |   |
| 3        | C3                                    | 1             | 10uF, 10V, SMD0805                  |  |   |
| 4        | C4, C6,                               | 2             | 100nF, SMD0805                      | 478-3351-2-ND  |   |
| 5        | D1                                    | 1             | green LED, SMD0805                  | P516TR-ND  |   |
| 6        | J1, J2                                | 0             | 14-pin header, TH                   |  | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder: (Header & Receptacle) |
| 7        | J5, JP1, JP4, JP5, JP6, JP7, JP8, JP9 | 8             | 3-pin header, male, TH              | SAM1035-03-ND  | Place jumper on 1-2 of JP4-JP9<br>Place on 1-2 on JP1   |
| 8        | JP2, JP3                              | 2             | 2-pin header, male, TH              | SAM1035-02-ND  | Place jumper on header  |
| 9        |                                       | 9             | Jumper                              | 15-38-1024-ND  | see Pos 7 an 8  |
| 10       | JTAG                                  | 1             | 14-pin connector, male, TH          | HRP14H-ND  |   |
| 11       | BOOTST                                | 0             |                                     |  | DNP Keep vias free of solder  |
| 12       | Q1                                    | 0             | Crystal                             | Micro Crystal MS3V<br>32.768kHz, C(Load) =<br>12.5pF | DNP: keep vias free of solder   |
| 13       | R1, R7                                | 2             | 330 Ω, SMD0805                      | 541-330ATR-ND  |   |
| 14       | R2, R3,R5, R6,                        | 0             | 0 Ohm, SMD0805                      | 541-000ATR-ND  | DNP R2, R3,R5, R6   |
| 15       | R4                                    | 1             | 47k Ω, SMD0805                      | 541-47000ATR-ND                                      |   |
| 16       | U1                                    | 1             | Socket: OTS-28-0.65-01              |  | Manuf.: Enplas  |
| 17       | PCB                                   | 1             | 63.5 x 64.8 mm                      |  | 2 layers  |
| 18       | Adhesive plastic feet                 | 4             | Approximately 6mm width, 2mm height | for example, 3M<br>Bumpons Part No. SJ-5302          | Apply to corners at bottom side   |
| 19       | MSP430                                | 2             | MSP430G2553IPW28                    |  | DNP: enclosed with kit, supplied by TI  |



B.9 MSP-TS430DA38




Figure B-17. MSP-TS430DA38 Target Socket Module, Schematic




Figure B-18. MSP-TS430DA38 Target Socket Module, PCB

**Table B-10. MSP-TS430DA38 Bill of Materials**

| Pos. | Ref Des                                 | No. per Board | Description                | DigiKey Part No.   | Comment   |
|------|---|---------------|----------------------------|--|---|
| 1    | C1, C2                                  | 0             | 12pF, SMD0805              |  | DNP   |
| 2    | C7                                      | 1             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 3    | C5                                      | 1             | 100nF, SMD0805             | 478-3351-2-ND  |   |
| 4    | C8                                      | 0             | 2.2nF, SMD0805             |  | DNP   |
| 5    | D1                                      | 1             | green LED, SMD0603         | 475-1056-2-ND  |   |
| 6    | J1, J2                                  | 0             | 19-pin header, TH          | SAM1029-19-ND<br>SAM1213-19-ND                           | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7    | "J3, JP1, JP4, JP5, JP6, JP7, JP8, JP9" | 8             | 3-pin header, male, TH     | SAM1035-03-ND  | Place jumpers on headers JP1, JP4, JP5, JP6, JP7, JP8, JP9; Pos 1-2                                   |
| 8    | JP2, JP3                                | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | Place jumper on header  |
| 9    |   | 9             | Jumper                     | 15-38-1024-ND  | Place on: JP1 - JP9; Pos 1-2  |
| 10   | JTAG                                    | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 11   | BOOTST                                  | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 12   | Q1                                      | 0             | Crystal                    | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Keep vias free of solder   |
| 13   | R1, R3                                  | 2             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND  |   |
| 14   | R10, R11                                | 0             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP   |
| 15   | R5                                      | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 16   | U1                                      | 1             | Socket: IC189-0382--037    |  | Manuf.: Yamaichi  |
| 17   | PCB                                     | 1             | 67 x 66 mm                 |  | 2 layers  |
| 18   | Adhesive Plastic feet                   | 4             | ~6mm width, 2mm height     | for example, 3M Bumpons<br>Part No. SJ-5302              | Apply to corners at bottom side   |
| 19   | MSP430                                  | 2             | MSP430F2274IDA             |  | DNP: enclosed with kit supplied by TI   |

B.10 MSP-TS430QFN23x0




Figure B-19. MSP-TS430QFN23x0 Target Socket Module, Schematic

|   |
|---|
| MSP-TS430F23x0<br>Target Socket Board for MSP430F23x0IPHH |
| TITLE: MSP-TS430F23x0                                     |
| Document Number:  |
| Date: 3/05/2007 09:31:46a                                 |
| REV: 2.2  |
| Sheet: 1/1  |




Figure B-20. MSP-TS430QFN23x0 Target Socket Module, PCB

**Table B-11. MSP-TS430QFN23x0 Bill of Materials**

| Pos. | Ref Des               | No. per Board | Description                | DigiKey Part No.   | Comment   |
|------|-----------------------|---------------|----------------------------|--|---|
| 1    | C1, C2                | 0             | 12pF, SMD0805              |  | DNP   |
| 2    | C3                    | 1             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 3    | C4                    | 1             | 100nF, SMD0805             | 478-3351-2-ND  |   |
| 4    | C5                    | 1             | 10nF, SMD0805              | 478-1383-2-ND  |   |
| 5    | D1                    | 1             | green LED, SMD0603         | 475-1056-2-ND  |   |
| 6    | J1, J2, J3, J4        | 0             | 10-pin header, TH          | SAM1034-10-ND<br>SAM1212-10-ND                           | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7    | J5, JP1               | 2             | 3-pin header, male, TH     | SAM1035-03-ND  | Place jumper on header JP1; Pos 1-2.  |
| 8    | JP2, JP3              | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | Place jumper on header  |
| 9    |                       | 3             | Jumper                     | 15-38-1024-ND  | Place on: JP1, JP2, JP3   |
| 10   | JTAG                  | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 11   | BOOTST                | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 12   | Q1                    | 0             | Crystal                    | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Keep vias free of solder   |
| 13   | R1                    | 1             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND  |   |
| 14   | R2, R3                | 0             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP   |
| 15   | R4                    | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 16   | U1                    | 1             | Socket: QFN-40B-0.5-01     |  | Manuf.: Enplas  |
| 17   | PCB                   | 1             | 79 x 66 mm                 |  | 2 layers  |
| 18   | Adhesive Plastic feet | 4             | ~6mm width, 2mm height     | for example, 3M Bumpons<br>Part No. SJ-5302              | Apply to corners at bottom side   |
| 19   | MSP430                | 2             | MSP430F2370IRHA            |  | DNP: enclosed with kit supplied by TI   |

B.11 MSP-TS430RSB40





Figure B-21. MSP-TS430RSB40 Target Socket Module, Schematic



**Figure B-22. MSP-TS430RSB40 Target Socket Module, PCB**



**Table B-12. MSP-TS430RSB40 Bill of Materials**

| Pos. | Ref Des                                     | No. Per Board | Description                | DigiKey Part No.                                   | Comment   |
|------|---|---------------|----------------------------|--|---|
| 1    | C1, C2                                      | 0             | 12pF, SMD0805              |  | DNP: C1, C2   |
| 2    | C3, C7, C10, C12                            | 3             | 10uF, 10V, SMD 0805        | 445-1371-1-ND                                      | DNP C12   |
| 3    | C4, C6, C8, C11                             | 3             | 100nF, SMD0805             | 311-1245-2-ND                                      | DNP C11   |
| 4    | C5  | 1             | 2.2nF, SMD0805             |  |   |
| 5    | C9  | 1             | 470nF, SMD0805             |  |   |
| 6    | D1  | 1             | green LED, SMD0805         | P516TR-ND  |   |
| 7    | J1, J2, J3, J4                              | 4             | 10-pin header, TH          |  | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7.1  |   | 4             | 10-pin header, TH          |  | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | JP1, JP4, JP5, JP6, JP7, JP8, JP9, J5, JP10 | 9             | 3-pin header, male, TH     | SAM1035-03-ND                                      | Jumper: 1-2 on JP1, JP10; 2-3 on JP4-JP9  |
| 9    | JP2, JP3                                    | 2             | 2-pin header, male, TH     | SAM1035-02-ND                                      | place jumper on header  |
| 10   | JTAG  | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 11   | BOOTST                                      | 0             | 10-pin connector, male, TH |  | DNP. Keep vias free of solder   |
| 12   | U1  | 1             | QFN-40B-0.4__ENPLAS_SOCKET | Enplas   |   |
| 13   | Q1  | 0             | Crystal                    | Micro Crystal MS3V-T1R 32.768kHz, C(Load) = 12.5pF | DNP: Q1. Keep vias free of solder   |
| 15   |   | 10            | Jumper                     | 15-38-1024-ND                                      | Place on: JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10   |
| 16   | R1,R7                                       | 2             | 330R SMD0805               |  |   |
| 17   | R2, R3, R5, R6, R8, R9, R10                 | 3             | 0R SMD0805                 |  | DNP R2, R3, R5, R6  |
| 18   | R4  | 1             | 47k SMD0805                |  |   |
| 19   | MSP430                                      | 2             | MSP430F5132                |  | DNP: enclosed with kit. Is supplied by TI   |
| 20   | Rubber stand off                            | 4             |                            | select appropriate; for example, Buerklin: 20H1724 | apply to corners at bottom side   |

B.12 MSP-TS430RHA40A





Figure B-23. MSP-TS430RHA40A Target Socket Module, Schematic



**Figure B-24. MSP-TS430RHA40A Target Socket Module, PCB**

**Table B-13. MSP-TS430RHA40A Bill of Materials**

| Position | Ref Des                               | No. per Board | Description                | DigiKey Part No.                                   | Comment   |
|----------|---------------------------------------|---------------|----------------------------|--|---|
| 1        | C1, C2                                | 0             | 12pF, SMD0805              |  | DNP: C1, C2   |
| 2        | C5                                    | 0             | 2.2nF, SMD0805             |  | DNP C12   |
| 3        | C3, C7                                | 2             | 10uF, 10V, SMD0805 5       |  | DNP C11   |
| 4        | C4, C6                                | 2             | 100nF, SMD0805             | 478-3351-2-ND                                      |   |
| 5        | C9                                    | 1             | 470nF, SMD0805             |  |   |
| 6        | D1                                    | 1             | green LED, SMD0805         | P516TR-ND  |   |
| 7        | J1, J2, J3, J4                        | 4             | 10-pin header, TH          |  | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7.1      |                                       | 4             | 10-pin header, TH          |  | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8        | J5, JP1, JP4, JP5, JP6, JP7, JP8, JP9 | 8             | 3-pin header, male, TH     | SAM1035-03-ND                                      | Place jumper on 1-2 of JP4-JP9; Place on 1-2 on JP1   |
| 9        | JP2, JP3                              | 2             | 2-pin header, male, TH     | SAM1035-02-ND                                      | place jumper on header  |
| 10       |                                       | 9             | Jumper                     | 15-38-1024-ND                                      | see Pos 8 an 9  |
| 11       | JTAG                                  | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 12       | BOOTST                                | 0             | 10-pin connector, male, TH |  | DNP. Keep vias free of solder   |
| 13       | U1                                    | 1             | Socket: QFN-40B-0.5-01     |  | Manuf.: Enplas  |
| 14       | Q1                                    | 0             | Crystal                    | Micro Crystal MS3V-T1R 32.768kHz, C(Load) = 12.5pF | DNP: Q1. Keep vias free of solder   |
| 15       | R1,R7                                 | 2             | 330R SMD0805               | 541-330ATR-ND                                      |   |
| 16       | R2, R3, R5, R6, R8, R9,               | 2             | 0 Ohm, SMD0805             | 541-000ATR-ND                                      | DNP:R2, R3, R5, R6  |
| 17       | R4                                    | 1             | 47k SMD0805                |  |   |
| 18       | PCB                                   | 1             | 79 x 66 mm                 |  | 2 layers  |
| 19       | Rubber stand off                      | 4             |                            | select appropriate; for example, Buerklin: 20H1724 | apply to corners at bottom side   |
| 20       | MSP430                                | 2             | MSP430N5736IRHA            |  | DNP: enclosed with kit. Is supplied by TI   |

B.13 MSP-TS430DL48




Figure B-25. MSP-TS430DL48 Target Socket Module, Schematic

|                                  |            |
|----------------------------------|------------|
| MSP-TS430DL48 Target Socket DL48 |            |
| TITLE: MSP-TS430DL48             |            |
| Document Number:                 |            |
| Date: 11/14/2006 1:24:44 PM      | Sheet: 1/1 |
| REV: 1.3                         |            |




Figure B-26. MSP-TS430DL48 Target Socket Module, PCB

**Table B-14. MSP-TS430DL48 Bill of Materials**

| Pos. | Ref Des               | No. per Board | Description                | DigiKey Part No.   | Comment   |
|------|-----------------------|---------------|----------------------------|--|---|
| 1    | C1, C2                | 0             | 12pF, SMD0805              |  | DNP   |
| 2    | C4, C7                | 2             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 3    | C3, C5                | 2             | 100nF, SMD0805             | 478-3351-2-ND  |   |
| 4    | C8                    | 1             | 10nF, SMD0805              | 478-1383-2-ND  |   |
| 5    | D1                    | 1             | yellow LED, TH, 3mm, T1    | 511-1251-ND  |   |
| 6    | J1, J2                | 0             | 24-pin header, TH          | SAM1034-12-ND<br>SAM1212-12-ND                           | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7    | J3, JP1, JP2          | 2             | 3-pin header, male, TH     | SAM1035-03-ND  | Place jumper on header JP1; Pos 1-2. DNP: JP2   |
| 8    | J4, J5                | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | Place jumper on header  |
| 9    |                       | 3             | Jumper                     | 15-38-1024-ND  | Place on: JP1, J4, J5   |
| 10   | JTAG                  | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 11   | BOOTST                | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 12   | Q1                    | 0             | Crystal                    | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Keep vias free of solder   |
| 13   | R3                    | 1             | 560 $\Omega$ , SMD0805     | 541-560ATR-ND  |   |
| 14   | R4, R6, R7, R12       | 2             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP: R6, R7   |
| 15   | R5                    | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 16   | U1                    | 1             | Socket: IC51-1387 KS-15186 |  | Manuf.: Yamaichi  |
| 17   | PCB                   | 1             | 58 x 66 mm                 |  | 2 layers  |
| 18   | Adhesive Plastic feet | 4             | ~6mm width, 2mm height     | for example, 3M Bumpons<br>Part No. SJ-5302              | Apply to corners at bottom side   |
| 19   | MSP430                | 2             | MSP430F4270IDL             |  | DNP: Enclosed with kit supplied by TI   |

B.14 MSP-TS430RGZ48B





Figure B-27. MSP-TS430RGZ48B Target Socket Module, Schematic





**Figure B-28. MSP-TS430RGZ48B Target Socket Module, PCB**

**Table B-15. MSP-TS430RGZ48B Bill of Materials**

| Position | Ref Des                              | No. per Board | Description                         | DigiKey Part No.  | Comment  |
|----------|--------------------------------------|---------------|-------------------------------------|---|--|
| 1        | C1, C2                               | 0             | 12pF, SMD0805                       |   | DNP  |
| 2        | C3, C4                               | 0             | 47pF, SMD0805                       |   | DNP  |
| 3        | C6, C7, C12                          | 3             | 10uF, 6.3V, SMD0805                 |   |  |
| 4        | C5, C11, C13, C14                    | 4             | 100nF, SMD0805                      | 311-1245-2-ND   |  |
| 5        | C8                                   | 1             | 2.2nF, SMD0805                      |   |  |
| 6        | C9                                   | 1             | 470nF, SMD0805                      | 478-1403-2-ND   |  |
| 7        | D1                                   | 1             | green LED, SMD0805                  | P516TR-ND   |  |
| 8        | J1, J2, J3, J4                       | 0             | 12-pin header, TH                   | SAM1029-12-ND (Header) SAM1213-12-ND (Receptacle)   | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder:                    |
| 9        | J5                                   | 1             | 3-pin header, male, TH              |   |  |
| 10       | JP3, JP5, JP6, JP7, JP8, JP9, JP10   | 7             | 3-pin header, male, TH              | SAM1035-03-ND   | place jumpers on pins 2-3 on JP5, JP6, JP7, JP8, JP9, JP10 place jumpers on pins 1-2 on JP3, |
| 11       | JP1, JP2                             | 2             | 2-pin header, male, TH              | SAM1035-02-ND   | Place jumper on header   |
| 12       |                                      | 9             | Jumper                              | 15-38-1024-ND   | See Pos. 10and Pos. 11   |
| 13       | JTAG                                 | 1             | 14-pin connector, male, TH          | HRP14H-ND   |  |
| 14       | BOOTST                               | 0             | 10-pin connector, male, TH          |   | "DNP Keep vias free of solder"   |
| 15       | Q1                                   | 0             | Crystal                             | Micro Crystal MS3V-T1R 32.768kHz, C(Load) = 12.5pF  | DNP: Q1 Keep vias free of solder   |
| 16       | Q2                                   | 0             | Crystal                             | Q2: 4MHz Buerklin: 78D134   | DNP: Q2 Keep vias free of solder   |
| 17       | Insulating disk to Q2                | 0             | Insulating disk to Q2               | <a href="http://www.ettinger.de/Art_Detail.cfm?ART_ART_NUM=70.08.121">http://www.ettinger.de/Art_Detail.cfm?ART_ART_NUM=70.08.121</a> |  |
| 18       | R3, R7                               | 2             | 330 Ω, SMD0805                      | 541-330ATR-ND   |  |
| 19       | R1, R2, R4, R6, R8, R9,R10, R11, R12 | 3             | 0 Ohm, SMD0805                      | 541-000ATR-ND   | DNP: R6, R8, R9, R10, R11,R12  |
| 20       | R5                                   | 1             | 47k Ω, SMD0805                      | 541-47000ATR-ND   |  |
| 21       | U1                                   | 1             | Socket: QFN11T048-008_A101121_RGZ48 |   | Manuf.: Yamaichi   |
| 22       | PCB                                  | 1             | 81 x 76 mm                          |   | 2 layers   |
| 23       | Adhesive plastic feet                | 4             | Approximately 6mm width, 2mm height | for example, 3M Bumpons Part No. SJ-5302  | Apply to corners at bottom side  |
| 24       | MSP430                               | 2             | MSP430F5342IRGZ                     |   | DNP: enclosed with kit, supplied by TI   |

B.15 MSP-TS430RGZ48C




Figure B-29. MSP-TS430RGZ48C Target Socket Module, Schematic




Figure B-30. MSP-TS430RGZ48C Target Socket Module, PCB


Table B-16. MSP-TS430RGZ48C Revision History

| Revision | Comments   |
|----------|--|
| 1.2      | Initial release  |
| 1.3      | LFOSC pins swapped at SV1 (9-10).<br>HFOSC pins swapped at SV1 (6-7).<br>BOOTST pin 4 now directly connected to the device RST/SBWTIO pin. |

**Table B-17. MSP-TS430RGZ48C Bill of Materials**

| Pos  | Ref Des   | Number Per Board | Description                             | DigiKey Part Number      | Comment   |
|------|---|------------------|---|--------------------------|---|
| 1    | SV1, SV2, SV3, SV4                              | 4                | 12-pin header, TH                       | SAM1029-12-ND            | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 1.1  | SV1, SV2, SV3, SV4                              | 4                | 12-pin receptable, TH                   | SAM1213-12-ND            | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 2    | JP1, JP2, JP9                                   | 3                | 2-pin header, male, TH                  | SAM1035-02-ND            | Place jumper on header  |
| 3    | JP10, JP11                                      | 2                | 2-pin header, male, TH                  | SAM1035-02-ND            | DNP   |
| 4    | J1, JP3, JP4, JP5, JP6, JP7, JP8                | 7                | 3-pin header, male, TH                  | SAM1035-03-ND            | Place jumpers on pins 2-3   |
| 5    | J2  | 1                | 3-pin header, male, TH                  | SAM1035-03-ND            |   |
| 6    | JP1, JP2, JP9, J1, JP3, JP4, JP5, JP6, JP7, JP8 | 10               | Jumper                                  | 15-38-1024-ND            | Place on: JP1, JP2, JP9, J1, JP3, JP4, JP5, JP6, JP7, JP8   |
| 7    | R2, R3, R5, R6, R8, R9, R10, R11, R14           | 9                | DNP, 0805                               |                          | DNP   |
| 8    | R12, R13, R7                                    | 3                | 0R, 0805                                | 541-000ATR-ND            |   |
| 9    | C5  | 1                | 1.1nF, CSMD0805                         | 490-1623-2-ND            |   |
| 10   | C3, C7  | 2                | 1uF, 10V, CSMD0805                      | 490-1702-2-ND            |   |
| 11   | R4  | 1                | 47k, 0805                               | 541-47000ATR-ND          |   |
| 12   | C4, C6  | 2                | 100nF, CSMD0805                         | 311-1245-2-ND            |   |
| 13   | R1  | 1                | 330R, 0805                              | 541-330ATR-ND            |   |
| 14   | C1, C2, C8, C9                                  | 4                | DNP, CSMD0805                           |                          | DNP   |
| 15   | SW1, SW2  | 2                | EVQ-11L05R                              | P8079STB-ND              | DNP, Lacon: 1251459   |
| 16   | BOOTST  | 1                | 10-pin connector, male, TH              | HRP10H-ND                | DNP, keep vias free of solder   |
| 17   | JTAG  | 1                | 14-pin connector, male, TH              | HRP14H-ND                |   |
| 18   | Q1  | 1                | DNP: MS3V-TR1 (32768kHz, 20ppm, 12.5pF) | depends on application   | Micro Crystal, DNP, enclosed in kit, keep vias free of solder   |
| 19   | Q2  | 1                | DNP, Christal                           | depends on application   | DNP, keep vias free of solder   |
| 20   | U1  | 1                | Socket: QFN11T048-008 A101121-001       |                          | Manuf.: Yamaichi  |
| 20.1 | U1  | 1                | MSP430                                  |                          | DNP: enclosed with kit. Is supplied by TI.  |
| 21   | D1  | 1                | green LED, DIODE0805                    | P516TR-ND                |   |
| 22   | D3  | 1                | red (DNP), DIODE0805                    |                          | DNP   |
| 23   | D2  | 1                | yellow (DNP), DIODE0805                 |                          | DNP   |
| 24   | TP1, TP2  | 2                | Testpoint                               |                          | DNP, keep pads free of solder   |
| 25   | Rubber stand off                                | 4                |   | Buerklin: 20H1724        | apply to corners at bottom side   |
| 26   | PCB   | 1                | 79.6 x 91.0 mm                          | MSP-TS430RGZ48C Rev. 1.2 | 2 layers, black solder mask   |

**B.16 MSP-TS430PM64**



NOTE: Connections between the JTAG header and pins XOUT and XIN are no longer required and should not be made.

**Figure B-31. MSP-TS430PM64 Target Socket Module, Schematic**




Figure B-32. MSP-TS430PM64 Target Socket Module, PCB

**Table B-18. MSP-TS430PM64 Bill of Materials**

| Pos. | Ref Des   | No. per Board | Description                     | DigiKey Part No.   | Comment   |
|------|---|---------------|---------------------------------|--|---|
| 1    | C1, C2  | 0             | 12pF, SMD0805                   |  | DNP   |
| 1.1  | C3, C4  | 0             | 47pF, SMD0805                   |  | DNP: Only recommendation. Check your crystal spec.  |
| 2    | C6, C7  | 1             | 10uF, 10V, Tantal Size B        | 511-1463-2-ND  | DNP: C6   |
| 3    | C5  | 1             | 100nF, SMD0805                  | 478-3351-2-ND  |   |
| 4    | C8  | 1             | 10nF, SMD0805                   | 478-1383-2-ND  |   |
| 5    | C9  | 1             | 470nF, SMD0805                  | 478-1403-2-ND  |   |
| 6    | D1  | 1             | green LED, SMD0805              | P516TR-ND  |   |
| 7    | J1, J2, J3, J4  | 0             | 16-pin header, TH               | SAM1029-16-ND<br>SAM1213-16-ND                               | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5  | 1             | 3-pin header, male, TH          | SAM1035-03-ND  |   |
| 9    | J6, J7  | 2             | 2-pin header, male, TH          | SAM1035-02-ND  | Place jumper on header  |
| 11   |   | 2             | Jumper                          | 15-38-1024-ND  | Place on: J6, J7  |
| 12   | JTAG  | 1             | 14-pin connector, male, TH      | HRP14H-ND  |   |
| 13   | BOOTST  | 0             | 10-pin connector, male, TH      |  | DNP: Keep vias free of solder   |
| 14   | Q1, Q2  | 0             | Crystal                         | Q1: Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Keep vias free of solder   |
| 15   | R3  | 1             | 330 $\Omega$ , SMD0805          | 541-330ATR-ND  |   |
| 16   | R1, R2, R4,<br>R6, R7, R8,<br>R9, R10,<br>R11, R12,<br>R13, R14 | 3             | 0 $\Omega$ , SMD0805            | 541-000ATR-ND  | DNP: R4, R6, R7, R9, R10,<br>R11, R12, R13, R14   |
| 17   | R5  | 1             | 47k $\Omega$ , SMD0805          | 541-47000ATR-ND  |   |
| 18   | U1  | 1             | Socket: IC51-0644-807           |  | Manuf.: Yamaichi  |
| 19   | PCB   | 1             | 78 x 75 mm                      |  | 2 layers  |
| 20   | Rubber<br>standoff  | 4             |                                 | select appropriate   | Apply to corners at bottom<br>side  |
| 21   | MSP430  | 22            | MSP430F2619IPM<br>MSP430F417IPM |  | DNP: Enclosed with kit<br>supplied by TI  |



B.17 MSP-TS430PM64A





Figure B-33. MSP-TS430PM64A Target Socket Module, Schematic



**Figure B-34. MSP-TS430PM64A Target Socket Module, PCB**

**Table B-19. MSP-TS430PM64A Bill of Materials**

| Pos. | Ref Des                                | No. per Board | Description                | DigiKey Part No.   | Comment   |
|------|--|---------------|----------------------------|--|---|
| 1    | C1, C2,                                | 0             | 12pF, SMD0805              |  | DNP   |
| 2    | C3                                     | 0             | 2.2nF, SMD0805             |  | DNP   |
| 3    | C6,                                    | 1             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 4    | C4, C5                                 | 2             | 100nF, SMD0805             | 478-3351-2-ND  |   |
| 5    | D1                                     | 1             | green LED, SMD0805         | P516TR-ND  |   |
| 6    | J1, J2, J3, J4                         | 0             | 16-pin header, TH          | SAM1029-16-ND<br>SAM1213-16-ND                           | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7    | J5, JP3, JP4, JP5, JP6, JP7, JP8, JP9  | 8             | 3-pin header, male, TH     | SAM1035-03-ND  |   |
| 8    | JP1, JP2                               | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | Place jumper on header  |
| 9    |  | 2             | Jumper                     | 15-38-1024-ND  | Place on: J6, J7  |
| 10   | JTAG                                   | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 11   | BOOTST                                 | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 12   | Q1                                     | 0             | Crystal                    | Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Keep vias free of solder   |
| 13   | R3, R6                                 | 2             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND  |   |
| 14   | R1, R2, R5, R7, R9, R10, R11, R13, R14 | 2             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP: R5, R7, R9, R10, R11, R13, R14   |
| 15   | R4                                     | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 16   | U1                                     | 1             | Socket: IC51-0644-807      |  | Manuf.: Yamaichi  |
| 17   | PCB                                    | 1             | 78 x 75 mm                 |  | 4 layers  |
| 18   | Rubber stand off                       | 4             |                            | select appropriate                                       | Apply to corners at bottom side   |
| 19   | MSP430                                 | 2             | MSP430F4152IPM             |  | DNP: Enclosed with kit supplied by TI   |

B.18 MSP-TS430RGC64B




Figure B-35. MSP-TS430RGC64B Target Socket Module, Schematic




Figure B-36. MSP-TS430RGC64B Target Socket Module, PCB

**Table B-20. MSP-TS430RGC64B Bill of Materials**

| Pos. | Ref Des                                       | No. per Board | Description                         | DigiKey Part No.  | Comment  |
|------|---|---------------|-------------------------------------|---|--|
| 1    | C1, C2  | 0             | 12pF, SMD0805                       |   | DNP  |
| 2    | C3, C4  | 0             | 47pF, SMD0805                       |   | DNP  |
| 3    | C6, C7, C10                                   | 3             | 10uF, 6.3V, SMD0805                 |   |  |
| 4    | C5, C11,<br>C13, C14,<br>C15                  | 5             | 100nF, SMD0805                      | 311-1245-2-ND   |  |
| 5    | C8  | 1             | 2.2nF, SMD0805                      |   |  |
| 6    | C9  | 1             | 470nF, SMD0805                      | 478-1403-2-ND   |  |
| 7    | C16   | 1             | 4.7uF, SMD0805                      |   |  |
| 8    | C17   | 1             | 220nF, SMD0805                      |   |  |
| 9    | D1  | 1             | green LED, SMD0805                  | P516TR-ND   |  |
| 10   | J1, J2, J3,<br>J4                             | 0             | 16-pin header, TH                   | SAM1029-16-ND<br>(Header) SAM1213-16-ND (Receptacle)  | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder:                    |
| 11   | J5 , J6                                       | 2             | 3-pin header, male, TH              |   |  |
| 12   | JP3, JP5,<br>JP6, JP7,<br>JP8, JP9,<br>JP10   | 7             | 3-pin header, male, TH              | SAM1035-03-ND   | place jumpers on pins 2-3 on JP5, JP6, JP7, JP8, JP9, JP10 place jumpers on pins 1-2 on JP3, |
| 13   | JP1, JP2,<br>JP4                              | 3             | 2-pin header, male, TH              | SAM1035-02-ND   | Place jumper on header   |
| 14   |   | 10            | Jumper                              | 15-38-1024-ND   | See Pos. 12 and Pos. 13  |
| 15   | JTAG  | 1             | 14-pin connector, male, TH          | HRP14H-ND   |  |
| 16   | BOOTST  | 0             | 10-pin connector, male, TH          |   | "DNP Keep vias free of solder"   |
| 17   | Q1  | 0             | Crystal                             | Micro Crystal MS3V-T1R<br>32.768kHz, C(Load) =<br>12.5pF  | DNP: Q1 Keep vias free of solder   |
| 18   | Q2  | 0             | Crystal                             | Q2: 4MHz Buerklin:<br>78D134  | DNP: Q2 Keep vias free of solder   |
| 19   | Insulating<br>disk to Q2                      | 0             | Insulating disk to Q2               | <a href="http://www.ettinger.de/Art_Detail.cfm?ART_ARTNUM=70.08.121">http://www.ettinger.de/Art_Detail.cfm?ART_ARTNUM=70.08.121</a> |  |
| 20   | R3, R7  | 2             | 330 Ω, SMD0805                      | 541-330ATR-ND   |  |
| 21   | R1, R2, R4,<br>R6, R8,<br>R9,R10,<br>R11, R12 | 3             | 0 Ohm, SMD0805                      | 541-000ATR-ND   | DNP: R6, R8, R9, R10, R11,R12  |
| 22   | R5  | 1             | 47k Ω, SMD0805                      | 541-47000ATR-ND   |  |
| 23   | U1  | 1             | Socket: QFN11T064-006-N-HSP         |   | Manuf.: Yamaichi   |
| 24   | PCB   | 1             | 85 x 76 mm                          |   | 2 layers   |
| 25   | Adhesive<br>plastic feet                      | 4             | Approximately 6mm width, 2mm height | for example, 3M<br>Bumpsons Part No. SJ-5302  | Apply to corners at bottom side  |
| 26   | D3,D4   |               |                                     |   |  |
| 27   | MSP430  | 2             | MSP430F5310 RGC                     |   | DNP: enclosed with kit, supplied by TI   |

## B.19 MSP-TS430RGC64C

The MSP-TS430RGC64C target board has been designed to operate with the target device DVIO input voltage supplied via header J6 (see [Figure B-37](#)). This development platform does not supply the 1.8-V DVIO rail on board and it MUST be provided by external power supply for proper device operation. For correct JTAG connection, programming, and debug operation, it is important to follow this procedure:

1. Make sure that the VCC and DVIO voltage supplies are OFF and that the power rails are fully discharged to 0 V.
2. Enable the 1.8-V external DVIO power supply.
3. Enable the 1.8-V to 3.6-V VCC power supply (alternatively, this supply can be provided from the MSP-FET430UIF JTAG debugger interface).
4. Connect the MSP-FET430UIF JTAG connector to the target board.
5. Start the debug session using IAR or CCS IDE.

For more information on debugging the MSP430F522x, see the device data sheet ([SLAS718](#)) and *Designing with MSP430F522x and MSP430F521x Devices* ([SLAA558](#)).




Figure B-37. MSP-TS430RGC64C Target Socket Module, Schematic

|  |  |           |           |                            |
|--|--|-----------|-----------|----------------------------|
|  |  | Date:     | Name:     | <b>MSP430</b><br>TI Filing |
|  |  | Design:   | S.G.      |                            |
| Title of Schematic<br><b>MSP-TS430RGC64C</b> |  | Drawn by: | Revision: | 1.1                        |
|  |  | Page:     | 1 of 1    |                            |







Figure B-38. MSP-TS430RGC64C Target Socket Module, PCB

**Table B-21. MSP-TS430RGC64C Bill of Materials**

| Item | Qty | Reference                             | Value                  | Description                                       | Comment   | Supplier No.                   |
|------|-----|---------------------------------------|------------------------|---|---|--------------------------------|
| 1    | 0   | C1, C2                                | 12pF                   | CAP, SMD, Ceramic, 0805                           | DNP C1 C2   |                                |
| 2    | 0   | C3, C4                                | tbd                    | CAP, SMD, Ceramic, 0805                           | DNP C3 C4   |                                |
| 4    | 3   | C5, C7, C10                           | 10uF                   | CAP, SMD, Ceramic, 0805                           |   |                                |
| 5    | 5   | C8 C6 C13-15                          | 100nF                  | CAP, SMD, Ceramic, 0805                           |   | DigiKey: 311-1245-2-ND         |
| 5    | 5   | C8                                    | 2.2nF                  | CAP, SMD, Ceramic, 0805                           |   |                                |
| 6    | 1   | C9                                    | 470nF                  | CAP, SMD, Ceramic, 0805                           |   | DigiKey: 478-1403-2-ND         |
| 7    | 1   | C16                                   | 4.7uF                  | CAP, SMD, Ceramic, 0805                           |   |                                |
| 8    | 1   | D1                                    | Green LED              | LED, SMD, 0805                                    |   |                                |
| 9    | 4   | J1-J4                                 | 16-pin header          | Pin header 1x16: Grid: 100mil (2.54 mm)           | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle | SAM1029-16-ND<br>SAM1213-16-ND |
| 10   | 2   | J5, J6                                | 3-pin header, male, TH | Pin header 1x3: Grid: 100mil (2.54 mm)            |   | SAM1035-03-ND                  |
| 11   |     | JP5, JP6, JP7, JP8, JP9, JP10         | 3-pin header, male, TH | Pinheader 1x3: Grid: 100mil (2.54 mm)             | place jumpers on pins 2-3   | SAM1035-03-ND                  |
| 12   |     | JP3                                   | 3-pin header, male, TH | Pin header 1x3: Grid: 100mil (2.54 mm)            | place jumper on pins 1-2  | SAM1035-03-ND                  |
| 13   |     | JP1, JP2, JP4                         | 2-pin header, male, TH | Pin header 1x2; Grid: 100mil (2.54 mm)            | place jumper on header  | SAM1035-02-ND                  |
| 14   | 10  |                                       | Jumper                 |   | Place on: JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10   | 15-38-1024-ND                  |
| 15   | 1   | JTAG                                  | 2x7Pin,Wanne           | Header, THD, Male 2x7 Pin, Wanne, 100mil spacing  |   | HRP14H-ND                      |
| 16   | 0   | BOOTST                                | 2x5Pin,Wanne           | Header, THD, Male 2x5 Pin, Wanne, 100mil spacing  |   | DNP                            |
| 17   | 1   | Q1                                    | 26MHz/ASX53            | CRYSTAL, SMD, 5x3MM, 26MHz                        |   | Only Kit.                      |
| 18   | 0   | Q2                                    | 26MHz/ASX53            | CRYSTAL, SMD, 5x3MM, 26MHz                        |   | 300-8219-1-ND                  |
| 19   | 1   | D3                                    | LL103A                 | DIODE, SMD, SOD123, Schottky                      |   | Buerklin: 24S3406              |
| 20   | 2   | R3, R7                                | 330 Ohm, SMD0805       |   |   | 541-330ATR-ND                  |
| 21   | 1   | R5                                    | 47k Ohm, SMD0805       | RES, SMD, 0805, 1/8W, x%                          |   | 541-47000ATR-ND                |
| 22   |     | R1, R2, R4, R6, R8, R9, R10, R11, R12 | 0 Ohm, SMD0805         | RES, SMD, 0805, 1/8W, x%                          | DNP: R6, R8, R9, R10, R11, R12  | 541-000ATR-ND                  |
| 23   | 1   | U1                                    |                        | Socket: QFN11T064-006-N-HSP                       | Manuf.: Yamaichi  |                                |
| 24   | 2   | MSP430                                | MSP430F5229IRGCR       | IC, MCU, SMD, 9.15x9.15mm Thermal Pad with Socket |   |                                |
| 25   | 4   | Rubber stand off                      | Rubber stand off       |   | apply to corners at bottom side   | Buerklin: 20H1724              |
| 26   | 1   | PCB                                   | 84 x 76 mm             | 84 x 76 mm  |   |                                |

**B.20 MSP-TS430RGC64USB**

Due to the use of diodes in the power chain, the voltage on the MSP430F5xx device is approximately 0.3 V lower than is set by the debugging tool. Set the voltage in the IDE to 0.3 V higher than desired; for example, to run the MCU at 3.0 V, set it to 3.3 V.



**Figure B-39. MSP-TS430RGC64USB Target Socket Module, Schematic**




Figure B-40. MSP-TS430RGC64USB Target Socket Module, PCB


**Table B-22. MSP-TS430RGC64USB Bill of Materials**

| Pos. | Ref Des                       | No. Per Board | Description                | DigiKey Part No.  | Comment   |
|------|-------------------------------|---------------|----------------------------|---|---|
| 1    | C1, C2                        | 0             | 12pF, SMD0805              |   | DNP: C1, C2   |
| 1.1  | C3, C4                        | 2             | 47pF, SMD0805              |   |   |
| 2    | C6, C7                        | 2             | 10uF, 6.3V, Tantal Size B  | 511-1463-2-ND   |   |
| 3    | C5, C11, C13, C14             | 4             | 100nF, SMD0805             | 311-1245-2-ND   |   |
| 3.1  | C10, C12                      | 0             | 10uF, SMD0805              |   | DNP: C10, C12   |
| 4    | C8                            | 1             | 2.2nF, SMD0805             |   |   |
| 5    | C9                            | 1             | 470nF, SMD0805             | 478-1403-2-ND   |   |
| 6    | D1                            | 1             | green LED, SMD0805         | P516TR-ND   |   |
| 7    | J1, J2, J3, J4                | 4             | 16-pin header, TH          | SAM1029-16-ND   | DNP: headers and receptacles enclosed with kit. Keep vias free of solder. |
|      |                               |               |                            | SAM1213-16-ND   | : Header  |
| 8    | J5                            | 1             | 3-pin header, male, TH     | SAM1035-03-ND   | : Receptacle  |
| 9    | JP5, JP6, JP7, JP8, JP9, JP10 | 6             | 3-pin header, male, TH     | SAM1035-03-ND   | place jumpers on pins 2-3   |
| 10   | JP1, JP2, JP4                 | 3             | 2-pin header, male, TH     | SAM1035-02-ND   | place jumper on header  |
| 11   | JP3                           | 1             | 3-pin header, male, TH     | SAM1035-03-ND   | place jumper on pins 1-2  |
| 12   |                               | 10            | Jumper                     | 15-38-1024-ND   | Place on: JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10               |
| 13   | JTAG                          | 1             | 14-pin connector, male, TH | HRP14H-ND   |   |
| 14   | Q1                            | 0             | Crystal                    | Q1: Micro Crystal MS1V-T1K 32.768kHz, C(Load) = 12.5pF  | DNP: Q1<br>Keep vias free of solder"                                      |
| 15   | Q2                            | 1             | Crystal                    | Q2: 4MHz Buerklin: 78D134   |   |
| 16   | R3, R7                        | 2             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND   |   |
| 17   | R1, R2, R4, R6, R8, R9, R12   | 2             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND   | DNP: R4, R6, R8, R9, R12  |
| 18   | R10                           | 1             | 100 $\Omega$ , SMD0805     | Buerklin: 07E500  |   |
| 18   | R11                           | 1             | 1M $\Omega$ , SMD0805      |   |   |
| 18   | R5                            | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND   |   |
| 19   | U1                            | 1             | Socket: QFN11T064-006      |   | Manuf.: Yamaichi  |
| 20   | PCB                           | 1             | 79 x 77 mm                 |   | 2 layers  |
| 21   | Rubber stand off              | 4             |                            | Buerklin: 20H1724   | apply to corners at bottom side   |
| 22   | MSP430                        | 2             | MSP430F5509 RGC            |   | DNP: enclosed with kit. Is supplied by TI                                 |
| 23   | Insulating disk to Q2         | 1             | Insulating disk to Q2      | <a href="http://www.ettinger.de/Art_De tail.cfm?ART_ARTNUM=70.08.121">http://www.ettinger.de/Art_De tail.cfm?ART_ARTNUM=70.08.121</a> |   |
| 27   | C33                           | 1             | 220n SMD0603               | Buerklin: 53D2074   |   |
| 28   | C35                           | 1             | 10p SMD0603                | Buerklin: 56D102  |   |
| 29   | C36                           | 1             | 10p SMD0603                | Buerklin: 56D102  |   |
| 30   | C38                           | 1             | 220n SMD0603               | Buerklin: 53D2074   |   |
| 31   | C39                           | 1             | 4u7 SMD0603                | Buerklin: 53D2086   |   |
| 32   | C40                           | 1             | 0.1u SMD0603               | Buerklin: 53D2068   |   |
| 33   | D2, D3, D4                    | 3             | LL103A                     | Buerklin: 24S3406   |   |

**Table B-22. MSP-TS430RGC64USB Bill of Materials (continued)**

| Pos. | Ref Des          | No. Per Board | Description     | DigiKey Part No.  | Comment  |
|------|------------------|---------------|-----------------|-------------------|----------|
| 34   | IC7              | 1             | TPD4E004        |                   | Manu: TI |
| 36   | LED              | 0             | JP3QE           | SAM1032-03-ND     | DNP      |
| 37   | LED1             | 0             | LEDCHIPLED_0603 | FARNELL: 852-9833 | DNP      |
| 38   | LED2             | 0             | LEDCHIPLED_0603 | FARNELL: 852-9868 | DNP      |
| 39   | LED3             | 0             | LEDCHIPLED_0603 | FARNELL: 852-9841 | DNP      |
| 40   | R13, R15,<br>R16 | 0             | 470R            | Buerklin: 07E564  | DNP      |
| 41   | R33              | 1             | 1k4 / 1k5       | Buerklin: 07E612  |          |
| 42   | R34              | 1             | 27R             | Buerklin: 07E444  |          |
| 43   | R35              | 1             | 27R             | Buerklin: 07E444  |          |
| 44   | R36              | 1             | 33k             | Buerklin: 07E740  |          |
| 45   | S1               | 0             | PB              | P12225STB-ND      | DNP      |
| 46   | S2               | 0             | PB              | P12225STB-ND      | DNP      |
| 46   | S3               | 1             | PB              | P12225STB-ND      |          |
| 47   | USB1             | 1             | USB_RECEPTACLE  | FARNELL: 117-7885 |          |

B.21 MSP-TS430PN80



NOTE: For MSP430F(G)47x devices:  
 Connect pins 7 and 10 (GND) externally to DV<sub>SS</sub> (see data sheet).  
 Connect load capacitance on V<sub>ref</sub> pin 60 when SD16 is used (see data sheet).

Figure B-41. MSP-TS430PN80 Target Socket Module, Schematic




Figure B-42. MSP-TS430PN80 Target Socket Module, PCB



**Table B-23. MSP-TS430PN80 Bill of Materials**

| Pos. | Ref Des                                 | No. per Board | Description                | DigiKey Part No.   | Comment   |
|------|---|---------------|----------------------------|--|---|
| 1    | C1, C2                                  | 0             | 12pF, SMD0805              |  | DNP: C1, C2   |
| 1.1  | C3, C4                                  | 0             | 47pF, SMD0805              |  | DNP: Only recommendation. Check your crystal spec.  |
| 2    | C6, C7                                  | 1             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 3    | C5                                      | 1             | 100nF, SMD0805             | 478-3351-2-ND  |   |
| 4    | C8                                      | 1             | 10nF, SMD0805              | 478-1383-2-ND  |   |
| 5    | D1                                      | 1             | green LED, SMD0603         | 475-1056-2-ND  |   |
| 6    | J1, J2, J3, J4                          | 0             | 25-pin header, TH          | SAM1029-20-ND<br>SAM1213-20-ND                               | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7    | J5, JP1                                 | 2             | 3-pin header, male, TH     | SAM1035-03-ND  |   |
| 8    | J6, JP2                                 | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | Place jumper on header  |
| 9    |   | 3             | Jumper                     | 15-38-1024-ND  | Place on: J6, JP2, JP1/Pos1-2   |
| 10   | JTAG                                    | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 11   | BOOTST                                  | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 12   | Q1, Q2                                  | 0             | Crystal                    | Q1: Micro Crystal MS1V-T1K<br>32.768kHz, C(Load) =<br>12.5pF | DNP: Keep vias free of solder   |
| 13   | R3                                      | 1             | 560 $\Omega$ , SMD0805     | 541-560ATR-ND  |   |
| 14   | R1, R2, R4,<br>R6, R7, R10,<br>R11, R12 | 2             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP: R4, R6, R7, R10, R11, R12  |
| 15   | R5                                      | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 16   | U1                                      | 1             | Socket: IC201-0804-014     |  | Manuf.: Yamaichi  |
| 17   | PCB                                     | 1             | 77 x 77 mm                 |  | 2 layers  |
| 18   | Adhesive<br>Plastic feet                | 4             | ~6mm width, 2mm height     | for example, 3M Bumpons<br>Part No. SJ-5302                  | Apply to corners at bottom side   |
| 19   | MSP430                                  | 2             | MSP430FG439IPN             |  | DNP: Enclosed with kit supplied by TI   |

B.22 MSP-TS430PN80A




Figure B-43. MSP-TS430PN80A Target Socket Module, Schematic





Figure B-44. MSP-TS430PN80A Target Socket Module, PCB

**Table B-24. MSP-TS430PN80A Bill of Materials**

| Position | Ref Des                               | No. per Board | Description                         | DigiKey Part No.  | Comment  |
|----------|---------------------------------------|---------------|-------------------------------------|---|--|
| 1        | C1, C2                                | 0             | 12pF, SMD0805                       |   | DNP  |
| 2        | C3, C4                                | 0             | 47pF, SMD0805                       |   | DNP  |
| 3        | C6, C7, C10, C12                      | 3             | 10uF, 6.3V, SMD0805                 |   | DNP C10  |
| 4        | C5, C11, C13, C14, C15                | 5             | 100nF, SMD0805                      | 311-1245-2-ND   |  |
| 5        | C8                                    | 1             | 2.2nF, SMD0805                      |   |  |
| 6        | C9                                    | 1             | 470nF, SMD0805                      | 478-1403-2-ND   |  |
| 7        | C16                                   | 1             | 4.7uF, SMD0805                      |   |  |
| 8        | C17                                   | 1             | 220nF, SMD0805                      |   |  |
| 9        | D1                                    | 1             | green LED, SMD0805                  | P516TR-ND   |  |
| 10       | J1, J2, J3, J4                        | 0             | 20-pin header, TH                   | SAM1029-20-ND (Header) SAM1213-20-ND (Receptacle)   | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder:                    |
| 11       | J5, J6                                | 2             | 3-pin header, male, TH              |   |  |
| 12       | JP3, JP5, JP6, JP7, JP8, JP9, JP10    | 7             | 3-pin header, male, TH              | SAM1035-03-ND   | place jumpers on pins 2-3 on JP5, JP6, JP7, JP8, JP9, JP10 place jumpers on pins 1-2 on JP3, |
| 13       | JP1, JP2, JP4                         | 3             | 2-pin header, male, TH              | SAM1035-02-ND   | Place jumper on header   |
| 14       |                                       | 10            | Jumper                              | 15-38-1024-ND   | See Pos. 12 and Pos. 13  |
| 15       | JTAG                                  | 1             | 14-pin connector, male, TH          | HRP14H-ND   |  |
| 16       | BOOTST                                | 0             | 10-pin connector, male, TH          |   | "DNP Keep vias free of solder"   |
| 17       | Q1                                    | 0             | Crystal                             | Micro Crystal MS3V-T1R 32.768kHz, C(Load) = 12.5pF  | DNP: Q1 Keep vias free of solder   |
| 18       | Q2                                    | 0             | Crystal                             | Q2: 4MHz Buerklin: 78D134   | DNP: Q2 Keep vias free of solder   |
| 19       | Insulating disk to Q2                 | 0             | Insulating disk to Q2               | <a href="http://www.ettinger.de/Art_Detail.cfm?ART_ART_NUM=70.08.121">http://www.ettinger.de/Art_Detail.cfm?ART_ART_NUM=70.08.121</a> |  |
| 20       | D3,D4                                 | 2             | LL103A                              | Buerklin: 24S3406   |  |
| 21       | R3, R7                                | 2             | 330 Ω, SMD0805                      | 541-330ATR-ND   |  |
| 22       | R1, R2, R4, R6, R8, R9, R10, R11, R12 | 3             | 0 Ohm, SMD0805                      | 541-000ATR-ND   | DNP: R6, R8, R9, R10, R11, R12   |
| 23       | R5                                    | 1             | 47k Ω, SMD0805                      | 541-47000ATR-ND   |  |
| 24       | U1                                    | 1             | Socket:IC201-0804-014               |   | Manuf.: Yamaichi   |
| 25       | PCB                                   | 1             | 77 x 91 mm                          |   | 2 layers   |
| 26       | Adhesive plastic feet                 | 4             | Approximately 6mm width, 2mm height | for example, 3M Bumpons Part No. SJ-5302  | Apply to corners at bottom side  |
| 27       | MSP430                                | 2             | MSP430F5329IPN                      |   | DNP: enclosed with kit, supplied by TI   |

### B.23 MSP-TS430PN80USB

Due to the use of diodes in the power chain, the voltage on the MSP430F5xx device is approximately 0.3 V lower than is set by the debugging tool. Set the voltage in the IDE to 0.3 V higher than desired; for example, to run the MCU at 3.0 V, set it to 3.3 V.



NOTE: R11 should be populated.

Figure B-45. MSP-TS430PN80USB Target Socket Module, Schematic




Figure B-46. MSP-TS430PN80USB Target Socket Module, PCB

**Table B-25. MSP-TS430PN80USB Bill of Materials**


| Pos. | Ref Des                       | No. per Board | Description                | DigiKey Part No.  | Comment   |
|------|-------------------------------|---------------|----------------------------|---|---|
| 1    | C1, C2                        | 0             | 12pF, SMD0805              |   | DNP: C1, C2   |
| 1.1  | C3, C4                        | 2             | 47pF, SMD0805              |   |   |
| 2    | C6, C7                        | 2             | 10uF, 6.3V, Tantal Size B  | 511-1463-2-ND   |   |
| 3    | C5, C11, C13, C14             | 4             | 100nF, SMD0805             | 311-1245-2-ND   |   |
| 3.1  | C10, C12                      | 0             | 10uF, SMD0805              | 311-1245-2-ND   | DNP: C10, C12   |
| 4    | C8                            | 1             | 2.2nF, SMD0805             |   |   |
| 5    | C9                            | 1             | 470nF, SMD0805             | 478-1403-2-ND   |   |
| 6    | D1                            | 1             | green LED, SMD0805         | P516TR-ND   |   |
| 7    | J1, J2, J3, J4                | 4             | 20-pin header, TH          | SAM1029-20-ND   | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.                             |
| 7.1  |                               | 4             | 20-pin header, TH          | SAM1213-20-ND   | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5                            | 1             | 3-pin header, male, TH     | SAM1035-03-ND   |   |
| 9    | JP5, JP6, JP7, JP8, JP9, JP10 | 6             | 3-pin header, male, TH     | SAM1035-03-ND   | Place jumpers on pins 2-3   |
| 10   | JP1, JP2                      | 2             | 2-pin header, male, TH     | SAM1035-02-ND   | Place jumper on header  |
|      | JP4                           | 1             |                            | SAM1035-02-ND   | Place jumper only on one pin  |
| 11   | JP3                           | 1             | 3-pin header, male, TH     | SAM1035-03-ND   | Place jumper on pins 1-2  |
| 12   |                               | 10            | Jumper                     | 15-38-1024-ND   | Place on: JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10   |
| 13   | JTAG                          | 1             | 14-pin connector, male, TH | HRP14H-ND   |   |
| 14   | Q1                            | 0             | Crystal                    | Micro Crystal MS1V-T1K 32.768kHz, C(Load) = 12.5pF  | DNP: Q1 Keep vias free of solder  |
| 15   | Q2                            | 1             | Crystal                    | "Q2: 4MHzBuerklin: 78D134"  |   |
| 16   | R3, R7                        | 2             | 330 Ω, SMD0805             | 541-330ATR-ND   |   |
| 17   | R1, R2, R4, R6, R8, R9, R12   | 2             | 0 Ω, SMD0805               | 541-000ATR-ND   | DNP: R4, R6, R8, R9, R12  |
| 18   | R10                           | 1             | 100 Ω, SMD0805             | Buerklin: 07E500  |   |
| 18   | R11                           | 0             | 1M Ω, SMD0805              |   | DNP   |
| 18   | R5                            | 1             | 47k Ω, SMD0805             | 541-47000ATR-ND   |   |
| 19   | U1                            | 1             | Socket:IC201-0804-014      |   | Manuf.: Yamaichi  |
| 20   | PCB                           | 1             | 79 x 77 mm                 |   | 2 layers  |
| 21   | Rubber standoff               | 4             |                            | Buerklin: 20H1724   | Apply to corners at bottom side   |
| 22   | MSP430                        | 2             | MSP430F5529                |   | DNP: Enclosed with kit supplied by TI   |
| 23   | Insulating disk to Q2         | 1             | Insulating disk to Q2      | <a href="http://www.ettinger.de/Art_Detail.cfm?ART_ARTNUM=70.08.121">http://www.ettinger.de/Art_Detail.cfm?ART_ARTNUM=70.08.121</a> |   |
| 27   | C33                           | 1             | 220n                       | Buerklin: 53D2074   |   |

**Table B-25. MSP-TS430PN80USB Bill of Materials (continued)**

| Pos. | Ref Des       | No. per Board | Description     | DigiKey Part No.  | Comment  |
|------|---------------|---------------|-----------------|-------------------|----------|
| 28   | C35           | 1             | 10p             | Buerklin: 56D102  |          |
| 29   | C36           | 1             | 10p             | Buerklin: 56D102  |          |
| 30   | C38           | 1             | 220n            | Buerklin: 53D2074 |          |
| 31   | C39           | 1             | 4u7             | Buerklin: 53D2086 |          |
| 32   | C40           | 1             | 0.1u            | Buerklin: 53D2068 |          |
| 33   | D2, D3, D4    | 3             | LL103A          | Buerklin: 24S3406 |          |
| 34   | IC7           | 1             | TPD4E004        |                   | Manu: TI |
| 36   | LED           | 0             | JP3QE           | SAM1032-03-ND     | DNP      |
| 37   | LED1          | 0             | LEDCHIPLED_0603 | FARNELL: 852-9833 | DNP      |
| 38   | LED2          | 0             | LEDCHIPLED_0603 | FARNELL: 852-9868 | DNP      |
| 39   | LED3          | 0             | LEDCHIPLED_0603 | FARNELL: 852-9841 | DNP      |
| 40   | R13, R15, R16 | 0             | 470R            | Buerklin: 07E564  | DNP      |
| 41   | R33           | 1             | 1k4             | Buerklin: 07E612  |          |
| 42   | R34           | 1             | 27R             | Buerklin: 07E444  |          |
| 43   | R35           | 1             | 27R             | Buerklin: 07E444  |          |
| 44   | R36           | 1             | 33k             | Buerklin: 07E740  |          |
| 45   | S1            | 0             | PB              | P12225STB-ND      | DNP      |
| 46   | S2            | 0             | PB              | P12225STB-ND      | DNP      |
| 46   | S3            | 1             | PB              | P12225STB-ND      |          |
| 47   | USB1          | 1             | USB_RECEPTACLE  | FARNELL: 117-7885 |          |



B.24 MSP-TS430PZ100



NOTE: Connections between the JTAG header and pins XOUT and XIN are no longer required and should not be made.

Figure B-47. MSP-TS430PZ100 Target Socket Module, Schematic




Figure B-48. MSP-TS430PZ100 Target Socket Module, PCB

**Table B-26. MSP-TS430PZ100 Bill of Materials**

| Pos. | Ref Des                           | No. per Board | Description                              | DigiKey Part No.                                       | Comment   |
|------|-----------------------------------|---------------|--|--|---|
| 1    | C1, C2                            | 0             | 12pF, SMD0805                            |  | DNP   |
| 1b   | C3, C4                            | 0             | 47pF, SMD0805                            |  | DNP: Only recommendation. Check your crystal spec.  |
| 2    | C6, C7                            | 1             | 10uF, 10V, Tantal Size B                 | 511-1463-2-ND  | DNP: C6   |
| 3    | C5                                | 1             | 100nF, SMD0805                           | 478-3351-2-ND  |   |
| 4    | C8                                | 1             | 10nF, SMD0805                            | 478-1383-2-ND  |   |
| 5    | C9                                | 1             | 470nF, SMD0805                           | 478-1403-2-ND  |   |
| 6    | D1                                | 1             | yellow LED, TH, 3mm, T1                  | 511-1251-ND  |   |
| 7    | J1, J2, J3, J4                    | 0             | 25-pin header, TH                        | SAM1029-25-ND<br>SAM1213-25-ND                         | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5                                | 1             | 3-pin header, male, TH                   | SAM1035-03-ND  |   |
| 9    | J6, J7                            | 2             | 2-pin header, male, TH                   | SAM1035-02-ND  | place jumper on header  |
| 10   |                                   | 2             | Jumper                                   | 15-38-1024-ND  | Place on: J6, J7  |
| 11   | JTAG                              | 1             | 14-pin connector, male, TH               | HRP14H-ND  |   |
| 12   | BOOTST                            | 0             | 10-pin connector, male, TH               |  | DNP: Keep vias free of solder   |
| 13   | Q1, Q2                            | 0             | Crystal                                  | Q1: Micro Crystal MS1V-T1K 32.768kHz, C(Load) = 12.5pF | DNP: Keep vias free of solder   |
| 14   | R3                                | 1             | 330 $\Omega$ , SMD0805                   | 541-330ATR-ND  |   |
| 15   | R1, R2, R4, R8, R9, R10, R11, R12 | 3             | 0 $\Omega$ , SMD0805                     | 541-000ATR-ND  | DNP: R4, R9, R10, R12   |
| 16   | R5                                | 1             | 47k $\Omega$ , SMD0805                   | 541-47000ATR-ND  |   |
| 17   | U1                                | 1             | Socket: IC201-1004-008 or IC357-1004-53N |  | Manuf.: Yamaichi  |
| 18   | PCB                               | 1             | 82 x 90 mm                               |  | 2 layers  |
| 19   | Adhesive Plastic feet             | 4             | ~6mm width, 2mm height                   | for example, 3M Bumpons Part No. SJ-5302               | Apply to corners at bottom side   |
| 20   | MSP430                            | 2             | MSP430FG4619IPZ                          |  | DNP: enclosed with kit supplied by TI   |

B.25 MSP-TS430PZ100A





Figure B-49. MSP-TS430PZ100A Target Socket Module, Schematic



**Figure B-50. MSP-TS430PZ100A Target Socket Module, PCB**

**Table B-27. MSP-TS430PZ100A Bill of Materials**

| Pos. | Ref Des                                   | No. per Board | Description                | DigiKey Part No.                                       | Comment   |
|------|---|---------------|----------------------------|--|---|
| 1    | C1, C2                                    | 0             | 12pF, SMD0805              |  | DNP   |
| 1b   | C3, C4                                    | 0             | 47pF, SMD0805              |  | DNP: Only recommendation. Check your crystal spec.  |
| 2    | C7, C9                                    | 2             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 3    | C5, C11, C14                              | 3             | 100nF, SMD0805             | 311-1245-2-ND  |   |
| 4    | C8  | 1             | 10nF, SMD0805              | 478-1358-1-ND  |   |
| 5    | C6  | 0             | 470nF, SMD0805             | 478-1403-2-ND  | DNP   |
| 6    | D1  | 1             | green LED, SMD0805         | 67-1553-1-ND   |   |
| 7    | J1, J2, J3, J4                            | 0             | 25-pin header, TH          | SAM1029-25-ND<br>SAM1213-25-ND                         | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5  | 1             | 3-pin header, male, TH     | SAM1035-03-ND  |   |
| 10   | JP1, JP2                                  | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | pPlace jumper on header   |
| 11   | JP3                                       | 1             | 3-pin header, male, TH     | SAM1035-03-ND  | Place jumper on pins 1-2  |
| 12   |   | 3             | Jumper                     | 15-38-1024-ND  | Place on: JP1, JP2, JP3   |
| 13   | JTAG                                      | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 14   | BOOTST                                    | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 15   | Q1, Q2                                    | 0             | Crystal                    | Q1: Micro Crystal MS1V-T1K 32.768kHz, C(Load) = 12.5pF | DNP: Keep vias free of solder   |
| 16   | R3  | 1             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND  |   |
| 17   | R1, R2, R4, R6, R7, R8, R9, R10, R11, R12 | 2             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP: R4, R6, R7, R8, R9, R10, R11, R12  |
| 18   | R5  | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 19   | U1  | 1             | Socket: IC357-1004-53N     |  | Manuf.: Yamaichi  |
| 20   | PCB                                       | 1             | 90 x 82 mm                 |  | 4 layers  |
| 21   | Rubber standoff                           | 4             |                            | Select appropriate                                     | Apply to corners at bottom side   |
| 22   | MSP430                                    | 2             | MSP430F5438IPZ             |  | DNP: Enclosed with kit supplied by TI   |

B.26 MSP-TS430PZ100B




Figure B-51. MSP-TS430PZ100B Target Socket Module, Schematic




Figure B-52. MSP-TS430PZ100B Target Socket Module, PCB



**Table B-28. MSP-TS430PZ100B Bill of Materials**

| Position | Ref Des                                     | No. per Board | Description                         | DigiKey Part No.   | Comment  |
|----------|---|---------------|-------------------------------------|--|--|
| 1        | C1, C2                                      | 0             | 12pF, SMD0805                       |  | DNP  |
| 2        | C4, C5,<br>C6, C7,<br>C8, C9                | 6             | 100nF, SMD0805                      | 311-1245-2-ND  |  |
| 3        | C10, C26                                    | 2             | 470 nF, SMD0805                     | 478-1403-2-ND  |  |
| 4        | C11, C12                                    | 1             | 10 uF / 6.3 V SMD0805               |  | C12 DNP  |
| 5        | C13, C14,<br>C16, C18,<br>C19, C29          | 6             | 4.7 uF SMD0805                      |  |  |
| 6        | D1  | 1             | green LED, SMD0805                  | P516TR-ND  |  |
| 7        | J1, J2, J3,<br>J4                           | 0             | 25-pin header, TH                   | SAM1029-25-ND<br>(Header) SAM1213-25-<br>ND (Receptacle) | DNP: Headers and receptacles enclosed with kit. Keep vias free of solder:                    |
| 8        | J5  | 1             | 3-pin header, male, TH              |  |  |
| 9        | JP3, JP5,<br>JP6, JP7,<br>JP8, JP9,<br>JP10 | 7             | 3-pin header, male, TH              | SAM1035-03-ND  | place jumpers on pins 2-3 on JP5, JP6, JP7, JP8, JP9, JP10 place jumpers on pins 1-2 on JP3, |
| 10       | JP1, JP2,<br>JP4                            | 3             | 2-pin header, male, TH              | SAM1035-02-ND  | Place jumper on header   |
| 11       | JP11,<br>JP12, JP13                         | 3             | 4-pin header, male, TH              |  | place jumper on header 1-2   |
| 12       |   | 13            | Jumper                              | 15-38-1024-ND  | See Pos. 9 and Pos. 10 and Pos. 11   |
| 15       | JTAG  | 1             | 14-pin connector, male, TH          | HRP14H-ND  |  |
| 16       | BOOTST                                      | 0             | 10-pin connector, male, TH          |  | "DNP Keep vias free of solder"   |
| 17       | Q1  | 0             | Crystal                             |  | DNP: Q1 Keep vias free of solder   |
| 21       | R3, R7                                      | 2             | 330 Ω, SMD0805                      | 541-330ATR-ND  |  |
| 22       | R1, R2,<br>R4, R6,<br>R8, R10,<br>R11       | 2             | 0 Ohm, SMD0805                      | 541-000ATR-ND  | DNP: R4, R6, R8, R10, R11  |
| 23       | R5  | 1             | 47k Ω, SMD0805                      | 541-47000ATR-ND  |  |
| 24       | U1  | 1             | Socket: IC357-1004-53N              |  | Manuf.: Yamaichi   |
| 25       | PCB   | 1             | 90 x 82 mm                          |  | 2 layers   |
| 26       | Adhesive plastic feet                       | 4             | Approximately 6mm width, 2mm height | for example, 3M Bumpons Part No. SJ-5302                 | Apply to corners at bottom side  |
| 27       | MSP430                                      | 2             | MSP430F6733IPZ                      |  | DNP: enclosed with kit, supplied by TI   |

B.27 MSP-TS430PZ100C





Figure B-53. MSP-TS430PZ100C Target Socket Module, Schematic



**Figure B-54. MSP-TS430PZ100C Target Socket Module, PCB**

**Table B-29. MSP-TS430PZ100C Bill of Materials**

| Pos. | Ref Des                               | Number Per Board | Description                | Digi-Key Part No.       | Comment  |
|------|---------------------------------------|------------------|----------------------------|-------------------------|--|
| 1    | C1, C2                                | 0                | 12pF, SMD0805              |                         | DNP: C1, C2  |
| 1.1  | C3, C4                                | 2                | 47pF, SMD0805              |                         | DNP: C3, C4  |
| 2    | C6, C7                                | 2                | 10uF, 6.3V, Tantal Size B  | 511-1463-2-ND           |  |
| 3    | C5, C11, C13, C14, C19, C20           | 6                | 100nF, SMD0805             | 311-1245-2-ND           |  |
| 3.1  | C10, C12, C18,17                      | 0                | 100nF, SMD0805             | 311-1245-2-ND           | DNP: C10, C12,C18, C17   |
| 4    | C8                                    | 1                | 2.2nF, SMD0805             | Buerklin 53 D 292       |  |
| 5    | C9                                    | 1                | 470nF, SMD0805             | 478-1403-2-ND           |  |
| 6    | D1                                    | 1                | green LED, SMD0805         | P516TR-ND               |  |
| 7    | J1, J2, J3, J4                        | 4                | 25-pin header, TH          | SAM1029-25-ND           | DNP: headers and receptacles enclosed with kit.<br>Keep vias free of solder. |
| 7.1  |                                       | 4                | 25-pin header, TH          | SAM1213-25-ND           | DNP: headers and receptacles enclosed with kit.<br>Keep vias free of solder. |
| 8    | J5, J6                                | 2                | 3-pin header, male, TH     | SAM1035-03-ND           |  |
| 9    | JP5, JP6, JP7, JP8,JP9, JP10          | 6                | 3-pin header, male, TH     | SAM1035-03-ND           | place jumpers on pins 2-3  |
| 10   | JP1, JP2                              | 2                | 2-pin header, male, TH     | SAM1035-02-ND           | place jumper on header   |
| 10.1 | JP4                                   | 1                | 2-pin header, male, TH     | SAM1035-02-ND           | place jumper on header   |
| 11   | JP3                                   | 1                | 3-pin header, male, TH     | SAM1035-03-ND           | place jumper on pins 1-2   |
| 12   |                                       | 10               | Jumper                     | 15-38-1024-ND           | Place on: JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10                  |
| 13   | JTAG                                  | 1                | 14-pin connector, male, TH | HRP14H-ND               |  |
| 14   | BOOTST                                | 1                | 10-pin connector, male, TH | HRP10H-ND               | DNP, keep vias free of solder  |
| 15   | Q1                                    | 0                | Crystal                    |                         | DNP: Q1<br>Keep vias free of solder  |
| 16   | Q2                                    | 1                | Crystal                    |                         | DNP: Q2 Keep vias free of solder   |
| 17   | R3, R7                                | 2                | 330 Ohm, SMD0805           | 541-330ATR-ND           |  |
| 18   | R1, R2, R4, R6, R8, R9, R10, R11, R12 | 3                | 0 Ohm, SMD0805             | 541-000ATR-ND           | DNP: R6, R8, R9, R10, R11, R12   |
| 19   | R5                                    | 1                | 47k Ohm, SMD0805           | 541-47000ATR-ND         |  |
| 20   | U1                                    | 1                | Socket: IC357-1004-53N     |                         | Manuf.: Yamaichi   |
| 21   | PCB                                   | 1                | 79.5 x 99.5 mm             | MSP-TS430PZ100C Rev 1.0 | 2 layers   |
| 22   | Rubber stand off                      | 4                |                            | Buerklin: 20H1724       | apply to corners at bottom side  |
| 23   | MSP430                                | 2                | MSP430F643x                |                         | DNP: enclosed with kit. Is supplied by TI.                                   |
| 24   | C16                                   | 1                | 4.7 nF SMD0603             | Buerklin 53 D 2042      |  |
| 26   | D3, D4                                | 2                | LL103A                     | Buerklin: 24S3406       |  |
| 27   | JP11                                  | 1                | 4-pin header, male, TH     | SAM1035-04-ND           | Place jumper on Pin 1 and Pin 2  |
| 28   | C15                                   | 1                | 4.7 uF, SMD0805            | Buerklin 53 D 2430      |  |
| 29   | C21                                   | 1                | 220nF, SMD0805             | Buerklin 53 D 2381      |  |



B.28 MSP-TS430PZ5x100





Figure B-55. MSP-TS430PZ5x100 Target Socket Module, Schematic



**Figure B-56. MSP-TS430PZ5x100 Target Socket Module, PCB**

**Table B-30. MSP-TS430PZ5x100 Bill of Materials**

| Pos. | Ref Des                               | No. Per Board | Description                | DigiKey Part No.                                       | Comment   |
|------|---------------------------------------|---------------|----------------------------|--|---|
| 1    | C1, C2                                | 0             | 12pF, SMD0805              |  | DNP   |
| 1b   | C3, C4                                |               | 47pF, SMD0805              |  | DNP: Only recommendation. Check your crystal spec.  |
| 2    | C6, C7                                | 2             | 10uF, 10V, Tantal Size B   | 511-1463-2-ND  |   |
| 3    | C5, C10, C11, C12, C13, C14           | 4             | 100nF, SMD0805             | 311-1245-2-ND  | DNP: C12, C14   |
| 4    | C8                                    | 0             | 2.2nF, SMD0805             |  | DNP   |
| 5    | C9                                    | 1             | 470nF, SMD0805             | 478-1403-2-ND  |   |
| 6    | D1                                    | 1             | green LED, SMD0805         | 67-1553-1-ND   |   |
| 7    | J1, J2, J3, J4                        | 0             | 25-pin header, TH          | SAM1029-25-ND<br>SAM1213-25-ND                         | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5                                    | 1             | 3-pin header, male, TH     | SAM1035-03-ND  |   |
| 9    | JP5, JP6, JP7, JP8, JP9, JP10         | 6             | 3-pin header, male, TH     | SAM1035-03-ND  | Place jumpers on pins 2-3   |
| 10   | JP1, JP2                              | 2             | 2-pin header, male, TH     | SAM1035-02-ND  | Place jumper on header  |
| 11   | JP3                                   | 1             | 3-pin header, male, TH     | SAM1035-03-ND  | Place jumper on pins 1-2  |
| 12   |                                       | 9             | Jumper                     | 15-38-1024-ND  | Place on JP1, JP2, JP3, JP5, JP6, JP7, JP8, JP9, JP10   |
| 13   | JTAG                                  | 1             | 14-pin connector, male, TH | HRP14H-ND  |   |
| 14   | BOOTST                                | 0             | 10-pin connector, male, TH |  | DNP: Keep vias free of solder   |
| 15   | Q1, Q2                                | 0             | Crystal                    | Q1: Micro Crystal MS1V-T1K 32.768kHz, C(Load) = 12.5pF | DNP: Keep vias free of solder   |
| 16   | R3, R7                                | 2             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND  |   |
| 17   | R1, R2, R4, R6, R8, R9, R10, R11, R12 | 3             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND  | DNP: R6, R8, R9, R10, R11, R12  |
| 18   | R5                                    | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND  |   |
| 19   | U1                                    | 1             | Socket: IC357-1004-53N     |  | Manuf.: Yamaichi  |
| 20   | PCB                                   | 1             | 90 x 82 mm                 |  | 2 layers  |
| 21   | Rubber standoff                       | 4             |                            | Select appropriate                                     | Apply to corners at bottom side   |
| 22   | MSP430                                | 2             | MSP430F5438IPZ             |  | DNP: Enclosed with kit supplied by TI   |



**B.29 MSP-TS430PZ100USB**

Due to the use of diodes in the power chain, the voltage on the MSP430F5xx device is approximately 0.3 V lower than is set by the debugging tool. Set the voltage in the IDE to 0.3 V higher than desired; for example, to run the MCU at 3.0 V, set it to 3.3 V.




Figure B-57. MSP-TS430PZ100USB Target Socket Module, Schematic




Figure B-58. MSP-TS430PZ100USB Target Socket Module, PCB

**Table B-31. MSP-TS430PZ100USB Bill of Materials**

| Pos. | Ref Des                       | No. Per Board | Description                | DigiKey Part No.  | Comment   |
|------|-------------------------------|---------------|----------------------------|---|---|
| 1    | C1, C2                        | 0             | 12pF, SMD0805              |   | DNP: C1, C2   |
| 1.1  | C3, C4                        | 2             | 47pF, SMD0805              |   |   |
| 2    | C6, C7                        | 2             | 10uF, 6.3V, Tantal Size B  | 511-1463-2-ND   |   |
| 3    | C5, C11, C13, C14, C19        | 5             | 100nF, SMD0805             | 311-1245-2-ND   |   |
| 3.1  | C10, C12, C18, C17            | 0             | 100nF, SMD0805             | 311-1245-2-ND   | DNP: C10, C12, C18, C17   |
| 4    | C8                            | 1             | 2.2nF, SMD0805             |   |   |
| 5    | C9                            | 1             | 470nF, SMD0805             | 478-1403-2-ND   |   |
| 6    | D1                            | 1             | green LED, SMD0805         | P516TR-ND   |   |
| 7    | J1, J2, J3, J4                | 4             | 25-pin header, TH          | SAM1029-25-ND   | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 7.1  |                               | 4             | 25-pin header, TH          | SAM1213-25-ND   | DNP: headers and receptacles enclosed with kit. Keep vias free of solder.<br>: Header<br>: Receptacle |
| 8    | J5                            | 1             | 3-pin header, male, TH     | SAM1035-03-ND   |   |
| 9    | JP5, JP6, JP7, JP8, JP9, JP10 | 6             | 3-pin header, male, TH     | SAM1035-03-ND   | place jumpers on pins 2-3   |
| 10   | JP1, JP2, JP4                 | 3             | 2-pin header, male, TH     | SAM1035-02-ND   | place jumper on header  |
| 11   | JP3                           | 1             | 3-pin header, male, TH     | SAM1035-03-ND   | place jumper on pins 1-2  |
| 12   |                               | 10            | Jumper                     | 15-38-1024-ND   | Place on: JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10   |
| 13   | JTAG                          | 1             | 14-pin connector, male, TH | HRP14H-ND   |   |
| 14   | Q1                            | 0             | Crystal                    | Micro Crystal MS1V-T1K 32.768kHz, C(Load) = 12.5pF  | DNP: Q1. Keep vias free of solder   |
| 15   | Q2                            | 1             | Crystal                    | Q2: 4MHz, Buerklin: 78D134  |   |
| 16   | R3, R7                        | 2             | 330 $\Omega$ , SMD0805     | 541-330ATR-ND   |   |
| 17   | R1, R2, R4, R6, R8, R9, R12   | 3             | 0 $\Omega$ , SMD0805       | 541-000ATR-ND   | DNP: R6, R8, R9, R12  |
| 18   | R10                           | 1             | 100 $\Omega$ , SMD0805     | Buerklin: 07E500  |   |
| 18   | R11                           | 1             | 1M $\Omega$ , SMD0603      |   | not existing in Rev 1.0   |
| 18   | R5                            | 1             | 47k $\Omega$ , SMD0805     | 541-47000ATR-ND   |   |
| 19   | U1                            | 1             | Socket:IC201-1004-008      |   | Manuf.: Yamaichi  |
| 20   | PCB                           | 1             | 79 x 77 mm                 |   | 2 layers  |
| 21   | Rubber stand off              | 4             |                            | Buerklin: 20H1724   | apply to corners at bottom side   |
| 22   | MSP430                        | 2             | MSP430F5529                |   | DNP: enclosed with kit. Is supplied by TI   |
| 23   | Insulating disk to Q2         | 1             | Insulating disk to Q2      | <a href="http://www.ettinger.de/Art_De tail.cfm?ART_ARTNUM=70.08.121">http://www.ettinger.de/Art_De tail.cfm?ART_ARTNUM=70.08.121</a> |   |
| 24   | C16                           | 1             | 4.7 nF SMD0603             |   |   |
| 27   | C33                           | 1             | 220n SMD0603               | Buerklin: 53D2074   |   |
| 28   | C35, C36                      | 2             | 10p SMD0603                | Buerklin: 56D102  |   |

**Table B-31. MSP-TS430PZ100USB Bill of Materials (continued)**

| Pos. | Ref Des             | No. Per Board | Description            | DigiKey Part No.  | Comment                    |
|------|---------------------|---------------|------------------------|-------------------|----------------------------|
| 30   | C38                 | 1             | 220n SMD0603           | Buerklin: 53D2074 |                            |
| 31   | C39                 | 1             | 4u7 SMD0603            | Buerklin: 53D2086 |                            |
| 32   | C40                 | 1             | 0.1u SMD0603           | Buerklin: 53D2068 |                            |
| 33   | D2, D3, D4          | 3             | LL103A                 | Buerklin: 24S3406 |                            |
| 34   | IC7                 | 1             | TPD4E004               |                   | Manu: TI                   |
| 35   | LED                 | 0             | JP3QE                  | SAM1032-03-ND     | DNP                        |
| 36   | LED1, LED2,<br>LED3 | 0             | LEDCHIPLED_0603        | FARNELL: 852-9833 | DNP                        |
| 37   | R13, R15,<br>R16    | 0             | 470R SMD0603           | Buerklin: 07E564  | DNP                        |
| 38   | R33                 | 1             | 1k4 / 1k5 SMD0603      | Buerklin: 07E612  |                            |
| 39   | R34                 | 1             | 27R SMD0603            | Buerklin: 07E444  |                            |
| 40   | R35                 | 1             | 27R SMD0603            | Buerklin: 07E444  |                            |
| 41   | R36                 | 1             | 33k SMD0603            | Buerklin: 07E740  |                            |
| 42   | S1, S2, S3          | 1             | PB                     | P12225STB-ND      | DNP S1 and S2. (Only S3)   |
| 43   | USB1                | 1             | USB_RECEPTACLE         | FARNELL: 117-7885 |                            |
| 44   | JP11                | 1             | 4-pin header, male, TH | SAM1035-04-ND     | place jumper only on Pin 1 |

B.30 MSP-TS430PEU128




Figure B-59. MSP-TS430PEU128 Target Socket Module, Schematic




Figure B-60. MSP-TS430PEU128 Target Socket Module, PCB


**NOTE:** The MSP-TS430PEU128 Rev 1.1 ships with the following modifications:

- R7 value is changed to 0  $\Omega$  instead of 330  $\Omega$ .
- JTAG pin 8 is connected only to JP5 pin 3, and not to pin 2.
- JP5 pin 2 is connected to IC1 pin 97.
- BOOTST pin 7 is connected to IC1 pin 97.

**Table B-32. MSP-TS430PEU128 Bill of Materials**

| Pos. | Ref Des   | No. Per Board | Description                               | DigiKey Part No.         | Comment   |
|------|---|---------------|---|--------------------------|---|
| 1    | PCB   | 1             | 94x119.4mm, 4 layers                      | MSP-TS430PEU128 Rev. 1.1 | 4 layers, green solder mask                                   |
| 2    | D1  | 1             | green LED, DIODE0805                      | 516-1434-1-ND            |   |
| 3    | JP1, JP2, JP4   | 3             | 2-pin header, male, TH                    | SAM1035-02-ND            | Place jumper on header  |
| 4    | JP5, JP6, JP7, JP8, JP9, JP10                                       | 6             | 3-pin header, male, TH                    | SAM1035-03-ND            | Place jumpers on pins 1-2 (SBW)                               |
| 5    | JP11, JP12, JP13  | 3             | 4-pin header, male, TH                    | SAM1035-04-ND            | Place jumpers on pins 1-2 (AVCC=VCC)                          |
| 6    | JP3   | 1             | 4-pin header, male, TH                    | SAM1035-04-ND            | Place jumpers on pins 1-2                                     |
| 7    | JP1, JP2, JP3, JP4, JP5, JP6, JP7, JP8, JP9, JP10, JP11, JP12, JP13 | 13            | Jumper                                    | WM4592-ND                |   |
| 8    | R1, R2, R4, R6, R8  | 5             | 0R, 0805                                  | 541-0.0ATR-ND            |   |
| 9    | R10, R11  | 2             | 0R, 0805                                  | 541-0.0ATR-ND            | DNP   |
| 10   | C3  | 1             | 2.2nF, CSMD0805                           | 490-1628-2-ND            | DNP   |
| 11   | C13, C14, C16, C17, C18, C19, C29                                   | 7             | 4.7uF, 6.3V, CSMD0805                     | 587-1302-2-ND            |   |
| 12   | C11   | 1             | 10uF, 6.3V, CSMD0805                      | 445-1372-2-ND            |   |
| 13   | C12   | 1             | 10uF, 6.3V, CSMD0805                      | 445-1372-2-ND            | DNP   |
| 14   | C1, C2  | 2             | 12pF, CSMD0805                            | 490-5531-2-ND            | DNP   |
| 15   | R5  | 1             | 47K, 0805                                 | 311-47KARTR-ND           |   |
| 16   | C4, C5, C6, C7, C8, C15   | 6             | 100nF, CSMD0805                           | 311-1245-2-ND            |   |
| 17   | C9  | 1             | 100nF, CSMD0805                           | 311-1245-2-ND            | DNP   |
| 18   | R3, R7  | 2             | 330R, 0805                                | 541-330ATR-ND            |   |
| 19   | C10, C26  | 2             | 470nF, CSMD0805                           | 587-1282-2-ND            |   |
| 20   | BOOTST  | 1             | 10-pin connector, male, TH                | HRP10H-ND                | DNP, keep vias free of solder                                 |
| 21   | JTAG  | 1             | 14-pin connector, male, TH                | HRP14H-ND                |   |
| 22   | IC1 Socket  | 1             | Socket: IC500-1284-009P                   |                          | Manuf. Yamaichi   |
| 23   | IC1   | 2             | MSP430F67791PEU                           |                          | DNP: enclosed with kit. Is supplied by TI                     |
| 24   | J5  | 1             | 3-pin header, male, TH                    | SAM1035-03-ND            |   |
| 25   | Q1  | 1             | Crystal: MS3V-T1R 32.768kHz 12.5pF ±20ppm |                          | DNP: Crystal enclosed with kit. Keep vias free of solder      |
| 26   | TP1, TP2  | 2             | Test point                                |                          | DNP, keep vias free of solder                                 |
| 27   | J2,J4   | 2             | 26-pin header, TH                         | SAM1029-26-ND            | DNP: Headers enclosed with kit. Keep vias free of solder.     |
| 28   | J2,J4   | 2             | 26-pin receptacle, TH                     | SAM1213-26-ND            | DNP: Receptacles enclosed with kit. Keep vias free of solder. |
| 29   | J1, J3  | 2             | 38-pin header, TH                         | SAM1029-38-ND            | DNP: Headers enclosed with kit. Keep vias free of solder.     |
| 30   | J1, J3  | 2             | 38-pin receptacle, TH                     | SAM1213-38-ND            | DNP: Receptacles enclosed with kit. Keep vias free of solder. |
| 31   | Rubber feet   | 4             | Rubber feet                               | Buerklin: 20H1724        | apply to bottom side corners                                  |

B.31 EM430F5137RF900



- Power Management**
- VCC01 = external VCC
- Vdd = DVCC
- Vdda1 = ADD\_RF / ACC\_RF
- Vdda2 = AVCC
  
- Port connectors**
- CON1 ..
- CON3 = Port1 .. Port3 of cc430
- CON4 = spare
- CON5 = 1. XIN 2. XOUT
- CON6 = Vdd GND Vcore, COM0, LCDCAP
- CON7 = Vdda1, Vdda2, GND, AGND
- CON8 = JTAG BASE (JTAG Port)
- CON9 = Vdd GND, AGND

Figure B-61. EM430F5137RF900 Target board, Schematic






Figure B-62. EM430F5137RF900 Target board, PCB

The battery pack that is included with the EM430F5137RF900 kit may be connected to CON12. Ensure correct battery insertion regarding the polarity as indicated in battery holder.


**Table B-33. EM430F5137RF900 Bill of Materials**

| Item | Reference   | No. per Board | Description   | Value    | Manufacturer's Part Number | Manufacturer    | Comment |
|------|---|---------------|---|----------|----------------------------|-----------------|---------|
| 1    | Q1  | 1             | ( CUSTOMER SUPPLY ) CRYSTAL, SMT, 4P, 26MHz                           | 26M      | ASX-531(CS)                | AKER ELECTRONIC |         |
| 2    | C1-C5, C082, C222, C271, C281, C311, C321, C341, C412, C452 | 14            | CAPACITOR, SMT, 0402, CER, 16V, 10%, 0.1uF                            | 0.1uF    | 0402YC104KAT2A             | AVX             |         |
| 3    | C071  | 1             | CAPACITOR, SMT, 0603, CERAMIC, 0.47uF, 16V, 10%, X5R                  | 0.47uF   | 0603YD474KAT2A             | AVX             |         |
| 4    | R401  | 1             | RES0402, 47.0K  | 47kΩ     | CRCW04024702F100           | DALE            |         |
| 5    | CON11   | 1             | HEADER, THU, MALE, 14P, 2X7, 25.4x9.2x9.45mm                          |          | 09 18 514 6323             | HARTING         |         |
| 6    | CON10   | 0             | HEADER, THU, MALE, 10P, 2X5, 20.32x9.2x9.45mm                         |          | 09 18 510 6323             | HARTING         | DNP     |
| 7    | D1  | 1             | LED, SMT, 0603, GREEN, 2.1V   | active   | APT1608MGC                 | KINGBRIGHT      |         |
| 8    | D2  | 1             | LED, SMT, 0603, RED, 2.0V   | active   | APT1608EC                  | KINGBRIGHT      |         |
| 9    | Q3  | 0             | UNINSTALLED CRYSTAL, SMT, 3P, MS1V (Customer Supply)                  | 32.768k  | MS1V-T1K (UN)              | MICRO CRYSTAL   | DNP     |
| 10   | CON12   | 1             | HEADER, THU, MALE, 3P, 1x3, 9.9x4.9x5.9mm                             |          | 22-03-5035                 | MOLEX           |         |
| 11   | C251, C261  | 2             | 50V, 5%, 27pF   | 27pF     | GRM36COG270J50             | MURATA          |         |
| 12   | L341  | 1             | FERRITE, SMT, 0402, 1.0kΩ, 250mA                                      | 1kΩ      | BLM15HG102SN1D             | MURATA          |         |
| 13   | C293  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 100pF, 50V, 0.25pF, C0G(NP0)           | 100pF    | GRM1555C1H101JZ01          | MURATA          |         |
| 14   | L304  | 1             | INDUCTOR, SMT, 0402, 2.2nH, 0.1nH, 220mA, 500MHz                      | 0.0022uH | LQP15MN2N2B02              | MURATA          |         |
| 15   | L303, L305  | 2             | INDUCTOR, SMT, 0402, 15nH, 2%, 450mA, 250MHz                          | 0.015uH  | LQW15AN15NG00              | MURATA          |         |
| 16   | L292, L302  | 2             | INDUCTOR, SMT, 0402, 18nH, 2%, 370mA, 250MHz                          | 0.018uH  | LQW15AN18NG00              | MURATA          |         |
| 17   | C291  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 1pF, 50V, 0.05pF, C0G(NP0)             | 1pF      | GRM1555C1H1R0WZ01          | MURATA          |         |
| 18   | C303  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 8.2pF, 50V, 0.05pF, C0G(NP0)           | 8.2pF    | GRM1555C1H8R2WZ01          | MURATA          |         |
| 19   | C292, C301-C302, C304                                       | 4             | CAPACITOR, SMT, 0402, CERAMIC, 1.5pF, 50V, 0.05pF, C0G(NP0)           | 1.5pF    | GRM1555C1H1R5WZ01          | MURATA          |         |
| 20   | L291, L301  | 2             | INDUCTOR, SMT, 0402, 12nH, 2%, 500mA, 250MHz                          | 0.012uH  | LQW15AN12NG00              | MURATA          |         |
| 21   | C282, C312, C351, C361, C371                                | 5             | CAPACITOR, SMT, 0402, CERAMIC, 2pF, 50V, 0.1pF, C0G                   | 2.0pF    | GRM1555C1H2R0BZ01          | Murata          |         |
| 22   | L1  | 1             | INDUCTOR, SMT, 0402, 6.2nH, 0.1nH, 130mA, 500MHz                      | 6.2nH    | LQP15MN6N2B02              | Murata          |         |
| 23   | S1-S2   | 2             | ULTRA-SMALL TACTILE SWITCH, SMT, 2P, SPST-NO, 1.2x3x2.5mm, 0.05A, 12V |          | B3U-1000P                  | OMRON           |         |
| 24   | R4-R5, R051, R061, R431, R441                               | 0             | UNINSTALLED RESISTOR/JUMPER, SMT, 0402, 0 Ω, 5%, 1/16W                | 0Ω       | ERJ-2GE0R00X               | PANASONIC       | DNP     |
| 24a  | R7  | 1             | RESISTOR/JUMPER, SMT, 0402, 0 Ω, 5%, 1/16W                            | 0Ω       | ERJ-2GE0R00X               | PANASONIC       |         |
| 25   | R2-R3, R6   | 3             | RESISTOR, SMT, 0402, THICK FILM, 5%, 1/16W, 330                       | 330Ω     | ERJ-2GEJ331                | PANASONIC       |         |
| 26   | C431, C441  | 0             | CAPACITOR, SMT, 0402, CER, 12pF, 50V, 5%, NPO                         | 12pF     | ECJ-0EC1H120J              | PANASONIC       |         |
| 27   | C401  | 1             | CAPACITOR, SMT, 0402, CER, 2200pF, 50V, 10%, X7R                      | 0.0022uF | ECJ-0EB1H222K              | PANASONIC       |         |
| 28   | R331  | 1             | RESISTOR, SMT, THICK FILM, 56K, 1/16W, 5%                             | 56kΩ     | ERJ-2GEJ563                | PANASONIC       |         |
| 29   | C081, C221, C411, C451                                      | 4             | CAPACITOR, SMT, 0603, CERAMIC, 10uF, 6.3V, 20%, X5R                   | 10uF     | ECJ-1VB0J106M              | PANASONIC       |         |

**Table B-33. EM430F5137RF900 Bill of Materials (continued)**

| Item | Reference      | No. per Board | Description  | Value      | Manufacturer's Part Number | Manufacturer  | Comment |
|------|----------------|---------------|--|------------|----------------------------|---------------|---------|
| 30   | R1             | 1             | RESISTOR/JUMPER, SMT, 0402, 0 $\Omega$ , 5%, 1/16W       | 0 $\Omega$ | ERJ-2GE0R00X               | PANASONIC     |         |
| 31   | C041           | 0             | UNINSTALLED CAP CERAMIC 4.7UF 6.3V X5R 0603              | 4.7uF      | ECJ-1VB0J475K              | Panasonic     | DNP     |
| 32   | X1             | 1             | SMA STRIGHT JACK, SMT                                    |            | 32K10A-40ML5               | ROSENBERGER   |         |
| 33   | Q2             | 0             | Crystal, SMT, 32.768 kHz                                 | 32.768k    | MS3V-T1R                   | Micro Crystal | DNP     |
| 34   | U1             | 1             | DUT, SMT, PQFP, RGZ-48, 0.5mmLS, 7.15x7.15x1mm, THRM.PAD |            | CC430F52x1                 | TI            |         |
| 35   | JP1            | 1             | Pin Connector 2x4pin                                     |            | 61300821121                | WUERTH        |         |
| 36   | CON1-CON9      | 0             | Pin Connector 2x4pin                                     |            | 61300821121                | WUERTH        | DNP     |
| 37   | JP2            | 1             | Pin Connector 1x3pin                                     |            | 61300311121                | WUERTH        |         |
| 38   | JP3, JP5, JP10 | 3             | Pin Connector 1x2pin                                     |            | 61300211121                | WUERTH        |         |
| 38a  | JP7, CON13     | 0             | Pin Connector 1x2pin                                     |            | 61300211121                | WUERTH        | DNP     |
| 39   | JP4            | 1             | Pin Connector 2x2pin                                     |            | 61300421121                | WUERTH        | DNP     |
| 40   | JP1a           | 1             | Pin Connector 2x3pin                                     |            | 61300621121                | WUERTH        |         |

B.32 EM430F6137RF900



- Power Management**
- VCC01 = external VCC
- Vdd = DVCC
- Vdda1 = ADD\_RF / ACC\_RF
- Vdda2 = ACC
- Port connectors**
- CON1 ..
- CON5 = Port1 .. Ports of cc430
- CON6 = Vdd, GND, Vcore, COM0, LDCAP
- CON7 = Vdda1, Vdda2, GND, AGND
- CON8 = JTAG\_BASE (JTAG Port)
- CON9 = Vdd, GND, AGND

Figure B-63. EM430F6137RF900 Target board, Schematic




Figure B-64. EM430F6137RF900 Target board, PCB

The battery pack that is included with the EM430F6137RF900 kit may be connected to CON12. Ensure correct battery insertion regarding the polarity as indicated in battery holder.


**Table B-34. EM430F6137RF900 Bill of Materials**

| Pos. | Ref Des   | No. per Board | Description   | Part No.           | Manufacturer    |
|------|---|---------------|---|--------------------|-----------------|
| 1    | Q1  | 1             | ( CUSTOMER SUPPLY ) CRYSTAL, SMT, 4P, 26MHz                           | ASX-531(CS)        | AKER ELECTRONIC |
| 2    | C1-C5, C112, C252, C381, C391, C421, C431, C451, C522, C562 | 14            | CAPACITOR, SMT, 0402, CER, 16V, 10%, 0.1uF                            | 0402YC104KAT2A     | AVX             |
| 3    | C101  | 1             | CAPACITOR, SMT, 0603, CERAMIC, 0.47uF, 16V, 10%, X5R                  | 0603YD474KAT2A     | AVX             |
| 4    | R511  | 1             | RES0402, 47.0K  | CRCW04024702F100   | DALE            |
| 5    | CON11   | 1             | HEADER, THU, MALE, 14P, 2X7, 25.4x9.2x9.45mm, 90deg                   | 09 18 514 6323     | HARTING         |
| 7    | D1  | 1             | LED, SMT, 0603, GREEN, 2.1V   | APT1608MGC         | KINGBRIGHT      |
| 8    | D2  | 1             | LED, SMT, 0603, RED, 2.0V   | APT1608EC          | KINGBRIGHT      |
| 10   | CON12   | 1             | HEADER, THU, MALE, 3P, 1x3, 9.9x4.9x5.9mm                             | 22-03-5035         | MOLEX           |
| 11   | C361, C371  | 2             | 50V, ±5%, 27pF  | GRM36COG270J50     | MURATA          |
| 12   | L451  | 1             | FERRITE, SMT, 0402, 1.0kΩ, 250mA                                      | BLM15HG102SN1D     | MURATA          |
| 13   | C403  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 100pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H101JZ01  | MURATA          |
| 14   | L414  | 1             | INDUCTOR, SMT, 0402, 2.2nH, ±0.2nH, 1000mA, 250MHz                    | LQW15AN2N2C10      | MURATA          |
| 15   | L413, L415  | 2             | INDUCTOR, SMT, 0402, 15nH, ±5%, 460mA, 250MHz                         | LQW15AN15NJ00      | MURATA          |
| 16   | L402, L412  | 2             | INDUCTOR, SMT, 0402, 18nH, ±5%, 370mA, 250MHz                         | LQW15AN18NJ00      | MURATA          |
| 17   | C401  | 1             | CAPACITOR, SMT, 0402, CER, 1pF, 50V, ±0.25pF, NP0                     | GJM1555C1H1R0CB01D | MURATA          |
| 18   | C413  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 8.2pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H8R2CZ01  | MURATA          |
| 19   | C402, C411-C412, C414                                       | 4             | CAPACITOR, SMT, 0402, CERAMIC, 1.5pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H1R5CZ01  | MURATA          |
| 20   | L401, L411  | 2             | INDUCTOR, SMT, 0402, 12nH, ±5%, 500mA, 250MHz                         | LQW15AN12NJ00      | MURATA          |
| 21   | C46-C48, C392, C422   | 5             | CAPACITOR, SMT, 0402, CERAMIC, 2.0pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H2R0CZ01  | Murata          |
| 22   | L1  | 1             | INDUCTOR, SMT, 0402, 6.2nH, ±0.1nH, 700mA, 250MHz                     | LQW15AN6N2D00      | Murata          |
| 23   | S1-S2   | 2             | ULTRA-SMALL TACTILE SWITCH, SMT, 2P, SPST-NO, 1.2x3x2.5mm, 0.05A, 12V | B3U-1000P          | OMRON           |
| 24   | R7  | 1             | RESISTOR/JUMPER, SMT, 0402, 0 Ω, 5%, 1/16W                            | ERJ-2GE0R00X (UN)  | PANASONIC       |
| 25   | R2-R3, R6   | 3             | RESISTOR, SMT, 0402, THICK FILM, 5%, 1/16W, 330                       | ERJ-2GEJ331        | PANASONIC       |
| 27   | C511  | 1             | CAPACITOR, SMT, 0402, CER, 2200pF, 50V, 10%, X7R                      | ECJ-0EB1H222K      | PANASONIC       |
| 28   | C111, C251, C521, C561                                      | 4             | CAPACITOR, SMT, 0603, CERAMIC, 10uF, 6.3V, 20%, X5R                   | ECJ-1VB0J106M      | PANASONIC       |
| 28a  | C041  | 1             | CAP CERAMIC 4.7UF 6.3V X5R 0603                                       | ECJ-1VB0J475M      | PANASONIC       |
| 29   | R441  | 1             | RESISTOR, SMT, THICK FILM, 56K, 1/16W, 1%                             | ERJ-2RKF5602       | PANASONIC       |
| 30   | R1  | 1             | RESISTOR/JUMPER, SMT, 0402, 0 Ω, 5%, 1/16W                            | ERJ-2GE0R00X       | PANASONIC       |
| 31   | X1  | 1             | SMA STRIGHT JACK, SMT   | 32K10A-40ML5       | ROSENBERGER     |

**Table B-34. EM430F6137RF900 Bill of Materials (continued)**

| Pos. | Ref Des        | No. per Board | Description  | Part No.    | Manufacturer |
|------|----------------|---------------|--|-------------|--------------|
| 33   | U1             | 1             | DUT, SMT, PQFP, RGC-64, 0.5mmLS, 9.15x9.15x1mm, THRM.PAD | CC430F6137  | TI           |
| 34   | JP1            | 1             | Pin Connector 2x4pin                                     | 61300821121 | WUERTH       |
| 35   | JP2            | 1             | Pin Connector 1x3pin                                     | 61300311121 | WUERTH       |
| 36a  | JP3, JP5, JP10 | 3             | Pin Connector 1x2pin                                     | 61300211121 | WUERTH       |
| 38   | JP1a           | 1             | Pin Connector 2x3pin                                     | 61300621121 | WUERTH       |

B.33 EM430F6147RF900



- Power Management**
- VCC = external VCC
- DVCC = Digital VCC
- AVCC = Analog VCC
- RVCC = RF-VCC
  
- Port connectors**
- CON1 ..
- CON5 = Port1 .. Port5 of cc130
- CON6 = DVCC, GND, Vcore, COM0, LCDCAP
- CON7 = RFVCC\_1, AVCC, GND, AGND
- CON8 = JTAG\_BASE (JTAG Port)
- CON9 = DVCC, GND, AGND

Figure B-65. EM430F6147RF900 Target Board, Schematic






Figure B-66. EM430F6147RF900 Target Board, PCB

The battery pack which comes with the EM430F6147RF900 kit may be connected to CON12. Ensure correct battery insertion regarding the polarity as indicated in battery holder.

**Table B-35. EM430F6147RF900 Bill of Materials**

| Pos. | Ref Des   | No. per Board | Description   | Part No.           | Manufacturer    |
|------|---|---------------|---|--------------------|-----------------|
| 1    | Q1  | 1             | ( CUSTOMER SUPPLY ) CRYSTAL, SMT, 4P, 26MHz                           | ASX-531(CS)        | AKER ELECTRONIC |
| 2    | C1-5 C112<br>C252 C381<br>C391 C421<br>C431 C451<br>C522 C562 | 14            | CAPACITOR, SMT, 0402, CER, 16V, 10%, 0.1uF                            | 0402YC104KAT2A     | AVX             |
| 3    | C101  | 1             | CAPACITOR, SMT, 0603, CERAMIC, 0.47uF, 16V, 10%, X5R                  | 0603YD474KAT2A     | AVX             |
| 4    | R511  | 1             | RES0402, 47.0K  | CRCW04024702F100   | DALE            |
| 5    | CON11   | 1             | HEADER, THU, MALE, 14P, 2X7, 25.4x9.2x9.45mm, 90deg                   | 09 18 514 6323     | HARTING         |
| 7    | D1  | 1             | LED, SMT, 0603, GREEN, 2.1V   | APT1608MGC         | KINGBRIGHT      |
| 8    | D2  | 1             | LED, SMT, 0603, RED, 2.0V   | APT1608EC          | KINGBRIGHT      |
| 10   | CON12   | 1             | HEADER, THU, MALE, 3P, 1x3, 9.9x4.9x5.9mm                             | 22-03-5035         | MOLEX           |
| 11   | C361, C371  | 2             | 50V, ±5%, 27pF  | GRM36COG270J50     | MURATA          |
| 12   | L451  | 1             | Inductor, SMD, 0402, 12nH, 5%, 370mA                                  | LQW15AN12NJ00      | MURATA          |
| 13   | C403  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 100pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H101JZ01  | MURATA          |
| 14   | L414  | 1             | INDUCTOR, SMT, 0402, 2.2nH, ±0.2nH, 1000mA, 250MHz                    | LQW15AN2N2C10      | MURATA          |
| 15   | L413  | 1             | Inductor, SMD, 0402, 15nH, 5%, 370mA, 250MHz                          | LQW15AN15NJ00      | MURATA          |
| 15   | L415  | 1             | INDUCTOR, SMT, 0402, 15nH, ±5%, 460mA, 250 MHz                        | LQW15AN15NJ00      | MURATA          |
| 16   | L402, L412  | 2             | Inductor, SMD, 0402, 18nH, 5%, 460mA, 250MHz                          | LQW15AN18NJ00      | MURATA          |
| 17   | C401  | 1             | CAPACITOR, SMT, 0402, CER, 1pF, 50V, ±0.25pF, NP0                     | GJM1555C1H1R0CB01D | MURATA          |
| 18   | C413  | 1             | CAPACITOR, SMT, 0402, CERAMIC, 8.2pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H8R2CZ01  | MURATA          |
| 19   | C402, C411-<br>C412, C414                                     | 4             | CAPACITOR, SMT, 0402, CERAMIC, 1.5pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H1R5CZ01  | MURATA          |
| 20   | L1, L401, L411  | 3             | INDUCTOR, SMT, 0402, 12nH, ±5%, 500mA, 250MHz                         | LQW15AN12NJ00      | MURATA          |
| 21   | C46-C48,<br>C392  | 4             | CAPACITOR, SMT, 0402, CERAMIC, 2.0pF, 50V, ±0.25pF, C0G(NP0)          | GRM1555C1H2R0CZ01  | MURATA          |
| 22   | L2  | 1             | Inductor, SMD, 0805, 2.2uH, 20%, 600mA, 50MHz                         | LQM21PN2R2MC0      | MURATA          |
| 23   | S1-S2   | 2             | ULTRA-SMALL TACTILE SWITCH, SMT, 2P, SPST-NO, 1.2x3x2.5mm, 0.05A, 12V | B3U-1000P          | OMRON           |
| 24   | R1, R7, R551,<br>R554   | 4             | RESISTOR/JUMPER, SMT, 0402, 0 Ω, 5%, 1/16W                            | ERJ-2GE0R00X (UN)  | PANASONIC       |
| 25   | R2-R3, R6   | 3             | RESISTOR, SMT, 0402, THICK FILM, 5%, 1/16W, 330                       | ERJ-2GEJ331        | PANASONIC       |
| 27   | C511  | 1             | CAPACITOR, SMT, 0402, CER, 2200pF, 50V, 10%, X7R                      | ECJ-0EB1H222K      | PANASONIC       |
| 28   | C111, C251,<br>C521, C561                                     | 4             | CAPACITOR, SMT, 0603, CERAMIC, 1uF, 6.3V, 20%, X5R                    | ECJ-1VB0J105K      | PANASONIC       |
| 28a  | C041  | 1             | CAP CERAMIC 4.7UF 6.3V X5R 0603                                       | ECJ-1VB0J475M      | PANASONIC       |
| 29   | R441  | 1             | RESISTOR, SMT, THICK FILM, 56K, 1/16W, 1%                             | ERJ-2RKF5602       | PANASONIC       |
| 30   | X1  | 1             | SMA STRIGHT JACK, SMT   | 32K10A-40ML5       | ROSENBERGER     |

**Table B-35. EM430F6147RF900 Bill of Materials (continued)**

| Pos. | Ref Des             | No. per Board | Description   | Part No.           | Manufacturer |
|------|---------------------|---------------|---|--------------------|--------------|
| 31   | U1                  | 1             | DUT, SMT, PQFP, RGC-64, 0.5mmLS, 9.15x9.15x1mm, THRM.PAD        | CC430F6147         | TI           |
| 33   | U2                  | 1             | IC, Step Down Converter with Bypass Mode for Low Power Wireless | TPS62370           | TI           |
| 34   | JP1                 | 1             | Pin Connector 2x4pin  | 61300821121        | WUERTH       |
| 35   | JP2, JP6, JP8       | 3             | Pin Connector 1x3pin  | 61300311121        | WUERTH       |
| 36a  | JP3, JP5, JP9, JP10 | 4             | Pin Connector 1x2pin  | 61300211121        | WUERTH       |
| 38   | JP1a                | 1             | Pin Connector 2x3pin  | 61300621121        | WUERTH       |
| 38   | C7                  | 1             | Capacitor, Ceramic, 1206, 16V, X5R, 20%                         | GRM31CR61C226ME15L | MURATA       |
| 38   | C8-9                | 2             | CAP, SMD, Ceramic, 0402, 2.2uF, X5R                             | GRM155R60J225ME15D | MURATA       |
| 38   | C041                | 1             | CAP, SMD, Ceramic, 0603, 4.7uF, 16V, 10%, X5R                   |                    | MURATA       |

B.34 MSP-FET430PIF




Figure B-67. MSP-FET430PIF FET Interface Module, Schematic




Figure B-68. MSP-FET430PIF FET Interface Module, PCB

B.35 MSP-FET430UIF




Figure B-69. MSP-FET430UIF USB Interface, Schematic (1 of 4)




Figure B-70. MSP-FET430UIF USB Interface, Schematic (2 of 4)




Figure B-71. MSP-FET430UIF USB Interface, Schematic (3 of 4)






Figure B-72. MSP-FET430UIF USB Interface, Schematic (4 of 4)




Figure B-73. MSP-FET430UIF USB Interface, PCB

### **B.35.1 MSP-FET430UIF Revision History**

#### Revision 1.3

- Initial released hardware version

#### Assembly change on 1.3 (May 2005)

- R29, R51, R42, R21, R22, R74: value changed from 330R to 100R

#### Changes 1.3 to 1.4 (Aug 2005)

- J5: VBUS and RESET additionally connected
- R29, R51, R42, R21, R22, R74: value changed from 330R to 100R
- U1, U7: F1612 can reset TUSB3410; R44 = 0R added
- TARGET-CON.: pins 6, 10, 12, 13, 14 disconnected from GND
- Firmware-upgrade option through BSL: R49, R52, R53, R54 added; R49, R52 are currently DNP
- Pullups on TCK and TMS: R78, R79 added
- U2: Changed from SN74LVC1G125DBV to SN74LVC1G07DBV

---

**NOTE: Using a locally powered target board with hardware revision 1.4**

Using an MSP-FET430UIF interface hardware revision 1.4 with populated R62 in conjunction with a locally powered target board is not possible. In this case, the target device RESET signal is pulled down by the FET tool. It is recommended to remove R62 to eliminate this restriction. This component is located close to the 14-pin connector on the MSP-FET430UIF PCB. See the schematic and PCB drawings in this document for the exact location of this component.

---

#### Assembly change on 1.4 (January 2006)

- R62: not populated

## ***Hardware Installation Guide***

---



---

This section describes the hardware installation process of the following USB debug interfaces on a PC running Windows XP:

- MSP-FET430UIF
- eZ430-F2013
- eZ430-RF2500
- eZ430-Chronos
- eZ430-RF2780
- eZ430-RF2560
- MSP-WDSxx "Metawatch"
- LaunchPad (MSP-EXP430G2)
- MSP-EXP430FR5739
- MSP-EXP430F5529

The installation procedure for other supported versions of Windows is very similar and, therefore, not shown here.

| <b>Topic</b>                           | <b>Page</b> |
|--|-------------|
| <b>C.1 Hardware Installation .....</b> | <b>149</b>  |

### C.1 Hardware Installation


Table C-1 shows the USB VIDs and PIDs used in MSP430 tools.

**Table C-1. USB VIDs and PIDs Used in MSP430 Tools**

| Tool                         | USB VID | USB PID | INF File Name   |
|------------------------------|---------|---------|-----------------|
| eZ430-F2013                  | 0x0451  | 0xF430  | usbuart3410.inf |
| eZ430-RF2500                 | 0x0451  | 0xF432  | 430CDC.inf      |
| eZ430-RF2780                 | 0x0451  | 0xF432  | 430CDC.inf      |
| eZ430-RF2560                 | 0x0451  | 0xF432  | 430CDC.inf      |
| MSP-WDSxx "Metawatch"        | 0x0451  | 0xF432  | 430CDC.inf      |
| eZ430-Chronos                | 0x0451  | 0xF432  | 430CDC.inf      |
| MSP-FET430UIF <sup>(1)</sup> | 0x2047  | 0x0010  | msp430tools.inf |
| LaunchPad (MSP-EXP430G2)     | 0x0451  | 0xF432  | 430CDC.inf      |
| MSP-EXP430FR5739             | 0x0451  | 0xF432  | 430CDC.inf      |
| MSP-EXP430F5529              | 0x0451  | 0xF432  | 430CDC.inf      |


<sup>(1)</sup> The older MSP-FET430UIF used with IAR versions before v5.20.x and CCS versions before v5.1 has VID 0x0451 and PID 0xF430. With the firmware update, it is updated to the 0x2047 and 0x0010, respectively.

1. Before connecting of the USB Debug Interface with a USB cable to a USB port of the PC the one of IDEs (CCS or IAR) should be installed. The IDE installation isntalls also drivers for USB Debug Interfaces without user interaction. After IDE installation the USB Debug Interface can be connected and will be ready to work within few seconds.
2. The driver can be also installed manually. After plug in the USB Debug Interface to USB port of the PC the Hardware Wizard starts automatically and opens the "Found New Hardware Wizard" window.
3. Select "Install from a list or specific location (Advanced)" (see [Figure C-1](#)).



**Figure C-1. Windows XP Hardware Wizard**


4. Browse to the folder where the driver information files are located (see [Figure C-2](#)).  
 For CCS, the default folder is: c:\ti\ccsv5\ccs\_base\emulation\drivers\msp430\USB\_CDC, or  
 c:\ti\ccsv5\ccs\_base\emulation\drivers\msp430\USB\_FET\_XP\_XX, or  
 c:\ti\ccsv5\ccs\_base\emulation\drivers\msp430\USB\_eZ-RF depending of firmware version of the tool.  
 For IAR Embedded Workbench, the default folder is: <Installation Root>\Embedded Workbench x.x\  
 430\drivers\TIUSBFET\ez430-UART, or  
 <Installation Root>\Embedded Workbench x.x\ 430\drivers\<Win\_OS>.



**Figure C-2. Windows XP Driver Location Selection Folder**

5. The Wizard generates a message that an appropriate driver has been found.

6. The wizard installs the driver files.
7. The wizard shows a message that it has finished the installation of the software USB Debug Interface.
8. The USB debug interface is installed and ready to use. The Device Manager lists a new entry as shown in [Figure C-3](#), [Figure C-4](#), or [Figure C-5](#).



**Figure C-3. Device Manager Using USB Debug Interface using VID/PID 0x2047/0x0010**




Figure C-4. Device Manager Using USB Debug Interface with VID/PID 0x0451/0xF430






Figure C-5. Device Manager Using USB Debug Interface with VID/PID 0x0451/0xF432

### Document Revision History

| Version  | Changes  |
|----------|--|
| SLAU278  | Initial release  |
| SLAU278A | Updated USB driver installation according to CCE v3.1 SR1 and CCS v4.  |
| SLAU278B | Added information about MSP-FET430U80USB, MSP-TS430PN80USB, and eZ430-Chronos.   |
| SLAU278C | Added bills of materials and updated some PCBs in Appendix B.<br>Added information about MSP-TS430DA38, MSP-TS430DL48, MSP-TS430PW14, MSP-TS430PW28.   |
| SLAU278D | Added information about MSP-TS430L092, MSP-TS430RSB40, MSP-TS430RGC64USB, MSP-TS430PZ100USB, MSP-FET430F5137RF900  |
| SLAU278E | Added jumper information for MSP-TS430L092 PCBs to Appendix B.<br>Added new supported devices in Chapter 1.  |
| SLAU278F | Added information about MSP-TS430PW24, MSP-TS430PW28A, MSP-TS430RHA40A, MSP-TS430RGZ48B, MSP-TS430RGC64B, MSP-TS430PN80A, and MSP-TS430PZ100B.<br>Updated MSP-TS430RSB40 schematics  |
| SLAU278G | Added information for MSP-TS430PZ100C  |
| SLAU278H | Added information for MSP-TS430D8 and MSP-TS430RGC64C  |
| SLAU278I | Updated <a href="#">Table 1-1</a> .<br>Replaced <a href="#">Figure 2-2</a> .<br>Added <a href="#">Figure 2-3</a> .<br>Replaced <a href="#">Figure B-37</a> and <a href="#">Figure B-67</a> .<br>Added <a href="#">Table C-1</a> .<br>Editorial changes throughout. |
| SLAU278J | Added EM430F6147RF900 <a href="#">Section B.33</a> .   |
| SLAU278K | Added battery pack connection information to all EM430Fx1x7RF900 kits.<br>Added information for MSP-TS430RGZ48C and MSP-TS430PEU128.<br>Updated <a href="#">Figure B-38</a> .  |
| SLAU278L | Changed descriptions in <a href="#">Section B.19</a> and <a href="#">Section B.30</a> .<br>Changed <a href="#">Figure B-60</a> .   |
| SLAU278M | Added information for MSP430G2x44 and MSP430G2x55 in <a href="#">Table 1-2</a> .   |

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

## **RF EMISSION TESTING**

All MSP-TS430xxx kits and kits listed below have been tested for compliance with Part 15 of the FCC and Canadian ICES-003 rules. See [REGULATORY COMPLIANCE INFORMATION](#) for details on compliance with these rules. All other kits described in this document either have not been tested or have the statement in their documentation, which is listed in [Related Documentation From Texas Instruments](#).

MSP-FET430UIF

## EVALUATION BOARD/KIT/MODULE (EVM) ADDITIONAL TERMS

Texas Instruments (TI) provides the enclosed Evaluation Board/Kit/Module (EVM) under the following conditions:

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please visit [www.ti.com/esh](http://www.ti.com/esh) or contact TI.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used. TI currently deals with a variety of customers for products, and therefore our arrangement with the user is not exclusive. TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

## REGULATORY COMPLIANCE INFORMATION

As noted in the EVM User's Guide and/or EVM itself, this EVM and/or accompanying hardware may or may not be subject to the Federal Communications Commission (FCC) and Industry Canada (IC) rules.

For EVMs **not** subject to the above rules, this evaluation board/kit/module is intended for use for ENGINEERING DEVELOPMENT, DEMONSTRATION OR EVALUATION PURPOSES ONLY and is not considered by TI to be a finished end product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC or ICES-003 rules, which are designed to provide reasonable protection against radio frequency interference. Operation of the equipment may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

### General Statement for EVMs including a radio

*User Power/Frequency Use Obligations:* This radio is intended for development/professional use only in legally allocated frequency and power limits. Any use of radio frequencies and/or power availability of this EVM and its development application(s) must comply with local laws governing radio spectrum allocation and power limits for this evaluation module. It is the user's sole responsibility to only operate this radio in legally acceptable frequency space and within legally mandated power limitations. Any exceptions to this are strictly prohibited and unauthorized by Texas Instruments unless user has obtained appropriate experimental/development licenses from local regulatory authorities, which is responsibility of user including its acceptable authorization.

### For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant

#### Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Interference Statement for Class A EVM devices

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### **FCC Interference Statement for Class B EVM devices**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **For EVMs annotated as IC – INDUSTRY CANADA Compliant**

This Class A or B digital apparatus complies with Canadian ICES-003.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Concerning EVMs including radio transmitters**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### **Concerning EVMs including detachable antennas**

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Cet appareil numérique de la classe A ou B est conforme à la norme NMB-003 du Canada.

Les changements ou les modifications pas expressément approuvés par la partie responsable de la conformité ont pu vider l'autorité de l'utilisateur pour actionner l'équipement.

### **Concernant les EVMs avec appareils radio**

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### **Concernant les EVMs avec antennes détachables**

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

## **【Important Notice for Users of this Product in Japan】**

### **This development kit is NOT certified as Confirming to Technical Regulations of Radio Law of Japan**

If you use this product in Japan, you are required by Radio Law of Japan to follow the instructions below with respect to this product:

1. Use this product in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use this product only after you obtained the license of Test Radio Station as provided in Radio Law of Japan with respect to this product, or
3. Use of this product only after you obtained the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to this product. Also, please do not transfer this product, unless you give the same notice above to the transferee. Please note that if you could not follow the instructions above, you will be subject to penalties of Radio Law of Japan.

**Texas Instruments Japan Limited**  
**(address) 24-1, Nishi-Shinjuku 6 chome, Shinjuku-ku, Tokyo, Japan**

<http://www.tij.co.jp>

#### **【ご使用にあたっての注】**

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社  
東京都新宿区西新宿6丁目24番1号  
西新宿三井ビル

<http://www.tij.co.jp>

## **EVALUATION BOARD/KIT/MODULE (EVM) WARNINGS, RESTRICTIONS AND DISCLAIMERS**

**For Feasibility Evaluation Only, in Laboratory/Development Environments.** Unless otherwise indicated, this EVM is not a finished electrical equipment and not intended for consumer use. It is intended solely for use for preliminary feasibility evaluation in laboratory/development environments by technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems and subsystems. It should not be used as all or part of a finished end product.

Your Sole Responsibility and Risk. You acknowledge, represent and agree that:

1. You have unique knowledge concerning Federal, State and local regulatory requirements (including but not limited to Food and Drug Administration regulations, if applicable) which relate to your products and which relate to your use (and/or that of your employees, affiliates, contractors or designees) of the EVM for evaluation, testing and other purposes.
2. You have full and exclusive responsibility to assure the safety and compliance of your products with all such laws and other applicable regulatory requirements, and also to assure the safety of any activities to be conducted by you and/or your employees, affiliates, contractors or designees, using the EVM. Further, you are responsible to assure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard.
3. You will employ reasonable safeguards to ensure that your use of the EVM will not result in any property damage, injury or death, even if the EVM should fail to perform as described or expected.
4. You will take care of proper disposal and recycling of the EVM's electronic components and packing materials.

**Certain Instructions.** It is important to operate this EVM within TI's recommended specifications and environmental considerations per the user guidelines. Exceeding the specified EVM ratings (including but not limited to input and output voltage, current, power, and environmental ranges) may cause property damage, personal injury or death. If there are questions concerning these ratings please contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, some circuit components may have case temperatures greater than 60°C as long as the input and output are maintained at a normal ambient operating temperature. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors which can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during normal operation, please be aware that these devices may be very warm to the touch. As with all electronic evaluation tools, only qualified personnel knowledgeable in electronic measurement and diagnostics normally found in development environments should use these EVMs.

**Agreement to Defend, Indemnify and Hold Harmless.** You agree to defend, indemnify and hold TI, its licensors and their representatives harmless from and against any and all claims, damages, losses, expenses, costs and liabilities (collectively, "Claims") arising out of or in connection with any use of the EVM that is not in accordance with the terms of the agreement. This obligation shall apply whether Claims arise under law of tort or contract or any other legal theory, and even if the EVM fails to perform as described or expected.

**Safety-Critical or Life-Critical Applications.** If you intend to evaluate the components for possible use in safety critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, such as devices which are classified as FDA Class III or similar classification, then you must specifically notify TI of such intent and enter into a separate Assurance and Indemnity Agreement.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265  
Copyright © 2013, Texas Instruments Incorporated

## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

### Products

|                              |  |
|------------------------------|--|
| Audio                        | <a href="http://www.ti.com/audio">www.ti.com/audio</a>                               |
| Amplifiers                   | <a href="http://amplifier.ti.com">amplifier.ti.com</a>                               |
| Data Converters              | <a href="http://dataconverter.ti.com">dataconverter.ti.com</a>                       |
| DLP® Products                | <a href="http://www.dlp.com">www.dlp.com</a>   |
| DSP                          | <a href="http://dsp.ti.com">dsp.ti.com</a>   |
| Clocks and Timers            | <a href="http://www.ti.com/clocks">www.ti.com/clocks</a>                             |
| Interface                    | <a href="http://interface.ti.com">interface.ti.com</a>                               |
| Logic                        | <a href="http://logic.ti.com">logic.ti.com</a>                                       |
| Power Mgmt                   | <a href="http://power.ti.com">power.ti.com</a>                                       |
| Microcontrollers             | <a href="http://microcontroller.ti.com">microcontroller.ti.com</a>                   |
| RFID                         | <a href="http://www.ti-rfid.com">www.ti-rfid.com</a>                                 |
| OMAP Applications Processors | <a href="http://www.ti.com/omap">www.ti.com/omap</a>                                 |
| Wireless Connectivity        | <a href="http://www.ti.com/wirelessconnectivity">www.ti.com/wirelessconnectivity</a> |

### Applications

|                               |  |
|-------------------------------|--|
| Automotive and Transportation | <a href="http://www.ti.com/automotive">www.ti.com/automotive</a>                         |
| Communications and Telecom    | <a href="http://www.ti.com/communications">www.ti.com/communications</a>                 |
| Computers and Peripherals     | <a href="http://www.ti.com/computers">www.ti.com/computers</a>                           |
| Consumer Electronics          | <a href="http://www.ti.com/consumer-apps">www.ti.com/consumer-apps</a>                   |
| Energy and Lighting           | <a href="http://www.ti.com/energy">www.ti.com/energy</a>                                 |
| Industrial                    | <a href="http://www.ti.com/industrial">www.ti.com/industrial</a>                         |
| Medical                       | <a href="http://www.ti.com/medical">www.ti.com/medical</a>                               |
| Security                      | <a href="http://www.ti.com/security">www.ti.com/security</a>                             |
| Space, Avionics and Defense   | <a href="http://www.ti.com/space-avionics-defense">www.ti.com/space-avionics-defense</a> |
| Video and Imaging             | <a href="http://www.ti.com/video">www.ti.com/video</a>                                   |

### TI E2E Community

[e2e.ti.com](http://e2e.ti.com)